

➡ **COPIER SUPPLIES & PARTS CATALOG**

➡ **COPIER REPLACEMENT TONER CARTRIDGES CATALOG**

➡ **DOWNLOAD FORMS**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****CANON®****CANON IMAGERUNNER 400, 330**

|  |       |
|--|-------|
| Uni Drum™ F with gears for use in Canon Imagerunner 330, 400   | 7316  |
| SuMMiT® drum with gears for us in Canon IR 3320, 330, 2800, 2200, 400, 330, 220, 210, 200  | 12715 |
| Uni Drum™ with gears for use in Canon Imagerunner 330, 400   | 12896 |
| Wiper blade for use in Canon Imagerunner 330, 400  | 14593 |
| Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030 | 19526 |

**CANON IMAGERUNNER 6000, 5000, 600, 550**

|  |       |
|--|-------|
| Absolute Black® toner for use in Canon Imagerunner 6000, 5000 (10K bag)  | 11038 |
| Pick-Off finger upper for use in Canon iR 550, 5000, 5075, 6000, NP 6050, 6551, 6570, 7500                                 | 12122 |
| Upper fuser heat roller for use in Canon IR 6020, 6000, 5000   | 16241 |
| Absolute Black® toner for use in Canon Imagerunner 600, 550  | 17093 |
| Absolute Black® toner for use in Canon IR 6000, 5000   | 18348 |
| Paper pickup roller for use in Canon IR 550, 600, 5000, 6000, 7200   | 19348 |
| Front Upper Fuser Roller Gear 52T for use in Canon IR 6000, 5000   | 19352 |
| Upper Picker Finger for use in Canon iR 8500, 7200, 7105, 7095, 7086, 6570, 6020, 6000, 5570, 6065, 5055, 5050, 5020, 5000 | 19678 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****CANON IMAGERUNNER 1018, 1019, 1020, 1022, 1023, 1024, 1025**

SuMMiT® drum with gears for use in Canon™ Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025

17488

PCR for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024, 1025

17807

Absolute Black® toner for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024,1025

17843

Absolute Black® toner for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024,1025, 465g

18595

Wiper Blade for use in Canon IR 1025, 1024, 1023, 1022, 1019, 1018

19188

**CANON IMAGERUNNER 1600, 2000, 2010**

Absolute Black® toner for use in Canon IR 1600, 2000, 2010

6027

Clear Seal™ adhesive for use in Canon IR 1600, 2000, 2010

6949

Black Mag roller sleeve for use in Canon IR 1600, 2000, 2010

7161

Uni Drum™ with gears for use in Canon IR 1600, 2000, 2010

12716

X-Generation® Wiper blade for use in Canon IR 1600, 2000, 2010

17933

**CANON IMAGERUNNER 2016, 2018, 2020, 2022, 2025, 2030**

Uni Drum™ with gears for use in Canon IR 2016, 2020

12892

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Wiper blade for use in Canon IR 2016, 2020 12898

SuMMiT® OPC drum with gears for use in Canon IR Advance C 2030, 2020, 2016 GPR-36 19407

**CANON IMAGERUNNER 2200, 2300, 2800, 3300**

Uni Drum™ F with gears for use in Canon IR 2200, 2800, 3300 7056

Wiper blade for use in Canon IR 2200, 2800, 3300 , 10068

SuMMiT™ drum with gears for use in Canon IR 2200, 2800, 3300 12715

Absolute Black® toner for use in Canon IR 2200, 2800, 3300 16710

Fuser film for use in Canon IR 3300, 2800, 2200 19829

Fixing Film Assembly unit for use in Canon IR 2200, 2800, 3300, 3320 19637

**CANON IMAGERUNNER 6000, 5000, 7095, 7085, 7200, 8500, NP 6050, 6020, 6551, 6570, 5570, 550, 600**

Absolute Black® toner for use in Canon IR 6000, 5000 11038

Pick-Off finger upper for use in Canon iR 550, 5000, 5075, 6000, NP 6050, 6551, 6570, 7500, FB5-3625-000, FB5-8727-00 12122

Heat roller for Canon IR 5000, 6000 16241

Absolute Black® toner for use in Canon IR 6000, 5000, 1500g 18348

Upper fuser roller for use in Canon IR 9070, 8500, 8070, 7200, 7105, 7095, 7086, 105, 85 19346

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Paper pickup roller for use in Canon IR 550, 600, 5000, 6000, 7200   | 19348 |
| Paper feed pick up roller for use in Canon iR 6570, 6020, 6000, 5570, 5050, 5020, 5000, FF5-9779-000, FB5-3435-000                               | 19353 |
| Lower fuser pressure roller for use in Canon IR 6020, 6000, 5000, FB5-3619-000   | 19460 |
| Fuser Cleaning web for use in Canon IR 8500, 7200, 7105, 7095, 7085, 6570, 6020, 6000, 5070, 5065, 5050, 5020, 5000, 600, 500, 105, FY1-1157-000 | 19461 |
| Lower fuser roller bearing for use in Canon IR 6020, 6000, 5020, 5000, 600, 60, XG9-0018-000   | 19675 |
| Upper Picker Finger for use in Canon iR 8500, 7200, 7105, 7095, 7086, 6570, 6020, 6000, 5570, 6065, 5055, 5050, 5020, 5000, FA2-9037-000         | 19678 |

**CANON IMAGERUNNER C 3380, 2880, 2550, 3480**

|   |       |
|---|-------|
| Absolute Black® toner for use in Canon IR C 3380, 2880, 2550, 3480                          | 13003 |
| Absolute Cyan™ toner for use in Canon IR C 3380, 2880, 2550, 3480                           | 13004 |
| Absolute Magenta™ toner for use in Canon IR C 3380, 2880, 2550, 3480                        | 13005 |
| Absolute Yellow™ toner for use in Canon IR C 3380, 2880, 2550, 3480                         | 13006 |
| Uni Drum® with gears for use in Canon IR C 3580, 3480, 3380, 3080, 2880, 2550, 2380, GPR 23 | 19241 |
| Fuser film OEM for use in Canon IR C 3580, 3380, 3080, 2880, 2380, FM3-1994                 | 19831 |

**CANON IMAGERUNNER C 3100, 3170**

|  |       |
|--|-------|
| Black toner for use in Canon IR C 3100, 3170 | 11110 |
|--|-------|

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Cyan toner for use in Canon IR C 3100, 3170

11111

Magenta toner for use in Canon IR C 3100, 3170

11112

Yellow toner for use in Canon IR C 3100, 3170

11113

**CANON EP 105, MF 7280, 7460, 7470, 7480 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11591

Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11590

Clear Seal™ adhesive with foam for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11595

Mag roller for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11596

SuMMiT™ drum with gears for use in Canon EP 105, MF 7280, 7270, 7260, 7240

11592

**CANON GP 200**

Drum for use in Canon GP 200 F

7411

Uni Drum™ with gears for use in Canon GP 200

12895

Wiper blade for use in Canon GP 200

12897

**CANON GP 40**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Canon GP 40

7235

Drum with gears for use in Canon GP 40

7181

**CANON NP 6012, 6016**

Uni Drum™ F with gears for use in Canon NP 6012, 6014,

11397

Uni Drum™ S with gears for use in Canon NP 6012, 6014,

12540

**CANON NP 1510, 1215, 2120**

Uni Drum™ F w/gears for use in Canon NP 1215, 2020, 2120

102

X-Generation® Wiper blade for use in Canon NP 1510, 1215, 2020, 2120

105

Uni Drum™ with gears for use in Canon NP 1215, 2020, 2120

12539

Absolute Black® toner for use in Canon NP 1510, 1215, 2120

16045

Absolute Black® toner for use in Canon NP 1510, 1215, 2120

16564

**CANON NP 3030, 3050, 4050, 4080**

Wiper blade for use in Canon NP 3325, 3030, 4050, 4835

7141

Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030

19526

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****CANON NP 6030, 6025, 6330, NPG 7**

Uni Drum™ F with gears for use in Canon NP 6030, 6025, 6330

7409

Absolute Black® toner for use in Canon NP 6030, 6025, 6330, NPG 7

8295

Uni Drum™ drum for use in Canon NP 6030, 6025, 6330

8545

Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP 3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030

19526

**CANON NP 6045, 6050, 6060, 6085**

Absolute Black® toner for use in Canon NP 6045, 6050, 6060, 6085

11746

**DELCO AVANTI®****DELCO AVANTI 2600, 2650, 2690**

Absolute Black® toner for use in Delcop Avanti 2600, 2650, 2690

17939

Drum unit cover for use in Delcop Avanti 2600, 2650, 2690

17942

Smartchip® for use in Delcop Avanti 2600, 2650, 2690

17934

Uni Drum® with gears for use in Delcop Avanti 2600, 2650, 2690

17940



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****EPSON®****EPSON ACULASER C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF                         | 12526 |
| Smartchip™ Cyan for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF                          | 12527 |
| Smartchip™ Magenta for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF                       | 12528 |
| Smartchip™ Yellow for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF                        | 12529 |
| Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C   | 16659 |
| Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C    | 16660 |
| Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C | 16661 |
| Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C  | 16662 |
| Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C   | 17344 |
| Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C    | 17345 |
| Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C | 17346 |
| Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C  | 17347 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****EPSON ACULASER M 1400, MX 14 NF (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF

16675

Smartchip™ Black for use in Epson Aculaser M 1400, MX 14 NF

16676

Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF

17553

**EPSON ACULASER M 2400, 2300, MX 20 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20

16750

Smartchip™ for use in Epson Aculaser M 2400, MX 20, C13S050582

16750

Absolute Black® toner for use in Epson Aculaser M 2400, 2300, MX 20

17252

Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20

17438

Smartchip™ for use in Epson Aculaser M 2300, 2400, MX 20, C13S050583

19297

**FUJI XEROX ®****FUJI XEROX DOCUPRINT C 2250, 3360, DOCUCENTRE C 2205, 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305

18295

Smartchip® CMYK drum unit for use in Fuji Xerox DocuPrint C 3360, 2250

18305

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****FUJI XEROX DOCUPRINT C 3305, 2205 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip® CMYK drum unit for use in Fuji Xerox DocuPrint C 3305, 2205 18306

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305 18295

**FUJI XEROX DOCUPRINT C 3350**

Smartchip® Black for use in Fuji Xerox Docuprint C 3350 18020

Smartchip® Cyan for use in Fuji Xerox Docuprint C 3350 18021

Smartchip® Magenta for use in Fuji Xerox Docuprint C 3350 18022

Smartchip® Yellow for use in Fuji Xerox Docuprint C 3350 18023

Absolute Black® toner for use in Fuji Xerox Docuprint C 3350 18024

Absolute Cyan® toner for use in Fuji Xerox Docuprint C 3350 18025

Absolute Magenta® toner for use in Fuji Xerox Docuprint C 3350 18026

Absolute Yellow® toner for use in Fuji Xerox Docuprint C 3350 18027

Absolute Cyan® toner for use in Fuji Xerox Docuprint C 3350 19771

Absolute Black® toner for use in Fuji Xerox Docuprint C 3350 19770

Absolute Magenta® toner for use in Fuji Xerox Docuprint C 3350 19772

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Yellow® toner for use in Fuji Xerox Docuprint C 3350

19773

**FUJI XEROX DOCUPRINT C 1190 FS**

Smartchip® Black for use in Fuji Xerox Docuprint C 1190 FS

14895

Smartchip® Cyan for use in Fuji Xerox Docuprint C 1190 FS

14896

Smartchip® Magenta for use in Fuji Xerox Docuprint C 1190 FS

14897

Smartchip® Yellow for use in Fuji Xerox Docuprint C 1190 FS

14898

X-Generation® Black toner for use in Fuji Xerox Docuprint C 1190 FS

14899

X-Generation® Cyan toner for use in Fuji Xerox Docuprint C 1190 FS

14900

X-Generation® Magenta toner for use in Fuji Xerox Docuprint C 1190 FS

14901

X-Generation® Yellow toner for use in Fuji Xerox Docuprint C 1190 FS

14902

**FUJI XEROX DOCUPRINT C 5000**

Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000, 5005

17036

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000, 5005

17045

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint C 5000, 5005

17046

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000, 5005

17047

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000

17584

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000

17585

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000

17587

**FUJI XEROX DOCUPRINT CM 505**

Smartchip™ Black toner for use in Fuji Xerox Docuprint CM 505

17037

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CM 505

17038

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CM 505

17039

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CM 505

17040

X-Generation® Black toner for use in Fuji Xerox Docuprint CM 505 16,000 pages

18944

X-Generation® Cyan toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18945

X-Generation® Magenta toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18946

X-Generation® Yellow toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18947

**FUJI XEROX DOCUPRINT CP 305, CM 305**

Smartchip™ Black toner for use in Fuji Xerox Docuprint CP 305, CM 305

17041

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305

17042

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305

17043

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305

17044

X-Generation® Black toner for use in Fuji Xerox Docuprint CP 305, CM 305

17935

X-Generation® Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305

17936

X-Generation® Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305

17937

X-Generation® Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305

17938

**C 2250, 3360, DOCUCENTRE C 2205, 3305**

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305

18295

**FUJI XEROX DOCUCENTRE IV C 4430 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Fuji Xerox Docucentre IV C4430

17276

Absolute Cyan® toner for use in Fuji Xerox Docucentre IV C4430

17277

Absolute Magenta® toner for use in Fuji Xerox Docucentre IV C4430

17278

Absolute Yellow® toner for use in Fuji Xerox Docucentre IV C4430

17279

Smartchip® Black toner for use in Fuji Xerox Docucentre IV C4430

17286

Smartchip® Cyan toner for use in Fuji Xerox Docucentre IV C4430

17287

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® Magenta toner for use in Fuji Xerox Docucentre IV C4430          | 17288 |
| Smartchip® Yellow toner for use in Fuji Xerox Docucentre IV C4430, CT201679 | 17289 |
| Smartchip® Black drum unit for use in Fuji Xerox Docucentre IV C4430        | 17469 |
| Smartchip® Cyan drum unit for use in Fuji Xerox Docucentre IV C4430         | 17470 |
| Smartchip® Magenta drum unit for use in Fuji Xerox Docucentre IV C4430      | 17471 |
| Smartchip® Yellow drum unit for use in Fuji Xerox Docucentre IV C4430       | 17472 |

**FUJI XEROX DOCUPRINT M 265, 225, P 265, 225**

|   |       |
|---|-------|
| High Yield Reset Lever Gear for use in Fuji Xerox Docuprint M 265, 225, P 265, 225                                    | 19970 |
| High Yield Reset Lever Gear w/ Spring and Fill Plug for use in Fuji Xerox DocuPrint P 265, 260, 225, M 265, 260z, 225 | 21048 |

**HP®****HP CM 6030, 6040 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in HP CP 6015, CM 6030, 6040 | 13294 |
| Absolute Black® toner for use in HP CP 6015, CM 6030, 6040 | 13290 |
| Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040  | 13295 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040

13291

Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040

13296

Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040

13292

Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040

13297

Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040

13293

ASiC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040

15253

ASiC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040

13765

ASiC Smartchip® Black toner for use in HP CP 6015, CM 6030

15257

ASiC Smartchip® Black toner for use in HP CP 6015, CM 6030

13298

ASiC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040

15254

ASiC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040

13766

ASiC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040

15258

ASiC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040

13299

ASiC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040

15255

ASiC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040

13767

ASiC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040

15259

ASiC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040

13300



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| ASiC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040   | 15256 |
| ASiC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040   | 13768 |
| ASiC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040  | 15260 |
| ASiC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040  | 13301 |
| SuMMiT™ OPC drum with gears for use in HP CP 6015, CM 6030, 6040   | 13769 |
| X-Generation® Wiper blade for use in HP CM 6040 MFP                | 16558 |
| Uni Drum™ OPC with gears for use in HP CP 6015, CM 6030, 6040      | 16755 |
| Drum cover for use in HP Color LaserJet CP 6015, CM 6040, 6030 MFP | 20444 |

**HP LASERJET PRO 401, MFP M425**

|  |       |
|--|-------|
| Soft PCR roller for use in HP Laserjet Pro 401, MFP M425                       | 7080  |
| Seal pull tab for use in HP Laserjet Pro 401, MFP M 425                        | 9955  |
| Seal exit port plug for use in HP M 401, 425 MFP                               | 9957  |
| Universal Jumbo waste toner hopper conversion kit for use in HP M 401, 425 MFP | 17450 |
| Soft PCR roller for use in HP Laserjet Pro 401, MFP M 425                      | 18610 |

**HP CM 1312, 2320 MFP, M 476, 251, 276 MFP, Canon MF 8050**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Uni Drum™ with gears for use in HP CM 1312, 2320 MFP, M 476, 251, 276 MFP, Canon MF 8050   | 12610 |
| X-Generation® Wiper blade for use in HP CM 1312, 1415, 2320, Color Pro M 251, 276, 375, 451, 475, 476 MFP, Canon MF 8050,        | 12611 |
| Seal pull tab for use in HP CM 1312, 1415, 476 MFP   | 13022 |
| Shipping drum cover lock for use in HP CM 1312, 1415 MFP   | 13025 |
| X-Generation® Black toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)                                     | 13537 |
| X-Generation® Cyan toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)                                      | 13539 |
| X-Generation® Magenta toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)                                   | 13541 |
| X-Generation® Yellow toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050)(MPT-251)                                    | 13543 |
| X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451, (10 kg) bag (MPT-251) | 13544 |
| Supply roller for use in HP CM 1312 MFP  | 14077 |

**HP CM 2320 MFP**

|  |       |
|--|-------|
| X-Generation® Black toner for use in HP CM 2320 MFP (MPT-2025)   | 13271 |
| X-Generation® Cyan toner for use in HP CM 2320 MFP (MPT-2025)    | 13272 |
| X-Generation® Magenta toner for use in HP CM 2320 MFP (MPT-2025) | 13273 |
| X-Generation® Yellow toner for use in HP CM 2320 MFP (MPT-2025)  | 13274 |
| Seal pull tab for use in HP CM 2320 MFP                          | 13850 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Waste section for use in HP CM 2320 MFP

14739

X-Generation® Black toner for use in HP CM 2320 MFP (MPT-251)

20114

X-Generation® Cyan toner for use in HP CM 2320 MFP (MPT-251)

20115

X-Generation® Magenta toner for use in HP CM 2320 MFP (MPT-251)

20116

X-Generation® Yellow toner for use in HP CM 2320 MFP (MPT-251)

20117

**HP CM 3530 MFP, M 551, 575**

X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575

13650

X-Generation® Cyan toner for use in HP CM 3530 MFP, M 551, 575

13651

X-Generation® Magenta toner for use in HP CM 3530 MFP, M 551, 575

13652

X-Generation® Yellow toner for use in HP CM 3530 MFP, M 551, 575

13653

X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575

13654

Uni Drum™ with gears for use in HP CM 3530, 3525 MFP, Laserjet 500, M 551, M 651

13655

Smartchip™ Black for use in HP CM 3530 MFP

13715

SuMMiT® drum with gears for use in HP CM 3530, 3525 MFP

13934

Wiper blade for use in HP CM 3530, 4540 MFP, M 551, 575, 651

14503

X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)

18212

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| X-Generation® Cyan toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)    | 18213 |
| X-Generation® Magenta toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525) | 18214 |
| X-Generation® Yellow toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)  | 18215 |
| X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575 (MPT 4525)   | 18230 |

**HP CM 4540 MFP**

|  |       |
|--|-------|
| X-Generation® Black toner for use in HP CM 4540 MFP (MPT-4525)               | 14996 |
| X-Generation® Cyan toner for use in HP CM 4540 MFP (11,000 pages)            | 14997 |
| X-Generation® Magenta toner for use in HP CM 4540 MFP                        | 14998 |
| X-Generation® Yellow toner for use in HP CM 4540 MFP                         | 14999 |
| X-Generation® Black toner for use in HP CM 4540 MFP (MPT-4525)               | 15033 |
| Uni Drum™ with gears for use in HP CM 4540 MFP, M 551, 575 (with longer hub) | 17523 |

**HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451**

|   |       |
|---|-------|
| SuMMiT® drum with gears for use in HP M 251, 276, 375, 451, 475, 476 MFP, Canon MF 8050 (X-Generation®)   | 13220 |
| X-Generation® Black toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (10 kg) bag (MPT-251) | 13538 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Cyan toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (10 kg) bag (MPT-251) 13540

X-Generation® Magenta toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451, (10 kg) bag (MPT-251) 13542

X-Generation® Black toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17910

X-Generation® Cyan toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17911

X-Generation® Magenta toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17912

X-Generation® Yellow toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17913

X-Generation® Black toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 18030

X-Generation® Black toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18266

X-Generation® Cyan toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18267

X-Generation® Magenta toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18268

X-Generation® Yellow toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18269

Waste section for use in HP Laserjet Pro 200, M 251, 276, CP 1525, 1215,1515,1518, CM 1312, 1415 MFP 18346

X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 252, MFP M 277 20693

X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 252, MFP M 277 20727

**HP LASERJET PRO 300, 400, MFP M 351, 375, 475, 451**

SuMMiT® drum with no gears for use in HP Pro 400, MFP M 425 13372

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

SuMMiT® drum with no drive gear for use in HP Pro 402, 401, 400, MFP M 527, 426, 425 14013

Wiper blade for use in HP Pro 400, MFP M 425 16147

X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 17142

X-Generation® Cyan toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 17143

X-Generation® Magenta toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 17144

X-Generation® Yellow toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 17145

X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 17148

SuMMiT® drum with gears for use in HP Laserjet 300, 400, CM 1312, 1415, 2320, M 375, 475, 451 MFP, Canon MF 8050 17414

X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 18207

X-Generation® Cyan toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 18208

X-Generation® Magenta toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 18209

X-Generation® Yellow toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 18210

X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251) 18211

**HP M 226, 225, 202, 201, 127, 125 MFP, M 26, 12, Canon MF 227, 212**

SuMMiT® drum with gears for use in HP M 202, 201, MFP M 226, 225, 127, 125, 26, 12 12740

Wiper blade for use in HP M 226, 225, 202, 201, 127, 125 MFP, M 26, 12, Canon MF 227, 212 16139

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****HP LASERJET PRO M 447, 337, 277 MFP, M 252**

X-Generation® Black toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252) 20158

X-Generation® Cyan toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252) 20159

X-Generation® Magenta toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252) 20160

X-Generation® Yellow toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252) 20161

SuMMiT® drum for use in for use in HP Color LaserJet Pro M 477, 277 MFP, M 452, 252 20167

SuMMiT® drum with gears for use in for use in HP Color LaserJet Pro M 277 MFP, M 252 20223

SuMMiT® OPC drum gearless for use in for use in HP Color LaserJet Pro M 277 MFP, M 252 20230

X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252) 20232

X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252) 20233

X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252) 20234

X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252) 20235

X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252) 20236

X-Generation® Cyan glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252) 20237

X-Generation® Magenta glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252) 20238

X-Generation® Yellow glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252(10 kg) bag (MPT-252) 20239

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 552, 553 (MPT-252)     | 20303 |
| X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 553, 552, 553 (MPT-252) | 20304 |
| X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)             | 20305 |
| X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 552, 553 (MPT-252)    | 20306 |
| X-Generation® Black toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)                    | 20367 |
| X-Generation® Cyan toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)                     | 20368 |
| X-Generation® Magenta toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)                  | 20369 |
| X-Generation® Yellow toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)                   | 20370 |
| Wiper blade for use in HP Color LaserJet Pro M 477, 277 MFP, M452, 252                                   | 20422 |
| X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)               | 20644 |
| X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)                | 20645 |
| X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)             | 20646 |
| X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)              | 20647 |
| X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 452, MFP M 477           | 20653 |
| X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 452, MFP M 477           | 20728 |
| Uni Drum® with gears for use in for use in HP Color LaserJet Pro M 477, 277 MFP, M 452, 252              | 21198 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****HP M 506, 501, MFP M 527, M 402, MFP M 426**

X-Generation® toner for use in HP M 506, 501, MFP M 527, M 402, MFP M 426

20293

X-Generation® toner for use in HP M 506, 501, 402, MFP M 527, 426 (10 kg) bag

20383

Wiper blade for use in HP Laserjet Enterprise M 506, 501, MFP 527, Pro 402, MFP 426

20463

X-Generation® Black toner for use in HP M 402, 426 MFP

20695

X-Generation® Black toner for use in HP M 506, 501, 402, MFP M 527, 426

20909

X-Generation® black toner for use in HP M 506, 501, 527 MFP

20915

**HP LASERJET PRO M 26 MFP, M 12**

X-Generation® black toner for use in HP Laserjet Pro M 26 MFP, M 12

21066

**HP M 5035, 5025, 712, 435 MFP**

SuMMiT® OPC drum with gear for use in HP M 5035, 5025, 712, 435 MFP

16411

**HP LASERJET ENTERPRISE MFP M 630, 625**

X-Generation® toner for use in HP laserjet Enterprise MFP M 630, 625 (MPT-4015/M600 X GEN)

19680

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA®****KYOCERA FS 1370, 1320, 1220, 1041, TK 174, 172, 170,**

Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170 15968

Empty toner cartridge for use in Kyocera FS 1370, 1320, TK 174, 173, 172, 170 15969

Smartchip™ for use in Kyocera FS 1320 TK 170 17074

Smartchip™ for use in Kyocera FS 1320, TK 172 17167

Smartchip™ for use in Kyocera FS 1320, TK 174 17168

Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170 17318

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1115 1,600 pages, EUR 18895

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1119 1,600 pages, AUS 18899

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1117 1,600 pages US 19000

Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370, (100,000 pages) 19430

**KYOCERA FS 1000, TK 17 H**

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified) 7158

Absolute Black® toner for use in Kyocera FS 1000 TK 17 H (AMES Certified toner) 8694

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Toner hopper fill plug for use in Kyocera FS 1000, 1020, KM 1500, TK 17, LA, TK 18 H

9972

Black Airbag for Kyocera FS 1000 Cartridges

14972

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified toner)

16494

**KYOCERA FS 1020 MFP, 1118, TK 18 H**

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified)

7158

Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H (AMES Certified toner)

8881

Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H (AMES Certified)

9787

Toner hopper fill plug for use in Kyocera FS 1000,1020, KM 1500, TK 17, LA, TK 18 H,

9972

Absolute Black® refill toner for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1)

16494

Absolute Black® toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110, 1112, 1114

19076

Smartchip™ toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110

19080

Smartchip™ toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1112

19081

Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020

19428

**KYOCERA FS 1700, TK 20 H**

Absolute Black® toner for use in Kyocera FS 1700, TK 20 H (AMES Certified toner)

6074

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Waste hopper bottle for use in Kyocera FS 1700, TK 20 H

7315

Absolute Black® toner for use in Kyocera FS 1700, TK 20 H (AMES Certified toner)

8341

Absolute Black® toner for use in Kyocera TK 112, 67, 55, 50, 20, 18, 17, FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, 1kg

16494

**KYOCERA FS 3900, TK 322, 320**

Absolute Black® toner for use in Kyocera FS 3900, TK 322, 320 (AMES Certified)

10979

Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900

11118

Smartchip™ for use in Kyocera FS 3900, TK 322

11546

Smartchip™ for use in Kyocera FS 3900, TK 320

12684

Smartchip™ for use in Kyocera FS 3900, TK 324

17170

Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820

19589

**KYOCERA FS 4000 ,TK 332, 330**

Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 (AMES Certified)

10978

Absolute Black® toner cartridge for Kyocera FS 4000 ,TK 332, 330,

11119

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

11547

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

12685

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 (AMES Certified toner)

14058

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

16784

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

17171

Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820

19589

**KYOCERA FS 9100, 9500, TK 70 H**

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H(AMES Certified)

7599

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H (AMES Certified)

8966

Waste toner bottle for use in Kyocera FS 9100, 9500, TK 70 H

9606

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H (AMES Certified)

13726

Wiper blade for use in Kyocera FS 9530, 9500, 9130, 9120, 9100, KM 5035, 4035, 4030, 3530, 3035, 2530

19220

**KYOCERA FS 1920, TK 57 H, 55 H**

Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H (AMES Certified)

5308

Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H (AMES Certified)

6444

Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1)

16494

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA FS 3820, TK 67, 65**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)  | 5253  |
| Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)  | 5254  |
| Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)  | 13663 |
| Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1) | 16494 |

**KYOCERA FS 1035, 1135, TK 1140 MFP, TK 1142, TK 1144, TK 1147 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip® for use in Kyocera FS 1035, 1135 MFP, TK 1140  | 17361 |
| Smartchip® for use in Kyocera FS 1035, 1135MFP, TK 1142   | 17371 |
| Smartchip® for use in Kyocera FS 1035, 1135MFP, TK 1144   | 17372 |
| Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147 (7,200 pages)(AMES Certified)                   | 17375 |
| Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147 (AMES Certified)                                | 17579 |
| X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140)(AMES Certified)                            | 17580 |
| X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140 (AMES Certified)                            | 17581 |
| Smartchip® for use in Kyocera FS 1035, 1135 MFP, TK 1147  | 17831 |
| Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370, (100,000 pages) | 19430 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA FS 4020, TK 360, 362, 364**

|   |       |
|---|-------|
| Smartchip™ for use in Kyocera FS 4020, TK 360                                       | 14522 |
| Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364 (AMES Certified) | 14536 |
| Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364 (AMES Certified) | 14641 |
| Smartchip™ for use in Kyocera FS 4020, TK 362                                       | 16090 |
| Smartchip™ for use in Kyocera FS 4020, TK 364                                       | 17176 |

**KYOCERA FS 720, 820, 1016, TK 112, 110**

|  |       |
|--|-------|
| Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110)(AMES Certified toner)                       | 9115  |
| Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016(AMES Certified toner)     | 9975  |
| Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016(AMES Certified)           | 9976  |
| Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370 | 19430 |

**KYOCERA FS 1030, 1130 MFP, TK 1130, 1132, 1134 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120 (AMES Certified toner) | 10289 |
| Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120 (AMES Certified)       | 10290 |
| Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1130                       | 17360 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1132 17369

Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1134 17370

Absolute Black® toner for use in Kyocera FS 1030, 1130 MFP, TK 1130, 1132, 1134 17376

**KYOCERA FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for Kyocera TK 142, 140, FS 1100 (AMES Certified toner) 12614

Absolute Black® toner for use in Kyocera FS 1300, 1350, TK 132, 130 (AMES Certified toner) 12616

Absolute Black® toner for Kyocera FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104 (AMES Certified toner) 12617

Smartchip™ for use in Kyocera FS 1300, TK 130 12686

Smartchip™ for use in Kyocera TK 140, FS 1100, Europe 12687

Smartchip™ for use in Kyocera FS 1300, TK 132 16067

Absolute Black® toner for Kyocera TK 1100, 1102, 1104, FS 1110, 1024, 1124, 2,100 pages ( AMES Certified) 16828

Smartchip™ for use in Kyocera FS 1300, 1350, 1128, 1028, TK 134 17158

Smartchip™ for use in Kyocera TK 142, FS 1100 4,000 pages, US 17162

Smartchip™ for use in Kyocera TK 144, FS 1100 4,000 pages, AU 17163

Smartchip™ toner for Kyocera TK 1100, FS 1110, 1024, 1124, Europe 18716

Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370 19430



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA FS 9530, 9130, TK 712, 710**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 9530, 9130, TK 712, 710 (AMES Certified)                  | 10983 |
| Absolute Black® toner for use in Kyocera TK 712, 710, FS 9530, 9130                                   | 11881 |
| Absolute Black® toner for use in Kyocera FS 9530, 9130, TK 712, 710 (AMES Certified)                  | 13382 |
| Smartchip™ for use in Kyocera FS 9130, 9530, TK 712, FS 9530, 9130                                    | 14432 |
| Smartchip™ for use in Kyocera FS 9130, 9530, TK 710,  | 17223 |
| Smartchip™ for use in Kyocera FS 9130, 9530, TK 714   | 17224 |
| Wiper blade for use in Kyocera FS 9530, 9500, 9130, 9120, 9100, KM 5035, 4035, 4030, 3530, 3035, 2530 | 19220 |

**KYOCERA FS 2000, TK 314, 312, 310**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 2000, TK 312, 310 (AMES Certified)  | 10982 |
| Smartchip™ for use in Kyocera FS 2000, TK 312   | 11545 |
| Smartchip™ for use in Kyocera FS 2000, TK 310   | 12683 |
| Smartchip™ for use in Kyocera FS 2000, TK 314   | 17169 |
| Lower fuser roller for use in Kyocera Mita FS1128MFP, FS1028MFP, FS2000D, FS2020D, FS3900DN, FS4000DN, KM2810, KM2820, 2F925270 | 19589 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA FS 2020,TK 340, 342, 344**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 2020, TK 340, 342, 344, FS 2020 (AMES Certified toner)                            | 14585 |
| Smartchip™ for use in Kyocera FS 2020, TK 340 (Europe)  | 15020 |
| Absolute Black® toner for use in Kyocera FS 2020,TK 340, 342, 344 (AMES Certified)  | 15185 |
| Smartchip™ for use in Kyocera FS 2020, TK 342 (US)  | 17172 |
| Smartchip™ for use in Kyocera FS 2020, TK 344 (AU)  | 17173 |
| Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820 | 19589 |

**KYOCERA FS 1900, TK 50**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 1900, TK 50 (AMES Certified)  | 8877  |
| Absolute Black® toner for use in Kyocera FS 1900, TK 50 H (AMES Certified)  | 9597  |
| Absolute Black® toner for use in Kyocera FS 1900, TK 50 H (AMES Certified)  | 12287 |
| Absolute Black® toner for use in Kyocera TK 112, 67, 55, 50, 20, 18, 17, FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, 1kg | 16494 |

**KYOCERA FS 2100, 3100, 4100, 4200, 4300, TK 3104, 3102, 3100 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Kyocera , FS 2100, TK 3104, 3102, 3100 (AMES Certified) | 18125 |
| Smartchip™ toner for use in Kyocera FS 2100, TK 3100 (Europe)                            | 18134 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ toner for use in Kyocera FS 2100, M 3040, 3540, TK 3102 (USA) 18135

Smartchip™ toner for use in Kyocera FS 2100, TK 3104 (AUS) 18755

X-Generation® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100 18844

X-Generation® toner for use in Kyocera FS 2100, M 3040, 3540, TK 3104, 3102, 3100 18847

Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134 19008

Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 19739

**KYOCERA FS 4100, TK 3114, 3112, 3110, FS 4100 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Kyocera FS 4100, TK 3114, 3112, 3110 18122

Smartchip™ toner for use in Kyocera FS 4100, TK 3112 (USA) 18127

Smartchip™ toner for use in Kyocera FS 4100, TK 3110 (Europe) 18128

Smartchip™ toner for use in Kyocera FS 4100, TK 3114 (AUS) 18756

X-Generation® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100 18844

Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134 19008

X-Generation® toner for use in Kyocera FS 4100, TK 3114, 3112, 3110 19096

Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 19739

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA FS 4200, TK 3124, 3122, 3120 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Kyocera FS 4200, TK 3124, 3122, 3120 (AMES Certified)   | 18123 |
| Smartchip™ toner for use in Kyocera FS 4200, M 3550, TK 3122 (USA)   | 18130 |
| Smartchip™ toner for use in Kyocera FS 4300, 4200, M 3560, TK 3130 (Europe)  | 18133 |
| X-Generation ® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100           | 18844 |
| X-Generation® Black toner for use in Kyocera FS 4200, TK 3124, 3122, 3120  | 18845 |
| Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134 | 19008 |
| Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 (MPT-TK2)            | 19739 |

**KYOCERA FS 3800, TK 60 H**

|  |       |
|--|-------|
| Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner) | 6171  |
| Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner) | 8342  |
| Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner) | 16494 |

**KYOCERA FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350, (AMES Certified toner) | 14586 |
| Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP,TK 350, 352 (AMES Certified)              | 14808 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ for use in Kyocera FS 3920, TK 350

17141

Smartchip™ for use in Kyocera FS 3920, TK 352, FS 3920

17174

Smartchip™ for use in Kyocera FS 3920, TK 354, FS 3920

17175

**KYOCERA FS C 5400, 5350, 5250, 5150, 5200, 5100 TK 570, 572, 574**

Smartchip™ for use in Kyocera FS C 5400, TK 574, Black

17200

Smartchip™ for use in Kyocera FS C 5400, TK 574, Cyan

17201

Smartchip™ for use in Kyocera FS C 5400, TK 574, Magenta

17202

Smartchip™ for use in Kyocera FS C 5400, TK 574, Yellow

17203

Smartchip™ for use in Kyocera FS C 5400, TK 570, Black

17439

Smartchip™ for use in Kyocera FS C 5400, TK 570, Cyan

17440

Smartchip™ for use in Kyocera FS C 5400, TK 570, Magenta

17441

Smartchip™ for use in Kyocera FS C 5400, TK 570, Yellow

17442

Smartchip™ for use in Kyocera FS C 5400, TK 572, Black

17620

Smartchip™ for use in Kyocera FS C 5400, TK 572, Cyan

17621

Smartchip™ for use in Kyocera FS C 5400, TK 572, Magenta

17622

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ for use in Kyocera FS C 5400, TK 572, Yellow  | 17623 |
| Absolute Black® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 16,000 pages                                       | 17676 |
| Absolute Cyan® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 12,000 pages  | 17677 |
| Absolute Magenta® toner for use in Kyocera FS C 5400, TK 570, 572, 574   | 17678 |
| Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574  | 17679 |
| Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag   | 18077 |
| Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag    | 18078 |
| Absolute Magenta® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag | 18079 |
| Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574  | 18080 |
| Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg          | 19734 |
| Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg           | 19735 |
| Absolute Magenta® toner for use in Kyocera FS C 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg       | 19736 |
| Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg         | 19737 |

**KYOCERA FS C 1020 MFP, TK 152, 150**

|  |       |
|--|-------|
| Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Black toner | 14751 |
| Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Cyan toner  | 14752 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Magenta toner    | 14753 |
| Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Yellow toner     | 14754 |
| Smartchip® for use in Kyocera FS C 1020 MFP, Black toner TK 150K      | 14755 |
| Smartchip® for use in Kyocera FS C 1020 MFP, Cyan toner TK 150C       | 14756 |
| Smartchip® for use in Kyocera FS C 1020 MFP, Magenta toner TK 150M    | 14757 |
| Smartchip® for use in Kyocera FS C 1020 MFP, Yellow toner TK 150Y     | 14758 |
| Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150   | 14760 |
| Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150    | 14761 |
| Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150 | 14762 |
| Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150  | 14763 |
| Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150   | 15742 |
| Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150    | 15743 |
| Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150 | 15744 |
| Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150  | 15745 |
| Smartchip™ for use in Kyocera FS C 1020, Black TK 154K                | 16021 |
| Smartchip™ for use in Kyocera FS C 1020, Cyan TK154C                  | 16022 |
| Smartchip™ for use in Kyocera FS C 1020, Magenta TK154M               | 16023 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ for use in Kyocera FS C 1020, Yellow TK154Y   | 16024 |
| Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17, (MPT-TK1) | 16494 |
| Absolute Black® toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110, 1112, 1114  | 19076 |
| Smartchip™ toner for use in Kyocera FS-1040, 1120 MFP, 1020 MFP TK 1110  | 19080 |
| Smartchip™ toner for use in Kyocera FS-1040, 1120 MFP, 1020 MFP, TK 1112   | 19081 |
| Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020   | 19428 |

**KYOCERA FS C 5350, 5300, TK 560, 562, 564**

|  |       |
|--|-------|
| Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Black               | 17016 |
| Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Cyan                | 17017 |
| Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Magenta             | 17018 |
| Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Yellow              | 17019 |
| Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Black                | 17212 |
| Smartchip™ for use in Kyocera FS C 5350, 5300, TK 560, Cyan                | 17213 |
| Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Magenta              | 17214 |
| Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Yellow               | 17215 |
| Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564 | 17547 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564   | 17548 |
| Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564  | 17549 |
| Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564   | 17550 |
| Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag   | 18077 |
| Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag    | 18078 |
| Absolute Magenta® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag | 18079 |
| Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag  | 18080 |
| Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564  | 18081 |
| Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564   | 18082 |
| Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564  | 18083 |
| Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564   | 18084 |
| Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg           | 19734 |
| Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg            | 19735 |
| Absolute Magenta® toner for use in Kyocera FS C 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg        | 19736 |
| Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg          | 19737 |

**KYOCERA FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Black                   | 17430 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Cyan                    | 17431 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Magenta                 | 17432 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Yellow                  | 17433 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Black                   | 17434 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Cyan                    | 17435 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Magenta                 | 17436 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Yellow                  | 17437 |
| Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592          | 17465 |
| Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594      | 17466 |
| Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592        | 17467 |
| Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592         | 17468 |
| Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594     | 17766 |
| Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592           | 17767 |
| Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592        | 17768 |
| Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592         | 17769 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Black (7,000 pages)(AU) | 18446 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Cyan (5,000 pages)(AU)                 | 18447 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Magenta (5,000 pages)(AU)              | 18448 |
| Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Yellow (5,000 pages)(AU)               | 18449 |
| Uni Drum™ with gears for use in Kyocera FS C 5020, 5030, 5150, 5250, 5200, 5300 (100,000 pages)                     | 19433 |
| Waste toner bottle for use in Kyocera TK 594, 592, 590, 584, 582, 580, FS C 5250, 5150, 2026, 2126, 2526, 2626 MFP  | 19869 |
| Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 180g (7,000 pages)     | 20059 |
| Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594, 120g (5,000 pages) | 20060 |
| Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)   | 20061 |
| Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)    | 20062 |

**KYOCERA KM 1505, 1510, 1810**

|   |       |
|---|-------|
| Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810 (AMES Certified toner) | 11650 |
| Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810 (AMES Certified toner) | 13519 |

**KYOCERA KM 2530, 3035, 3530, 4030, 4035, 5035**

|   |       |
|---|-------|
| Waste hopper bottle for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035                          | 10422 |
| Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (AMES Certified toner) | 10700 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (AMES Certified toner)

14713

Wiper blade for use in Kyocera KM 5035, 4035, 4030, 3530, 3035, 2530

19220

Lower fuser roller for use in Kyocera Mita KM 5035, 4035, 3035, FS 9520, 9120 (2FG93151)

19627

**KYOCERA KM 3050, 4050, 5050, TK 717, 715**

Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715

11373

Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715

11374

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 717

13690

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 715

17225

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 719

17226

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 718

20464

**KYOCERA KM 4230, 5230, Ai 4040, 5050**

Absolute Black® toner for use in Kyocera KM 4230, 5230, Ai 4040, 5050

11652

**KYOCERA KM Ai 2310, 3010**

Absolute Black® for use in Kyocera KM 1510, 1530, 1810, Ai 2310, 4040

5519

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Kyocera KM Ai 2310, 3010

11653

**KYOCERA KM 1500, 1815, TK 100**

Absolute Black® toner for use in Kyocera KM 1500, 1815, TK 100 (AMES Certified toner)

8075

Wiper blade for use in Kyocera™ KM 1500

13158

Absolute Black® refill toner cartridge for use in Kyocera KM 1500, TK 112, 67, 55, 50, 20, 18, 17, (MPT-TK1)

16494

Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020

19428

**KYOCERA KM 1525, 1530, 1570, 2030, 2070**

Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070 (AMES Certified toner)

10257

Waste hopper bottle for use in Kyocera KM 1525, 1530, 1570, 2030, 2070

10421

Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070 (AMES Certified toner)

11651

Uni Drum™ with gears for use in Kyocera KM 1525, 1530, 1570, 2030, 2070

12358

Wiper blade for use in Kyocera Mita KM 2070, 2030, 1530, 1525

19212

**KYOCERA KM 1620, 1650, 2020, 2035, 2050, TK 410, 411,**

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411 (AMES Certified)

10298

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411 (AMES Certified)

10299

Waste toner bottle for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411

10417

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411(AMES Certified)

11033

Uni Drum™ with gears for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411

13002

Smartchip™ for use in Kyocera KM 1620,1635, 1650, 2020, 2035, 2050, TK 410, (EU)

17177

Smartchip™ for use in Kyocera KM 1620,1635, 1650, 2020, 2035, 2050, TK 412, (US)

17178

Smartchip™ for use in Kyocera KM 1620, 1635, 1650, 2020, 2035, 2050,TK 414, (AU, AP)

17179

Wiper blade for use in Kyocera Mita KM 2050, 2020, 1650, 1635, 1620

19221

**KYOCERA KM 2540, TK 677**

Smartchip™ for use in Kyocera KM 2540, TK 677

17221

Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060, TK 675, 679

18274

Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060 TK 675, 679

18287

**KYOCERA Mita KM 8030, 6030**

Wiper blade for use in Kyocera Mita KM 8030, 6030 (special order)(MOQ. 10)

19222

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA Mita TASKalfa 220, 180, KM 1620,**

Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620 (AMES Certified toner)

16565

Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK435

17180

Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK437

17181

Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK439

17182

Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620 (AMES Certified)

17319

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4105 (EU)

21067

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4107 (US)

21068

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4109 (AP)

21069

Absolute Black® toner for use in Kyocera TaskAlfa 2201, 2200, 1801, 1800 MFP, TK-4109, 4107, 4105

21070

**KYOCERA Mita TaskAlfa 520i, 420i, TK 725,**

Absolute Black® toner for use in Kyocera Mita TaskAlfa 420i, 520i ,TK 725

16612

Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 725

17227

Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 727

17228

Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 729

17229

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA TaskAlfa 300ci, 250ci, TK 865**

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Black 17242

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Cyan 17243

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Magenta 17244

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Yellow 17245

**KYOCERA TaskAlfa 5501, 5500, 4501, 4500, 3501, 3500**

Smartchip® Black for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501 (TK6305)(EU) 20142

Smartchip® Black for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501 (TK6307)(US) 20143

Absolute Black® toner for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501, (TK 6305, 6307) 20475

Absolute Black® developer for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501, (302LH93030, 302LH93034) 21129

**KYOCERA TaskAlfa 2201, 2200, 1801, 1800 MFP, TK-4105**

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4105)(EU) 21067

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4107)(US) 21068

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4109)(AP) 21069

Absolute Black® toner for use in Kyocera TaskAlfa 2201, 2200, 1801, 1800 MFP, (TK-4109, 4107, 4105) 21070



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA TaskAlfa 2551, TK-8327K**

|  |       |
|--|-------|
| Smartchip™ Black for use in Kyocera TASKalfa 2551 (TK-8327K)(US)     | 20717 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 2551ci (TK-8327C)(US)    | 20718 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 2551ci (TK-8327M)(US) | 20719 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 2551ci (TK-8327Y)(US)  | 20720 |
| Smartchip™ Black for use in Kyocera TASKalfa 2551ci (TK-8325K)(EU)   | 20721 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 2551ci (TK-8325C)(EU)    | 20722 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 2551ci (TK-8325M)(EU) | 20723 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 2551ci (TK-8325Y)(EU)  | 20724 |

**KYOCERA TaskAlfa 3011i, 3010i, TK7105**

|   |       |
|---|-------|
| Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7105)(EU)                | 20980 |
| Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7107)(US)                | 20981 |
| Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7109)(AP)                | 20982 |
| Absolute Black® toner for use in Kyocera TaskAlfa 3011i, 3010i, (TK-7105, 7107, 7109) | 21073 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA TaskAlfa 8001, 8000, 6501, 6500, TK-6705**

|   |       |
|---|-------|
| Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6705)(EU) | 20740 |
| Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6707)(US) | 20741 |
| Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6708)(CH) | 20742 |
| Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501,6500 (TK-6709)(AP)  | 20743 |

**KYOCERA TaskAlfa 7551, 7550, 6551, 6550, TK-8705K**

|  |       |
|--|-------|
| Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705K)(EU)   | 20744 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705C)(EU)    | 20745 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705M)(EU) | 20746 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705Y)(EU)  | 20747 |
| Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707K)(US)   | 20748 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707C)(US)    | 20749 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707M)(US) | 20750 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707Y)(US)  | 20751 |
| Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708K)(CH)   | 20752 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708C)(CH)    | 20753 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708M)(CH)

20754

Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708Y)(CH)

20755

Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709K)( AP)

20756

Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709C)(AP)

20757

Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709M)(AP)

20758

Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709Y)(AP)

20759

**KYOCERA TaskAlfa 3511i, 3510i**

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7205)(EU)

20987

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7207)(US)

20988

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7209)(Asia P.)

20989

Absolute Black® toner for use in Kyocera TaskAlfa 3511i, 3510i

21072

**KYOCERA TaskAlfa 820, 620**

Absolute Black® toner for use in Kyocera TaskAlfa 820, 620

21084

**KYOCERA TaskAlfa 406, TK-5215K**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5215K)(EU)   | 20776 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5215C)(EU)    | 20777 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5215M)(EU) | 20778 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5215Y)(EU)  | 20779 |
| Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5217K)(US)   | 20780 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5217C)(US)    | 20781 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5217M)(US) | 20782 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5217Y)(US)  | 20783 |
| Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5218K)(CH)   | 20784 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5218C)(CH)    | 20785 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5218M)(CH) | 20786 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5218Y)(CH)  | 20787 |
| Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5219K)(AP)   | 20788 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5219C)(AP)    | 20789 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5219M)(AP) | 20790 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5219Y)(AP)  | 20791 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA TaskAlfa 356, TK-5205K**

|   |       |
|---|-------|
| Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5205K)(EU)   | 20792 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5205C)(EU)    | 20793 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5205M)(EU) | 20794 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5205Y)(EU)  | 20795 |
| Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5207K)(US)   | 20796 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5207C)(US)    | 20797 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5207M)(US) | 20798 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5207Y)(US)  | 20799 |
| Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5208K)(CH)   | 20800 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5208C)(CH)    | 20801 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5208M)(CH) | 20802 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5208Y)(CH)  | 20803 |
| Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5209K)(AP)   | 20804 |
| Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5209C)(AP)    | 20805 |
| Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5209M)(AP) | 20806 |
| Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5209Y)(AP)  | 20807 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KYOCERA TaskAlfa 306, TK-5195K**

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5195K)(EU) 20760

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5195C)(EU) 20761

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5195M)(EU) 20762

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5195Y)(EU) 20763

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5197K)(US) 20764

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5197C)(US) 20765

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5197M)(US) 20766

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5197Y)(US) 20767

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5198K)(CH) 20768

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5198C)(CH) 20769

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5198M)(CH) 20770

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5198Y)(CH) 20771

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5199K)(AP) 20772

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5199C)(AP) 20773

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5199M)(AP) 20774

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5199Y)(AP)

20775

**KYOCERA TaskAlfa 266, 265, TK-5135K**

Smartchip™ Black for use in Kyocera TaskAlfa 266, 265 (TK-5135K)(EU)

19927

Smartchip™ Cyan for use in Kyocera TaskAlfa 266, 265 (TK-5135C)(EU)

19928

Smartchip™ Magenta for use in Kyocera TaskAlfa 266, 265 (TK-5135M)(EU)

19929

Smartchip™ Yellow for use in Kyocera TaskAlfa 266, 265 (TK-5135Y)(EU)

19930

Smartchip™ Black for use in Kyocera TaskAlfa 266, 265 (TK-5137K)(US)

19931

Smartchip™ Cyan for use in Kyocera TaskAlfa 266, 265 (TK-5137C)(US)

19932

Smartchip™ Magenta for use in Kyocera TaskAlfa 266, 265 (TK-5137M)(US)

19933

Smartchip™ Yellow for use in Kyocera TaskAlfa 266, 265 (TK-5137Y)(US)

19934

Absolute Black® toner for use in Kyocera TaskAlfa 266, 265

19935

Absolute Cyan® toner for use in Kyocera TaskAlfa 266, 265

19936

Absolute Magenta® toner for use in Kyocera TaskAlfa 266, 265

19937

Absolute Yellow® toner for use in Kyocera TaskAlfa 266, 265

19938

**KYOCERA Mita 3060, 3040, 2560, 2540**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Upper fuser roller for use in Kyocera Mita 3060, 3040, 2560, 2540 (2H094160)

19624

**KYOCERA Mita DC 1460**

Absolute Black® toner for use in Kyocera Mita DC 1460

8293

**KYOCERA Mita 3060, 3040, 2560, 2540**

Upper fuser roller for use in Kyocera Mita 3060, 3040, 2560, 2540 (2H094160)

19624

**KONICA MINOLTA®****KONICA MINOLTA BIZHUB 200, 250, 350, 282, 350, 362, DI 3510, 3010, 2510, 2050**

Fuser roller Lower for use in Konica Minolta Bizhub 200, DI 3510, 3010, 2510, 2010 (4030-5702-02, 4030-5702-03)

12147

Absolute Black® toner for use in Minolta Bizhub 200, 250, 350

17976

Uni Drum® with gears for use in Konica Minolta Bizhub C 200, 203, 253, 353

18573

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786

**KONICA MINOLTA BIZHUB 223, 283, 363, 423**



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Minolta Bizhub 223, 283, 363, 423

17977

Uni Drum® with gears for use in Konica Minolta Bizhub 423, 363, 283, 223, Di 3510, 2510, 2010, 1810

19240

**KONICA MINOLTA BIZHUB 501, 421, 420, 361, 360**

Upper Fuser Roller for use in Konica Minolta Bizhub 501, 421, 420, 361, 360 (50GE53030)

19618

Absolute Black® toner for use in Konica Minolta Bizhub 501, 500, 421, 420, 361, 360

20385

**KONICA MINOLTA BIZHUB 4700, 4000, 3300**

Smartchip® for use in Konica Minolta Bizhub 3300 (A63V00W, TNP-39)

19914

Smartchip® for use in Konica Minolta Bizhub 4000 (A63W01W, TNP-38)(US)

19915

Smartchip™ drum for use in Konica Minolta Bizhub 4700, 4000, 3300 (A63X03W, IUP-17)

19917

X-Generation® Black toner for use in Konica Minolta Bizhub 4750, 4700, 4050, 4000

19951

**KONICA MINOLTA BIZHUB 4750, 4050 MFP**

Smartchip® for use in Konica Minolta Bizhub MFP 4750, 4050 (A6VK01W, TNP-46)(US)

19922

Smartchip™ drum for use in Konica Minolta Bizhub MFP 4750, 4050 (A6VM03W, IUP-21)(US)

19924

X-Generation® Black toner for use in Konica Minolta Bizhub 4750, 4700, 4050, 4000

19951

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KONICA MINOLTA BIZHUB 4020, 3320 MFP**

Smartchip® for use in Konica Minolta Bizhub MFP 3320 (A6WT00W, TNP-43)(US)

19920

Smartchip® for use in Konica Minolta Bizhub MFP 4020 (A6WN01W, TNP-42)(US)

19921

Smartchip™ drum for use in Konica Minolta Bizhub MFP 4020, 3320 (A6W903W, IUP-19)(US)

19923

**KONICA MINOLTA BIZHUB 40P**

Smartchip™ toner for use in Konica Minolta Bizhub 40P (A0FP013)

13625

Absolute Black® toner for use in Konica Minolta Bizhub 40P

13775

Absolute Black® toner for use in Konica Minolta Bizhub 40P

13826

Smartchip™ toner for use in Konica Minolta Bizhub 40P (A0FP023)(EU)

18813

**KONICA MINOLTA Pro C 500, CF 5001, 8050**

Uni Drum™ F drum with gears for use in Minolta Pro C 500, CF 5001, 8050

12158

**KONICA MINOLTA BIZHUB Pro 950, 920**

SuMMiT® OPC drum for use in Minolta Bizhub Pro 950, 920

20093

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Konica Minolta Bizhub Pro 920

20384

Absolute Black® toner for use in Konica Minolta Bizhub Pro 920

20393

**KONICA MINOLTA C 252, 250**

Uni Drum™ with gears for use in Minolta Bizhub C 250, 252

11221

Wiper blade for use in Konica Minolta Bizhub C 252, 250, 222, 200 (200-CB)

19219

**KONICA MINOLTA C 450, 362, 351, 350**

Wiper blade for use in Konica Minolta Bizhub C 450, 362, 351, 350 (200-CB)

19894

Absolute Black® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310K, 4053-401)

20002

Absolute Cyan® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310C, 4053-701)

20003

Absolute Magenta® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310M, 4053-601)

20004

Absolute Yellow® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310Y, 4053-501)

20005

**KONICA MINOLTA BIZHUB C 654, 650, 451, 550, 353, 253, 203, 200**

Smartchip™ Black for use in Konica Minolta Bizhub C 253, 353

16304

Smartchip™ Cyan for use in Konica Minolta Bizhub C 253, 353

16305

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Magenta for use in Konica Minolta Bizhub C 253, 353                               | 16306 |
| Smartchip™ Yellow for use in Konica Minolta Bizhub C 253, 353                                | 16307 |
| Smartchip™ Black drum unit for use in Konica Minolta Bizhub C 253, 353                       | 16308 |
| Smartchip™ Cyan drum unit for use in Konica Minolta Bizhub C 253, 353                        | 16309 |
| Smartchip™ Magenta drum unit for use in Konica Minolta Bizhub C 253, 353                     | 16310 |
| Smartchip™ Yellow drum unit for use in Konica Minolta Bizhub C 253, 353                      | 16312 |
| Smartchip® Black for use in Konica Minolta Bizhub C 203,253                                  | 18069 |
| Smartchip® Cyan for use in Konica Minolta Bizhub C 203,253                                   | 18070 |
| Smartchip® Magenta for use in Konica Minolta Bizhub C 203,253                                | 18071 |
| Smartchip® Yellow for use in Konica Minolta Bizhub C 203,253                                 | 18072 |
| Smartchip® Black drum unit for use in Konica Minolta Bizhub C 203,253                        | 18073 |
| Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 203,253                         | 18074 |
| Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 203,253                      | 18075 |
| Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 203,253                       | 18076 |
| Absolute Black toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200   | 18537 |
| Absolute Cyan toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200    | 18538 |
| Absolute Magenta toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200 | 18539 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Yellow toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200     | 18544 |
| Uni Drum® with gears for use in Konica Minolta Bizhub C 200, 203, 253, 353                      | 18573 |
| SuMMiT® drum for CMY with gears for use in Konica Minolta Bizhub C 451, 452, 550, 552, 650, 652 | 18574 |
| Wiper blade for use in Konica Minolta Bizhub C 252, 250, 222, 200 (200-CB)                      | 19219 |
| Wiper blade for use in Konica Minolta Bizhub C 654, 652, 650, 552, 550, 550, 452, 451           | 21256 |

**KONICA MINOLTA BIZHUB C 20**

|  |       |
|--|-------|
| Absolute Black® toner for use in Konica Minolta Bizhub C 20                        | 14942 |
| Absolute Cyan® toner for use in Konica Minolta Bizhub C 20                         | 14943 |
| Absolute Magenta® toner for use in Konica Minolta Bizhub C 20                      | 14944 |
| Absolute Yellow® toner for use in Konica Minolta Bizhub C 20                       | 14945 |
| Smartchip® for use in Konica Minolta Bizhub C 20 Black (A0DK133, TN318K)(USA)      | 14946 |
| Smartchip® for use in Konica Minolta Bizhub C 20 Cyan (A0DK233, TN318C)(USA)       | 14947 |
| Smartchip® for use in Konica Minolta Bizhub C 20 Magenta (A0DK333, TN318M)(USA)    | 14948 |
| Smartchip® Black for use in Konica Minolta Bizhub C 20 (A0DK153, TN318K)(Europe)   | 15065 |
| Smartchip® Cyan for use in Konica Minolta Bizhub C 20 (A0DK453, TN318C)(Europe)    | 15066 |
| Smartchip® Magenta for use in Konica Minolta Bizhub C 20 (A0DK353, TN318M)(Europe) | 15067 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip® Yellow for use in Konica Minolta Bizhub C 20 (A0DK253, TN318Y)(Europe)    | 15068 |
| Smartchip® Black drum unit for use in Konica Minolta Bizhub C 20 (A03100J)           | 15069 |
| Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 20 (A0310GJ)(Europe)    | 15070 |
| Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 20 (A0310AJ)(Europe) | 15071 |
| Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 20 (A03105J)          | 15072 |
| Smartchip® Black drum unit for use in Konica Minolta Bizhub C 20 (A03100G)           | 15073 |
| Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 20 (A0310GG)            | 15074 |
| Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 20 (A0310AG)         | 15075 |
| Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 20 (A03105G)          | 15076 |
| Smartchip® Yellow for use in Konica Minolta Bizhub C 20 (A0DK253, TN318Y)(Europe)    | 15078 |

**KONICA MINOLTA BIZHUB C 35, 25**

|   |       |
|---|-------|
| Smartchip™ Yellow for use in Minolta Bizhub C35 (AOX5252)(EUR)                | 18402 |
| Smartchip™ Yellow drum unit for use in Minolta Bizhub C 25, 35 (AOWG08J)(EUR) | 18410 |
| Smartchip™ Yellow toner for use in Minolta bizhub C 25 (TNP27Y, A0X5233)(USA) | 19707 |
| Smartchip™ Yellow toner for use in Minolta bizhub C 25 (TNP27Y, A0X5253)(EU)  | 19719 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KONICA MINOLTA BIZHUB C 368, 308, 258 MFP**

Waste toner container for use in Konica Minolta Bizhub 554, 454, 364, 284, 224, C 554, 454, 368, 308, 364, 224

20371

Smartchip™ Black for use in Minolta Bizhub C 368, 308, 258 MFP (TN324K, A8DA130)(US)

21145

Smartchip™ Cyan for use in Minolta Bizhub C 368, 308, 258 MFP (TN324C, A8DA430)(US)

21146

Smartchip™ Magenta for use in Minolta Bizhub C 368, 308, 258 MFP (TN324M, A8DA330)(US)

21147

Smartchip™ Yellow for use in Minolta Bizhub C 368, 308, 258 MFP (TN324Y, A8DA330)(US)

21148

**KONICA MINOLTA BIZHUB C 3850, 3350**

Absolute Black® toner for use in Minolta Bizhub C 3850, 3350

19572

Absolute Cyan® toner for use in Minolta Bizhub C 3850, 3350

19573

Absolute Magenta® toner for use in Minolta Bizhub C 3850, 3350

19574

Absolute Yellow® toner for use in Minolta Bizhub C 3850, 3350

19575

Smartchip™ Black for use in Minolta Bizhub C 3850, 3350 (A5X0150)

19576

Smartchip™ Cyan for use in Minolta Bizhub C 3850, 3350 (A5X0430)

19577

Smartchip™ Magenta for use in Minolta Bizhub C 3850, 3350 (A5X0330)

19578

Smartchip™ Yellow for use in Minolta Bizhub C 3850, 3350 (A5X0230)

19579

SuMMiT® OPC drum gearless for use in Minolta Bizhub C 3850, 3350

19580

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Black drum for use in Minolta Bizhub C 3850, 3350 (IUP22K,A3GP01D)

20894

Smartchip™ Cyan drum for use in Minolta Bizhub C 3850, 3350 (IUP22C,A3GP0HD)

20895

Smartchip™ Magenta drum for use in Minolta Bizhub C 3850, 3350 (IUP22M,A3GP0CD)

20896

Smartchip™ Yellow drum for use in Minolta Bizhub C 3850, 3350 (IUP22M,A3GP0CD)

20897

**KONICA MINOLTA Di 181, 350**

Absolute Black® toner for use in Minolta Di 181, 350

5200

Uni Drum® with gears for use in Konica Minolta Bizhub 423, 363, 283, 223, Di 3510, 2510, 2010, 1810

19240

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786

**KONICA MINOLTA Di 200, 250, 350**

Absolute Black® toner for use in Minolta Di 200, 250, 350

8968

Fuser roller Lower for use in Konica Minolta Bizhub 200, DI 3510, 3010, 2510, 2010 (4030-5702-02, 4030-5702-03)

12147

Wiper blade for use in Minolta Di 200, 250

12670

Uni Drum™ with gears for use in Minolta Di 200, 250, 251, 350, 351

12671

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KONICA MINOLTA Di 550, 470, 450, EP 3050, 4050, 4000, 6001, 8010, 8015**

|   |       |
|---|-------|
| Feed tire assembly kit for use in Konica Minolta DI 550, 470, 450, PF 208, 115 (4002-3201-01)                                       | 12127 |
| Uni Drum™ F with gears for use in Minolta Di 450, 470, 550  | 12541 |
| Wiper blade for use in Minolta Di 450, 470, 550   | 12572 |
| Wiper blade for use in Minolta EP 4050, 4000, 3050, 2050, DI 550, 470, 450  | 12666 |
| Absolute Black™ toner for use in Minolta Di 550, 470, 450, (10kg) bag   | 15102 |
| Absolute Black™ toner for use in Minolta Di 550, 470, 450,  | 17814 |
| Cleaning web supply roller for for use in Konica Minolta DI 450, 470, 520, 550, 620, EP 6001, 8010, 8015 (4002-5732-01)             | 19620 |
| Upper Fuser Roller for use in Konica Minolta DI 450, 550 (4002-5701-01)   | 19621 |
| Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052) | 19857 |

**KONICA MINOLTA Di 551, 650, 5510, 7210**

|   |       |
|---|-------|
| Wiper blade for use in Minolta Di 551, 650, 5510, 7210  | 12543 |
| Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052) | 19857 |
| Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052) | 19857 |

**KONICA MINOLTA Di 750, 850**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Minolta Di 750

10225

Wiper blade for use in Konica Minolta 7085, 7075, Di 850, 750

19218

**KONICA MINOLTA EP 1030, 1031, 1050**

Uni Drum™ F with gears for use in Minolta EP 1030, 1031, 1053

9002

Wiper blade for use in Minolta EP 1030, 1031, 1053

12545

**KONICA MINOLTA EP 1050, 1052, 1054, 1080, 1082, 1083, 2010**

Uni Drum™ F with gears for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010

12546

Wiper blade for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010

12547

**KONICA MINOLTA EP 2120**

Uni Drum™ S with gears for use in Minolta EP 2120

5689

**KONICA MINOLTA EP 8015, 6001, 6000, 5050**

Absolute Black® toner for use in Minolta EP 8015, 6001, 6000, 5050

12302

Cleaning web supply roller for for use in Konica Minolta DI 450, 470, 520, 550, 620, EP 6001, 8010, 8015 (4002-5732-01)

19620

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****KONICA MINOLTA CF 2002, 3102**

Uni Drum™ gearless for use in Minolta CF 2002, 3102,

11963

**LEXMARK®****LEXMARK X 954, 952, 950 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip® Black toner for use in Lexmark C/X 950, 952, 954 (C/X950X2KG)

17513

Smartchip® Black toner for use in Lexmark X 950, 952, 954

17517

Smartchip® Cyan toner for use in Lexmark X 950, 952, 954

17518

Smartchip® Magenta toner for use in Lexmark X 950, 952, 954

17519

Smartchip® Yellow toner for use in Lexmark X 950, 952, 954

17520

X-Generation® Black toner for use in Lexmark C 950, 952, X 950, 952, 954

17634

X-Generation® Cyan toner for use in Lexmark C 950, 952, X 950, 952, 954

17635

X-Generation® Magenta toner for use in Lexmark C 950, 952, X 950, 952, 954

17636

X-Generation® Yellow toner for use in Lexmark C 950, 952, X 950, 952, 954

17637

X-Generation® drum with gears and insert for use in Lexmark C 950, 952, X 954, 952, 950

18298

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip® CMYK drum unit for use in Lexmark C 950, 952, X 954, 952, 950

18304

Wiper blade for use in Lexmark C 952, 950, X 954, 952, 950

18557

**LEXMARK X 792, 748, 746, 738, 736, 734, 730**

X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15792

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15793

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15794

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15795

Smartchip™ Black for use in Lexmark C 730, 734, 736, X 734, 736, 738

15800

Smartchip™ Cyan for use in Lexmark C 730, 734, 736, X 734, 736, 738

15801

Smartchip™ Magenta for use in Lexmark C 730, 734, 736, X 734, 736, 738

15802

Smartchip™ Yellow for use in Lexmark C 730, 734, 736, X 734, 736, 738,

15803

X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16739

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16740

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16741

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16742

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, X 734, 736, 738, 746, 748

19730

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19731

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19732

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19733

X-Generation® Black toner for use in Lexmark C 792, X 792 (MPT LXC792)

19943

X-Generation® Cyan toner for use in Lexmark C 792, X 792 (MPT LXC792)

19944

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

20101

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

20112

**LEXMARK X 658, 656, 654, 652, 651**

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (25,000 pages)(USA & WW)(MPS Jumbo yield)

18639

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (USA & WW)(MPS Jumbo yield)

18640

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (Asia Pacific)(MPS Jumbo yield)

18928

Fuser maintenance kit for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X4724)

19843

Fuser assembly type 1 for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X4418)

19844

Transfer roller for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X1886)

19845

PCR roller for use in Lexmark X 658, 656, 654, 652, 651, 646, 644, 642, T 654, 652, 650, 644, 642, 640 (40X5852)

19846

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****LEXMARK X 864, 862, 860, 854, 852, 850**

Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

16787

Smartchip® toner for use in Lexmark X 860, 862, 864 (X860H21G)

17884

Smartchip® drum unit for use in Lexmark X 860, 862, 864 (W860H22G)

17885

Developer for drum unit for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

18990

SuMMiT® OPC drum with gears for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

18991

Wiper blade for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

19150

Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

20860

**LEXMARK M/XM 3150, 1145**

Smartchip® for use in Lexmark M/XM 3150 (24B6186)

20052

X-Generation® Black toner for use in Lexmark M 3150, 1145, XM 3150, 1145

20058

**LEXMARK MX 812, 811, 810, 710, 611, 610, 510, 410, 310, 310**

Smartchip™ for use in Lexmark MX 310, 410, 511, 611 (US)

18653

Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611(US)

18654

Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (US)

18655

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (EUR)   | 18660 |
| Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (EUR)   | 18661 |
| Absolute Black® toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611(AB MPT-MS810)                                  | 18679 |
| Absolute Black® toner for use in Lexmark MS 510, 610, MX 510, 511, 610, 611   | 18680 |
| X-Generation® Black toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611(XG MPT-MS810)                              | 18688 |
| X-Generation® Black toner for use in Lexmark MS 510, 610, MX 510, 511, 610, 611   | 18690 |
| X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812 (MPT-MS810-XGEN)                 | 18693 |
| Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (Asia Pacific)  | 18698 |
| Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (SE Asia)   | 18699 |
| Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (Latin America)   | 18713 |
| Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (Latin America)   | 18714 |
| X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812 (MPT-MS810-XGEN)                 | 18715 |
| Absolute Black® toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812,(MPT-MS810-LGA)(EU LGA Prequalified) | 18883 |
| Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 611 (MEA)  | 19609 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****OKIDATA CX 2033 MFP**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP                            | 14220 |
| Absolute Cyan™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP                             | 14221 |
| Absolute Magenta™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP                          | 14222 |
| Absolute Yellow™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP                           | 14223 |
| Smartchip™ Black toner for use in Okidata CX 2033 MFP   | 14224 |
| Smartchip™ Cyan toner for use in Okidata CX 2033 MFP  | 14225 |
| Smartchip™ Magenta toner for use in Okidata CX 2033 MFP   | 14226 |
| Smartchip™ Yellow toner for use in Okidata CX 2033 MFP  | 14227 |
| Smartchip™ drum fuse for use in Okidata CX 2033, MC 560 MFP   | 14228 |
| Uni Drum™ with gears for use in Okidata CX 2033 MFP   | 14232 |
| Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033 | 14301 |
| X-Generation® Black toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP                       | 17266 |
| X-Generation® Cyan toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP                        | 17267 |
| X-Generation® Magenta toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP                     | 17268 |
| X-Generation® Yellow toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP                      | 17269 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****OKIDATA MC 160 MFP, C 130, 110**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110   | 14568 |
| Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110    | 14569 |
| Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110 | 14570 |
| Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110  | 14571 |
| Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110        | 14572 |
| Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110         | 14573 |
| Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110      | 14574 |
| Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110       | 14575 |
| Developer roller cover for use in Okidata MC 160 MFP              | 14581 |
| Developer roller cover for use in Okidata C 130, 110, MC 160 MFP  | 18288 |

**OKIDATA C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562   | 17719 |
| Absolute Cyan® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562,   | 17720 |
| Absolute Magenta® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 | 17721 |
| Absolute Yellow® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562  | 17722 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Black for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562                                   | 17727 |
| Smartchip™ Cyan for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562                                    | 17728 |
| Smartchip™ Magenta for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562                                 | 17729 |
| Smartchip™ Yellow for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562                                  | 17730 |
| Uni Drum ® drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP  | 17793 |
| Uni Drum ® drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP  | 17793 |
| Smartchip™ drum fuse for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP                                     | 18307 |
| Color cartridges chip holder and retainer for use in Okidata C 310, 330, 510, 511, 530, 531, MC 562, 561, 361 MFP                | 18566 |
| SuMMiT® Drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP   | 18733 |
| Absolute Black® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag   | 20627 |
| Absolute Cyan® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag    | 20628 |
| Absolute Magenta® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag | 20629 |
| Absolute Yellow® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag  | 20630 |

**OKIDATA B 8300**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata B 8300             | 9092  |
| Absolute Black® developer carrier for use in Okidata B 8300 | 11937 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Uni Drum™ gearless for use in Okidata B 8300

11938

**OKIDATA B 930**

Absolute Black® toner for use in Okidata B 930

13036

Developer carrier for drum unit for use in Okidata B 930,

13037

Smartchip™ Drum for use in Okidata B 930

13038

Uni Drum™ with gears for use in Okidata B 930

13040

Smartchip™ Black for use in Okidata C 930, 910

18283

Smartchip™ Cyan for use in Okidata C 930, 910

18284

Smartchip™ Magenta for use in Okidata C 930, 910

18285

Smartchip™ Yellow for use in Okidata C 930, 910

18286

Smartchip™ Black for use in Okidata B 930 (52117101)(US)

19979

**OKIDATA B 6500**

Cartridge pin for use in Okidata B 6200, 6300, 6500

6792

Clear Seal™ adhesive for use in Okidata B 6200, 6300, 6500, 710, 720, 730

7208

Absolute Black® toner for use in Okidata B 6500

11231

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ for use in Okidata B 6500                      | 11234 |
| Doctor blade for use in Okidata B 6500                    | 11710 |
| Drum shutter spring for use in Okidata B 6500, 6300, 6200 | 11989 |
| Absolute Black® toner for use in Okidata B 6500           | 13308 |
| Absolute Black® toner for use in Okidata B 6500           | 13309 |
| Smartchip™ for use in Okidata B 6500                      | 13310 |
| Smartchip™ for use in Okidata B 6500                      | 13311 |
| SuMMiT™ drum with gears for use in Okidata B 6500         | 15230 |
| X-Generation® Doctor blade for use in Okidata B 6500      | 17923 |
| X-Generation® Wiper blade for use in Okidata B 6500       | 17924 |

**OKIDATA C 5100**

|  |      |
|--|------|
| Absolute Black® toner for use in Okidata C 5100                                      | 8555 |
| Absolute Yellow™ toner for use in Okidata C 5100,                                    | 8558 |
| Absolute Yellow™ toner for use in Okidata C 5100                                     | 8804 |
| Smartchip™ fuse for drum unit for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450 | 9362 |
| Drum unit wiper blade for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450         | 9884 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata C 5100                             | 9934  |
| Absolute Yellow™ toner for use in Okidata C 5100                            | 9937  |
| Absolute Black® Glossy toner for use in Okidata C 5100                      | 10190 |
| Absolute Cyan™ Glossy toner for use in Okidata C 5100                       | 10191 |
| Absolute Magenta™ Glossy toner for use in Okidata C 5100                    | 10192 |
| Absolute Yellow™ Glossy toner for use in Okidata C 5100                     | 10193 |
| Absolute Black™ Glossy toner for use in Okidata C 5100                      | 10349 |
| Absolute Cyan™ Glossy toner for use in Okidata C 5100                       | 10350 |
| Absolute Magenta™ Glossy toner for use in Okidata C 5100                    | 10351 |
| Absolute Yellow™ Glossy toner for use in Okidata C 5100                     | 10352 |
| Uni Drum™ with gears for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450 | 16543 |

**OKIDATA C 511, 531, 330, 310, 321, 301, MC 332, 342, 351, 352, 361, 362, 561, 562 MFP**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562   | 17719 |
| Absolute Cyan® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562    | 17720 |
| Absolute Magenta® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562 | 17721 |
| Absolute Yellow® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562  | 17722 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Cyan® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP   | 17724 |
| Absolute Magenta® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP  | 17725 |
| Absolute Yellow® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP   | 17726 |
| Smartchip® Black for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469803)(3,500 pages)   | 17727 |
| Smartchip® Cyan for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469706)(2,000 pages)    | 17728 |
| Smartchip® Magenta for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469705)(2,000 pages) | 17729 |
| Smartchip® Yellow for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469704)(2,000 pages)  | 17730 |
| Smartchip® Cyan toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP  | 17732 |
| Smartchip® Magenta toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP   | 17733 |
| Smartchip® Yellow toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP  | 17734 |
| Smartchip® Black toner for use in Okidata C 511, 531, MC 562 MFP   | 17736 |
| Absolute Black® toner for use in Okidata C 511, 531, MC 562 MFP  | 17741 |
| Uni Drum® for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP  | 17793 |
| Smartchip™ drum fuse for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP                                 | 18307 |
| Color cartridges chip holder and retainer for use in Okidata C 310, 330, 510, 511, 530, 531, MC 562, 561, 361 MFP            | 18566 |
| SuMMiT® Drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP   | 18733 |
| Smartchip® Cyan for use in Okidata C 841, 831, MC 873 (44844511)(US)   | 19988 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Black® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562   | 20627 |
| Absolute Cyan® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562    | 20628 |
| Absolute Magenta® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562 | 20629 |
| Absolute Yellow® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562  | 20630 |

**OKIDATA C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860**

|  |       |
|--|-------|
| X-Generation® Black glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860   | 12721 |
| X-Generation® Cyan glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860    | 12722 |
| X-Generation® Magenta glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860 | 12723 |
| X-Generation® Yellow glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860  | 12724 |
| Absolute Cyan® toner for use in Okidata C 810, 830   | 14229 |
| Absolute Magenta® toner for use in Okidata C 810, 830  | 14230 |
| Absolute Yellow® toner for use in Okidata C 810, 830   | 14231 |
| Smartchip™ Black toner for use in Okidata C 810, 830   | 15422 |
| Smartchip™ Cyan toner for use in Okidata C 810, 830  | 15423 |
| Smartchip™ Magenta toner for use in Okidata C 810, 830   | 15424 |
| Smartchip™ Yellow toner for use in Okidata C 810, 830  | 15425 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

SuMMiT® drum with gears for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

16264

Absolute Black® toner for use in Okidata C 810, 830

17378

**OKIDATA C 9000, 9100, 9200, 9300, 9400, 9500**

Uni Drum™ with gears for use in Okidata C 9000

7522

Absolute Black® toner for use in Okidata C 9000

8389

Smartchip™ fuse for OPC drum unit for use in Okidata C 9000

9648

Drum unit wiper blade for use in Okidata C 9000

9885

Absolute Black® Glossy toner for use in Okidata C 9000

10195

Absolute Cyan™ Glossy toner for use in Okidata C 9000

10196

Absolute Magenta™ Glossy toner for use in Okidata C 9000

10197

Absolute Yellow™ Glossy toner for use in Okidata C 9000

10198

Absolute Black® Glossy toner for use in Okidata C 9000

11900

Absolute Cyan™ Glossy toner for use in Okidata C 9000

11901

Absolute Magenta™ Glossy toner for use in Okidata C 9000

11902

Absolute Yellow™ Glossy toner for use in Okidata C 9000

11903

Drum unit cover for use in Okidata C9000, 9100, 9200, 9300, 9400, 9500

14564



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****OKIDATA C 3000, 3100, 3200, 5100, 5200, 5250, 5300, 5400, 5450, 710, 711**

Absolute Cyan® toner for use in Okidata C 3000, 3100, 3200 9322

Absolute Magenta® toner for use in Okidata C 3000, 3100, 3200 9323

Absolute Yellow® toner for use in Okidata C 3000, 3100, 3200 9324

Smartchip™ fuse for drum unit for use in Okidata C 3000, 3100, 3200, 5100, 5200, 5250 5300, 5400, 5450 9362

Absolute Black® Glossy toner for use in Okidata C 3000, 3100, 3200 10208

Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200 10209

Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200 10210

Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200 10211

Smartchip™ drum unit fuse for use in Okidata C 3000, 3100, 3200 11313

Drum unit wiper blade for use in Okidata C 3000, 3100, 3200 11314

Uni Drum™ with gears for use in Okidata C 3000, 3100, 3200, 5100, 5200, 5250, 5300, 5400, 5450, 710, 711 16543

Uni Drum™ with gears for use in Okidata C 3000, 3100, 3200 16545

Absolute Black® Glossy toner for use in Okidata C 3000, 3100, 3200 16994

Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200 16995

Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200 16996

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200

16997

**OKIDATA C 3600, 3530, 3400, 3450, 3300, MC 360**

Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10829

Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10830

Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10831

Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10832

Smartchip™ fuse drum unit for use in Okidata C 3600, 3400, 3300, MC 360

10838

Smartchip™ Black toner for use in Okidata C 3450, 3600

13608

Smartchip™ Magenta toner for use in Okidata C 3450, 3600

13610

Smartchip™ Yellow toner for use in Okidata C 3450, 3600

13611

Smartchip™ Black toner for use in Okidata C 3450, 3600

13612

Smartchip™ Cyan toner for use in Okidata C 3450, 3600

13613

Smartchip™ Magenta toner for use in Okidata C 3450, 3600

13614

Smartchip™ Yellow toner for use in Okidata C 3450, 3600

13615

Drum unit toner sealing cover for use in Okidata C 3600, 3400, 3300, MC 360

14306

Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

14496

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360           | 14497 |
| Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360        | 14498 |
| Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360         | 14499 |
| Smartchip™ Black for use in Okidata C 3300, 3600, 3400, 3450, 3530                              | 16267 |
| Smartchip™ Cyan for use in Okidata C 3300, 3600, 3400, 3450, 3530                               | 16268 |
| Smartchip™ Magenta for use in Okidata C 3300, 3600, 3400, 3450, 3530                            | 16269 |
| Smartchip™ Yellow for use in Okidata C 3300, 3600, 3400, 3450, 3530                             | 16270 |
| X-Generation® Black toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360   | 17715 |
| X-Generation® Cyan toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360    | 17716 |
| X-Generation® Magenta toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360 | 17717 |
| X-Generation® Yellow toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360  | 17718 |
| X-Generation® Black toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360             | 18868 |
| X-Generation® Cyan toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360              | 18869 |
| X-Generation® Magenta toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360           | 18870 |
| X-Generation® Yellow toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360            | 18874 |

**OKIDATA C 5700, 5750, 5600, 5650, 5550, 5700, 5800, 5900, 6000, 6050, 6100**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5700, 5650, 5600, 5550, 5500

10695

Absolute Black® Glossy toner for use in Okidata C 5700, 5600

11161

Absolute Cyan™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11162

Absolute Magenta™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11163

Absolute Yellow™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11164

Smartchip™ Black for use in Okidata C 5700, 5600

11165

Smartchip cover for use in Okidata C 6000, 5900, 5500, 711, 710, 610

19889

**OKIDATA C 5900, 5800, 5500, CX 2032 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10612

Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10613

Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10614

Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10615

Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10616

Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10617

Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10618

Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10619

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Uni Drum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500

10620

Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610

10695

Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500,

11747

Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500

11748

Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500

11749

Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500

11750

Smartchip™ Black Toner for use in Okidata C 5900, 5800, 5550

11957

Smartchip™ Cyan Toner for use in Okidata C 5900, 5800, 5550

11958

Smartchip™ Magenta Toner for use in Okidata C 5900, 5800, 5550

11959

Smartchip™ Yellow Toner for use in Okidata C 5900, 5800, 5550

11960

Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033

14301

**OKIDATA C 6100, 5550 MFP, B 6100**

Absolute Black® toner for use in Okidata B 6100

8364

Absolute MICR™ toner for use in Okidata B 6100

8365

Doctor blade for use in Okidata B 6100

8367

Wiper blade for use in Okidata B 6100

8862

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| PCR roller for use in Okidata B 6100  | 8890  |
| Seal adhesive for use in Okidata B 6100   | 8891  |
| Uni Drum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500                         | 10620 |
| Absolute Black® Glossy toner for use in Okidata C 6100, 5550 MFP                                    | 10629 |
| Absolute Cyan™ glossy toner for use in Okidata C 6100, 5550 MFP                                     | 10630 |
| Absolute Magenta™ glossy toner for use in Okidata C 6100, 5550 MFP                                  | 10631 |
| Absolute Yellow™ glossy toner for use in Okidata C 6100, 5550 MFP                                   | 10632 |
| Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610          | 10695 |
| Smartchip™ Black for use in Okidata C 6100, 5550 MFP  | 11402 |
| Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP   | 11405 |
| Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033 | 14301 |
| Smartchip™ Black for use in Okidata C 6100, 5550 MFP  | 18251 |
| Smartchip™ Cyan for use in Okidata C 6100, 5550 MFP   | 18252 |
| Smartchip™ Magenta for use in Okidata C 6100, 5550 MFP  | 18253 |
| Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP   | 18254 |

**OKIDATA C 7000, 7300, 7400, 7500**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500           | 8386  |
| Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500        | 8387  |
| Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500         | 8388  |
| Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500           | 8597  |
| Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500        | 8598  |
| Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500         | 8599  |
| Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500           | 8771  |
| Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500        | 8772  |
| Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500         | 8773  |
| Uni Drum™ with gear for use in Okidata C 7000, 7300, 7500                  | 8913  |
| Smartchip™ fuse for OPC drum unit for use in Okidata C 7000, 7300, 7500    | 9992  |
| Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500   | 11039 |
| Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500    | 11040 |
| Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500 | 11041 |
| Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500  | 11042 |
| Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500   | 11043 |
| Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500    | 11044 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500

11045

Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500

11046

Drum unit toner sealing cover for use in Okidata C 7000, 7300, 7500

14296

**OKIDATA C 710, B 710, 720, 730, 6200, 6300, 6500, MC 560 MFP**

Clear Seal™ adhesive for use in Okidata B 6200, 6300, 6500, 710, 720, 730

7208

Absolute Black® Glossy toner for use in Okidata C 710, 711

13042

Absolute Cyan™ Glossy toner for use in Okidata C 710

13043

Absolute Magenta™ Glossy toner for use in Okidata C 710

13044

Absolute Yellow™ Glossy toner for use in Okidata C 710

13045

Smartchip™ drum fuse for use in Okidata C 711, 710, 610, CX 2033, MC 560 MFP

14228

Smartchip™ Black for use in Okidata C 710, 711

15092

Smartchip™ Cyan for use in Okidata C 710, 711

15093

Smartchip™ Magenta for use in Okidata C 710, 711

15094

Smartchip™ Yellow for use in Okidata C 710, 711

15095

Smartchip™ Black for use in Okidata C 710, 711 (44318604)(43866104)(USA)

15096

Smartchip™ Cyan for use in Okidata C 710, 711 (44318603)(43866103)(USA)

15097



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta for use in Okidata C 710, 711 (44318602)(43866102)(USA)

15098

Smartchip™ Yellow for use in Okidata C 710, 711 (44318601)(43866101)(USA)

15099

Absolute Black® toner for use in Okidata B 710, 720, 730

18439

Smartchip cover for use in Okidata C 6000, 5900, 5500, 711, 710, 610

19889

**OKIDATA C 8600, 8800**

Absolute Black® Glossy toner for use in Okidata C 8600, 8800

11928

Absolute Cyan™ glossy toner for use in Okidata C 8600, 8800

11929

Absolute Magenta™ glossy toner for use in Okidata C 8600, 8800

11930

Absolute Yellow™ glossy toner for use in Okidata C 8600, 8800

11931

Smartchip™ Black toner for use in Okidata C 8600, 8800

11932

Smartchip™ Cyan toner for use in Okidata C 8600, 8800

11933

Smartchip™ Magenta toner for use in Okidata C 8600, 8800

11934

Smartchip™ Yellow toner for use in Okidata C 8600, 8800

11935

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12721

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12722

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12723

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12724

Smartchip™ OPC drum unit fuse for use in Okidata C 8600, 8800

13028

X-Generation® Black glossy toner for use in Okidata C 8600, 8800

13105

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800

13106

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800

13107

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800

13108

Uni Drum™ with gears for use in Okidata C 8600, 8800

13329

Drum unit sealing cover for use in Okidata C 8600, 8800

15241

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16099

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16100

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16101

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16102

SuMMiT™ drum with gears for use in Okidata C 8600, 8800

16264

**OKIDATA C 9600, 9800, 9850, 9600, 8800, 8600**

Absolute Black® Glossy toner for use in Okidata C 9600, 9800

10621

Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800

10622

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800

10623

Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800

10624

Smartchip™ Black for use in Okidata C 9600, 9800

10625

Smartchip™ Cyan for use in Okidata C 9600, 9800

10626

Smartchip™ Magenta for use in Okidata C 9600, 9800

10627

Smartchip™ Yellow for use in Okidata C 9600, 9800

10628

Smartchip™ OPC drum unit fuse for use in Okidata C 9600, 9800

10849

Uni Drum™ drum with gears for use in Okidata C 9600, 9800

10850

Absolute Black® Glossy toner for use in Okidata C 9600, 9800

11315

Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800

11316

Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800

11317

Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800

11318

X-Generation® Black glossy toner for use in Okidata C 9600, 9650, 9800, 9850

12290

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12721

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12722

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12723

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12724

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| X-Generation® Cyan glossy toner for use in Okidata C 9600, 9650, 9800, 9850                | 13617 |
| X-Generation® Magenta glossy toner for use in Okidata C 9600, 9650, 9800, 9850             | 13618 |
| X-Generation® Yellow glossy toner for use in Okidata C 9600, 9650, 9800, 9850              | 13619 |
| Drum unit toner sealing cover for use in Okidata C 9600, 9800                              | 14307 |
| Absolute Black™ glossy toner for use in Okidata C 9600, 9800                               | 14576 |
| Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800                             | 14578 |
| Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800                              | 14579 |
| Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800                                | 14582 |
| X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850   | 16099 |
| X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850    | 16100 |
| X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850 | 16101 |
| X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850  | 16102 |
| SuMMiT® drum with gears for use in Okidata C 9600, 9800                                    | 19559 |

**OKIDATA CX 2366 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Okidata CX 2366 | 14336 |
| Absolute Cyan™ toner for use in Okidata CX 2366  | 14337 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ toner for use in Okidata CX 2366

14338

Absolute Yellow™ toner for use in Okidata CX 2366

14339

Smartchip™ Black toner for use in Okidata CX 2366

14340

Smartchip™ Cyan toner for use in Okidata CX 2366

14341

Smartchip™ Magenta toner for use in Okidata CX 2366

14342

Smartchip™ Yellow toner for use in Okidata CX 2366

14343

**OKIDATA ES 3640 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ Magenta for use in Okidata ES 3640 Pro

15094

Smartchip™ Black for use in Okidata ES 3640

16177

Smartchip™ Cyan for use in Okidata ES 3640

16178

Smartchip™ Magenta for use in Okidata ES 3640

16179

Smartchip™ Yellow for use in Okidata ES 3640

16180

Smartchip™ Black for use in Okidata ES 3640 Pro

17482

Smartchip™ Cyan for use in Okidata ES 3640 Pro

17483

Smartchip™ Magenta for use in Okidata ES 3640 Pro

17484

Smartchip™ Yellow for use in Okidata ES 3640 Pro

17485

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****OKIDATA B 431, 411, MB 491, 471, 461 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Drum unit cover for use in Okidata B 431, 411, MB 491, 471, 461  | 11936 |
| Smartchip™ for use in Okidata B 431, 411, MB 491, 471, 461   | 15100 |
| Smartchip™ for use in Okidata B 431, MB 461, 471, 491  | 17297 |
| Absolute Black® toner for use in Okidata B 431, 411, MB 491, 471, 461  | 17573 |
| Absolute Black® toner for use in Okidata B 431, MB 491   | 17574 |
| Smartchip® toner for use in Okidata B 431, MB 491 (44917601)(US, Latin America)                                  | 17608 |
| Smartchip® toner for use in Okidata B 431, MB 491 (44917602)(EU)   | 17609 |
| Smartchip™ drum fuse for use in Okidata B 431, 430, 420, 411, 410, 401, MB 491, 471, 470, 461, 460, 451, 441 MFP | 18385 |
| Uni Drum® with gears for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441 MFP                          | 18508 |
| Smartchip™ for use in Okidata B 431, 411, MB 491, 471, 461 (44574701)(US)  | 18515 |
| Absolute Black® toner for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441                             | 18516 |
| Wiper blade for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441 MFP                                   | 18565 |
| Absolute Black® toner for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441                             | 18608 |
| Absolute Black® toner for use in Okidata B 431, 411, MB 491, 471, 461  | 18609 |
| Smartchip™ drum fuse with contacts for use in Okidata B 431, 430, 411, 401, MB 491, 471, 461, 451, 441 MFP       | 20643 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****OKIDATA MB 260, 280, 290 MFP**

|  |       |
|--|-------|
| Smartcard™ reset smartchip for use in Okidata MB 260, 280, 290 MFP       | 14288 |
| Smartcard™ toner reset smartchip for use in Okidata MB 260, 280, 290 MFP | 14600 |
| Absolute black® toner for use in Okidata MB 260, 280, 290 MFP            | 14601 |
| Uni Drum™ with gears for use in Okidata MB 290, 280, 260                 | 14930 |

**OKIDATA MC 160 MFP, C 130, 110**

|   |       |
|---|-------|
| Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110   | 14568 |
| Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110    | 14569 |
| Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110 | 14570 |
| Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110  | 14571 |
| Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110        | 14572 |
| Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110         | 14573 |
| Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110      | 14574 |
| Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110       | 14575 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Developer roller cover for use in Okidata MC 160 MFP

14581

Developer roller cover for use in Okidata C 130, 110, MC 160 MFP

18288

**OKIDATA MC 860, 830, 810, 9800, 9850, 9600, 9650, 8800, 8600,**

X-Generation® Black glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12721

X-Generation® Cyan glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12722

X-Generation® Magenta glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12723

X-Generation® Yellow glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12724

Smartchip™ OPC drum unit fuse for use in Okidata C 8800, 8600, 830, 821, 810, 801, MC 861, 860, 851

13028

Absolute Black® toner for use in Okidata MC 860

14310

Absolute Cyan™ toner TBAg for use in Okidata MC 860

14311

Absolute Magenta™ toner TBAg for use in Okidata MC 860

14312

Absolute Yellow™ toner TBAg for use in Okidata MC 860

14313

Smartchip™ Black toner for use in Okidata MC 860

14314

Smartchip™ Cyan toner for use in Okidata MC 860

14315

Smartchip™ Magenta toner for use in Okidata MC 860

14316

Smartchip™ Yellow toner for use in Okidata MC 860

14317



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Drum unit sealing cover for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

15241

Smartchip™ Black toner for use in Okidata MC 860

15550

Smartchip™ Cyan toner for use in Okidata MC 860

15551

Smartchip™ Magenta toner for use in Okidata MC 860

15552

Smartchip™ Yellow toner for use in Okidata MC 860

15553

Smartchip™ Black drum unit toner for use Okidata MC 860

15554

Smartchip™ Cyan drum unit toner for use Okidata MC 860

15555

Smartchip™ Magenta drum unit toner for use Okidata MC 860

15556

Smartchip™ Magenta drum unit toner for use Okidata MC 860

15557

X-Generation® Black glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16099

X-Generation® Cyan glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16100

X-Generation® Magenta glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16101

X-Generation® Yellow glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16102

SuMMiT® drum with gears for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

16264

**OKIDATA 5900, 5780, 5750, 5700, 5680, 4515**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Okidata 5900, 5780, 5750, 5700, 5680, 4515

5636

**PANASONIC®****PANASONIC DP 2000, 2500, 3000**

Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000

13912

Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000

16715

**PANASONIC WORKIO DP 310, 2330, 3010, 3030**

Uni Drum™ drum with gears for use in Panasonic Workio DP 2310, 2330, 3010, 3030

10297

**RICOH®****RICOH AFICIO 200, 250, FX 200**

Wiper blade for use in Ricoh Aficio 200, 250

5148

Drum with gears for use in Ricoh Aficio 200, 250 F

7272

Drum with gears for use in Ricoh Aficio 200, 250 S,

8548

Absolute Black® toner for use in Ricoh Aficio 200, 250

8735

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Developer for use in Ricoh Aficio 200, 250                      | 8793  |
| Developer for use in Ricoh Aficio 200, 250                      | 8794  |
| Absolute Black® toner for use in Ricoh Aficio 200, 250          | 9470  |
| Absolute Black® toner for use in Ricoh Aficio FX 200, Type 2285 | 11321 |
| Smartchip™ for use in Ricoh Aficio FX 200, Type 2285            | 11322 |
| Ricoh Aficio FX 200, Type 2285 Uni Drum™ OEM style with gears   | 11323 |
| PCR roller for use in Ricoh Aficio FX 200, Type 2285            | 11328 |
| Supply roller for use in Ricoh Aficio FX 200, Type 2285         | 11329 |

**RICOH AFICIO 350, 450**

|   |       |
|---|-------|
| Uni Drum™ S with gears for use in Ricoh Aficio 340, 350, 450  | 7271  |
| Uni Drum™ F with gears for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045  | 7412  |
| Absolute Black® toner for use in Ricoh Aficio 350, 450  | 8734  |
| Absolute Black® toner for use in Ricoh Aficio 350, 450  | 9469  |
| Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035) | 12123 |
| Wiper blade for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045   | 12575 |
| X-Generation® Wiper blade for Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045  | 16522 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Transfer belt cleaning blade for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 2035, 2045, 3035, 3045, MP 3500, SP 8100 (A232-3930)              | 19245 |
| Paper feed roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1045 P, 1045, 1035, 350, 355, 450, SP 500, 480, 360, COLOR 3506, 3006 (AF031035) | 19468 |
| Paper separation roller for use in Ricoh Aficio 1035, 1045, 340, 350, 450, AP4500, 4510, Color 3006, PS360, 380, 420, 430, 500 (AF03-2035)            | 19656 |
| PCR for use in Ricoh Aficio 1045, 1035, 455, 450, 355, 350, 340, AP 4510, 4500 (AD027006)   | 19858 |

**RICOH AFICIO 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085**

|   |       |
|---|-------|
| Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085  | 7270  |
| Uni Drum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105                                      | 8547  |
| Wiper blade for use in Ricoh Aficio 550, 650, 850   | 12553 |
| Upper Fuser Roller for use in Ricoh Aficio 550, 551, 650, 700, MP 9001, 9002 (AE011044)   | 19497 |
| Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)        | 19650 |
| ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295) | 19838 |

**RICOH AFICIO 1015, 1018, 2015, 2020**

|  |       |
|--|-------|
| Wiper blade for use in Ricoh Aficio 1015, 1018   | 12550 |
| Uni Drum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027      | 12712 |
| Upper fuser picker finger for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (AE044062) | 19452 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Fuser thermistor for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (AW100073)  | 19463 |
| Paper feed roller for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (B0392740)   | 19464 |
| Primary Charge roller for use in Ricoh Aficio 1015, 1018, 2015, 2016, 2018, 2020, 3025, 3030, MP 1600, 2000, 2510, 2550, 2852, 3010, 3350, 3352 (AD027018) | 19467 |
| Upper fuser roller for use in Ricoh Aficio 1015, 1018 (AE011065)   | 19586 |
| Lower fuser pressure roller for use in Ricoh Aficio 1015, 1018 (AE02-0100)   | 19647 |

**RICOH AFICIO 1022, 1027, 2022**

|   |       |
|---|-------|
| OPC drum cleaning blade for use in Ricoh Aficio 220, 270,1022, 1027, 1032, 2022, 2027, 3025, 3030, MP 2352, 2510, 2550 (AD041114)                 | 12552 |
| Uni Drum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027   | 12712 |
| Drum with gears for use in Ricoh Aficio 1022, 1027, 2022  | 12713 |
| Lower pressure roller for use in Ricoh Aficio 1022, 1027, 2022, 2027, 3030, 3025, MP 2510, 2550, 2852, 3010, 3350, 3352 (AE020138)                | 19291 |
| Upper fuser roller for use in Ricoh Aficio 1022, 1027, 2022, 2027, 3030, 3025, MP 2510, 2550, 2852, 3010, 3350, 3352                              | 19293 |
| Upper fuser picker finger for use in Ricoh Aficio 2027, 2022, 1027, 1022, 3030, 3025, MP 3352, 3350, 3010, 2550 (AE044025)                        | 19453 |
| Drum unit for use in Ricoh Aficio 1022, 1027, 2022, 2027, 2032, 3025, 3030, MP 2510, 2550, 2851, 3010, 3350, 3351                                 | 19462 |
| Lower cleaning roller for use in Ricoh Aficio 1022, 2022, 3025, 3030, AP 2700, 3200, MP 2510, 2851, 3010, 3350 (AE042029)                         | 19583 |
| Paper feed roller for use in Ricoh Aficio 1022, 1027, 2022, 220, 270, 3025, AP2700, 3200, MP2500, 2550, 3010, 3350, PB3030, PS400, 450 (A2672751) | 19655 |
| Developer gear 5 piece kit for use in Ricoh Aficio 2032, 2027, 2022, 1032, 1022, 1027 (411018)  | 21012 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

PCR roller for use in Ricoh Aficio 2027, 2022, 1027, 1022

21063

**RICOH AFICIO 1060, 1075, 2051, 2060**

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

7270

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

8547

Uni Drum™ with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

12299

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060

12299

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500 (USA)

12553

Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105

15107

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060

17925

Transfer belt cleaning blade for use in Ricoh Aficio 2075SP, 2075, 2060SP, 2060, 2051, 1075, 1060, MP 9100, 9002, 8002, 7500, 6500, 6000, 5500

19286

Lower sleeved roller for use in Ricoh Aficio 1075, 1060, SP 9100 (AE020112)

19496

Upper fuser roller for use in Ricoh Aficio 1060, 1075 (AE011069)

19587

Fuser cleaning web roller for use in Ricoh Aficio 1060, 1075, SP 9100 DN (AE045046)

19619

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500 (S. AMERICA)

20626

**RICOH AFICIO 2035, 2045, 3035, 3045**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| SuMMIT® OPC drum with gears for use in Ricoh Aficio 340, 350, 450, 1035, 1045, 2035, 2045, 3035, 3045, 4500, 4510, MP 4500, 3500  | 7271  |
| Uni Drum™ F with gears for use in Ricoh Aficio 340, 350, 450, 1035, 1045, 2035, 2045, 3035, 3045  | 7412  |
| Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035) | 12123 |
| Wiper blade for use in Ricoh Aficio 2035, 2045, 3035, 3045  | 12575 |
| X-Generation® Wiper blade for Ricoh Aficio 2035, 2045, 3035, 3045   | 16522 |
| Transfer belt cleaning blade for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 2035, 2045, 3035, 3045, MP 3500, SP 8100 (A232-3930)  | 19245 |
| Lower fuser pressure roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, SP 8100, MP 4500, 3500 (AE020123, AE020125)   | 19448 |
| Transfer belt for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 1045, 2035, 2045, 3035, 3045, MP 3500, 4000, 5000, 5001, 5002, SP 8100 (A232-3880)                           | 19504 |
| Upper Fuser roller for use in Ricoh Aficio 1035, 2035, 2045, 3035, 3045, AP 4510, MP 3500, MP 4500, SP8100 (AE011071)   | 19508 |
| Lower cleaning roller for use in Ricoh Aficio 2035, 2045, 3035, 3045 (AE042084)   | 19584 |
| Paper separation roller for use in Ricoh Aficio 1035, 1045, 340, 350, 450, AP4500, 4510, Color 3006, PS360, 380, 420, 430, 500 (AF03-2035)  | 19656 |
| Primary Charge Roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, MP 5000, 4500, 4000, 3500 (AD02-7012)   | 19852 |
| Cleaning roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, MP 5000, 4500, 4000, 3500 (B082-2329)   | 19853 |

**RICOH AFICIO 3800, 3850**

|  |      |
|--|------|
| Black toner for use in Ricoh Aficio 3800, 3850 | 8134 |
| Drum with gears for use in Ricoh Aficio 3800   | 9694 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH AFICIO SP 100e, 100SF, 100SU, 200, 201, 202, 203, 204**

SuMMiT® drum with gears for use in Ricoh Aficio SP 204, 203, 202, 201, 200, 100e, 100SF, 100SU

18524

Smartchip™ for use in Ricoh Aficio SP 100e, 100SF, 100SU (407165, 407166, 407167)(US, LATAM, Asia)

18550

Smartchip™ for use in Ricoh Aficio SP 100e, 100SF, 100SU (407166)(EUR)

18576

Wiper blade for use in Ricoh Aficio SP 204, 203, 202, 201, 200, 100e, 100SF, 100SU

19247

**RICOH AFICIO SP 300**

Smartchip® for use in Ricoh Aficio SP 3300

14818

Uni Drum® OPC with gears for use in Ricoh SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735

Absolute Black® toner for use in Ricoh Aficio SP 300

17834

Uni Drum® with gears for use in Ricoh Aficio SP 300 dn

17835

Smartchip® for use in Ricoh Aficio SP 300

17837

**RICOH AFICIO SP 3400, 3410**

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF

17301

Uni Drum® OPC with gears for use in Ricoh Aficio SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Black® toner for use in Ricoh Aficio SP 3400, 3410, 3410SF                     | 17742 |
| Absolute Black® toner for use in Ricoh Aficio SP 3500, 3510, 3510SF, 3400, 3410, 3410SF | 17770 |
| Wiper blade for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF                  | 19149 |
| Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF            | 19151 |
| SuMMiT® drum with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF      | 19152 |
| Developer roller for use in Ricoh SP 3500, 3400   | 19561 |

**RICOH AFICIO SP 5200, 5210**

|  |       |
|--|-------|
| Smartchip™ for use in Ricoh Aficio SP 5200, 5210                             | 18256 |
| Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210                  | 18257 |
| Wiper blade for use in Ricoh Aficio SP 5200, 5210 SF, 5210 SR                | 18799 |
| SuMMiT® Drum with gears for use in Ricoh Aficio SP 5200, 5210                | 19024 |
| Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210                  | 19084 |
| Upper Fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4101)         | 19384 |
| Lower sleeved fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4059) | 19385 |
| Doctor blade for use in Ricoh Aficio SP 5210, 5200                           | 20432 |
| Developer roller for use in Ricoh SP 5200, 5210, MFP 5200S, 5210SF           | 20729 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH AFICIO SP C 430, 431**

|   |       |
|---|-------|
| Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035) | 12123 |
| Smartchip for use in Ricoh Aficio SPC 430, 431 Black  | 17756 |
| Smartchip for use in Ricoh Aficio SPC 430, 431 Cyan   | 17757 |
| Smartchip for use in Ricoh Aficio SPC 430, 431 Magenta  | 17758 |
| Smartchip for use in Ricoh Aficio SPC 430, 431 Yellow   | 17759 |
| Absolute Black® toner for use in Ricoh Aficio SPC 430, 431  | 17826 |
| Absolute Cyan® toner for use in Ricoh Aficio SPC 430, 431   | 17827 |
| Absolute Magenta® toner for use in Ricoh Aficio SPC 430, 431  | 17828 |
| Absolute Yellow® toner for use in Ricoh Aficio SPC 430, 431   | 17829 |
| Absolute Black® toner for use in Ricoh Aficio SPC 430, 431  | 19203 |
| Absolute Cyan® toner for use in Ricoh Aficio SPC 430, 431   | 19204 |
| Absolute Magenta® toner for use in Ricoh Aficio SPC 430, 431  | 19205 |
| Absolute Yellow® toner for use in Ricoh Aficio SPC 430, 431   | 19206 |
| X-Generation® Black toner for use in Ricoh Aficio SPC 430, 431  | 19762 |
| X-Generation® Cyan toner for use in Ricoh Aficio SPC 430, 431   | 19763 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Magenta toner for use in Ricoh Aficio SPC 430, 431

19764

X-Generation® Yellow toner for use in Ricoh Aficio SPC 430, 431

19765

**RICOH AFICIO SP 4100**

Clear Seal™ adhesive for toner hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

12259

Clear Seal™ adhesive for carrier hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

12260

Smartchip™ for use in Ricoh Aficio SP 4100N KP, 4110N KP, 4210N

13313

Wiper blade for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

15808

Uni Drum™ with gears for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

15809

Smartchip™ for use in Ricoh Aficio SP 4100 NL

15956

X-Generation® Black toner for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

17331

X-Generation® toner developer for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

17342

X-Generation® Black toner for use in Ricoh Aficio SP 4100 NL

17624

X-Generation® Black toner for use in Ricoh SP 4100, 4110, 4210, 4310

18884

X-Generation® toner developer for use in Ricoh SP 4100, 4110, 4210, 4310

18885

**RICOH AFICIO SP C 220, 221, 222**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Uni Drum™ S with gears for use in Ricoh Aficio 220, 270 S           | 8542  |
| Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222    | 12310 |
| Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222     | 12311 |
| Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222  | 12312 |
| Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222   | 12313 |
| Wiper blade for use in Ricoh Aficio 220, 270                        | 12552 |
| SuMMiT™ drum with gears for use in Ricoh Aficio 220, 270            | 12711 |
| Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222   | 13064 |
| Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222    | 13065 |
| Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222 | 13066 |
| Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222  | 13067 |
| Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222   | 13126 |
| Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222    | 13127 |
| Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222 | 13128 |
| Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222  | 13129 |
| Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222   | 14938 |
| Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222    | 14939 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222                            | 14940 |
| Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222                             | 14941 |
| Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222                               | 16550 |
| Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222                                | 16551 |
| Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222                             | 16552 |
| Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222                              | 16553 |
| Uni Drum™ with gear for use in Ricoh SPC 320, 312, 311, 310, 252, 242, 232, 231, 222, 221, 220 | 16789 |
| Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222                               | 16925 |
| Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222                            | 16926 |
| Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222                             | 16927 |

**RICOH AFICIO 551, 700**

|   |       |
|---|-------|
| Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085                    | 7270  |
| Uni Drum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105              | 8547  |
| Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105 | 12553 |
| Copier toner for use in Ricoh Aficio 551, 700, Type 5105,   | 16713 |
| Lower fuser pressure roller for use in Ricoh Aficio 1055, 1050, 700, 650, 551, 550 (AE022078)                     | 19447 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Upper Fuser Roller for use in Ricoh Aficio 550, 551, 650, 700, MP 9001, 9002 (AE011044)

19497

Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)

19650

ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295)

19838

**RICOH AFICIO MP C 3500, 4500**

Absolute Black® toner for use in Ricoh Aficio MPC 3500, 4500

12558

Absolute Magenta™ toner for use in Ricoh Aficio MP C 3500, 4500

12560

Absolute Yellow™ toner for use in Ricoh Aficio MP C 3500, 4500

12561

Smartchip™ Black for use in Ricoh Ipsi SPC 810, 811

13722

Absolute Cyan™ toner for use in Ricoh Aficio MP C 3500, 4500

14630

Smartchip™ Black for use in Ricoh Aficio MP C 3500, 4500

14631

Smartchip™ Cyan for use in Ricoh Aficio MP C 3500, 4500

14632

Smartchip™ Magenta for use in Ricoh Aficio MP C 3500, 4500

14633

Smartchip™ Yellow for use in Ricoh Aficio MP C 3500, 4500

14634

Absolute Black® toner for use in Ricoh Aficio® MPC 2000, 2500, 3000, 3500, 4500

14635

Absolute Cyan® toner for use in Ricoh Aficio® MPC 2000, 2500, 3000, 3500, 4500

14637

Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500

14638

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500                             | 14639 |
| Wiper blade for use in Ricoh MPC 4500, 3500, 3000, 2500, 2000   | 19224 |
| Uni Drum® with gears for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000                                 | 19426 |
| Transfer belt wiper blade for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000 (B233-6023)                | 19720 |
| Transfer belt cleaning blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3500, 3300, 3000, 2800, 2500, 2000 | 20439 |

**RICOH AFICIO MP C 2000, 2500, 3000**

|  |       |
|--|-------|
| Absolute Black® toner for use in Ricoh Aficio MP C 2000, 2500, 3000                | 13173 |
| Absolute Cyan™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000                 | 13174 |
| Absolute Magenta™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000              | 13175 |
| Absolute Yellow™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000               | 13176 |
| Absolute Black® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500   | 14635 |
| Absolute Cyan® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000                | 14636 |
| Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500 | 14638 |
| Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500  | 14639 |
| Smartchip™ Black (20,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000      | 14952 |
| Smartchip™ Cyan (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000       | 14953 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000

14954

Smartchip™ Yellow (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000

14955

Wiper blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3300, 2800, 2500, 2000

18300

Wiper blade for use in Ricoh MPC 4500, 3500, 3000, 2500, 2000

19224

Uni Drum® with gears for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000

19426

Transfer belt wiper blade for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000 (B233-6023)

19720

Transfer belt cleaning blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3500, 3300, 3000, 2800, 2500, 2000

20439

**RICOH AFICIO IPSIO CX 7100, 7500**

Uni Drum with gears for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000

9270

**RICOH AP 1400, 1600**

Absolute Black® toner for use in Ricoh AP 1400, 1600

9344

Absolute Black® toner for use in Ricoh AP 1400, 1600

5128

**RICOH AP 400, 410**

Uni Drum™ with gears for use in Ricoh AP 400, 410

9768



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Clear Seal™ adhesive for toner hopper for use in Ricoh AP 400, 410

9772

Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 400, 410

9773

Wiper blade for use in Ricoh AP 400, 410

11775

Smartchip™ for use in Ricoh AP 400, 410

12175

X-Generation® Black toner for use in Ricoh AP 400, 410

17330

X-Generation® toner developer for use in Ricoh AP 400, 410

17341

**RICOH AP 600, 610, 2600, 2610**

Clear Seal™ adhesive for toner hopper for use in Ricoh AP 600, 610, 2600, 2610

9775

Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 600, 610, 2600, 2610

9776

Wiper blade for use in Ricoh AP 600, 610, 2600, 2610

9777

Uni Drum™ with gears for use in Ricoh AP 600, 610, 2600, 2610

9778

Smartchip™ for use in Ricoh AP 2610, 2600, 610, 600 toner

15219

X-Generation® Black toner for use in Ricoh AP 600, 610, 2600, 2610

17335

X-Generation® toner carrier for use in Ricoh AP 600, 610, 2600, 2610

17339

X Generation Wiper blade for use in Ricoh AP 600, 610, 2600, 2610

18575

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH IMAGIO P TYPE 2**

Uni Drum™ S drum with gears for use in Ricoh Imagio P Type 2

8707

**RICOH IMAGIO CA, CF, DA SERIES TYPE 1**

Absolute Black® toner for use in Ricoh Imagio CA, CF, DA Series, Type 1

8151

**RICOH IMAGIO TYPE 18**

Absolute Black® toner for use in Ricoh Imagio Type 18

8730

**RICOH IMAGIO TYPE 4**

Absolute Black® toner for use in Ricoh Imagio Type 4

8148

**RICOH IMAGIO TYPE 7**

Absolute Black® toner for use in Ricoh Imagio Type 7

8732

**RICOH IMAGIO TYPE 900**

Absolute Black® toner for use in Ricoh Imagio Type 900

6758

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Ricoh Imagio Type 900

6624

**RICOH IPSIO CX 6000, 6100, 6600**

Absolute Black® toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9734

Absolute Cyan™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9735

Absolute Magenta™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9736

Absolute Yellow™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9738

**RICOH IPSIO SP C 710, 711**

Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711

11727

Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11728

Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11729

Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11730

Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711

12729

Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12730

Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12731

Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12732

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Black toner for use in Ricoh Ipsio SP C 710, 711    | 13264 |
| Smartchip™ Cyan toner for use in Ricoh Ipsio SP C 710, 711     | 13267 |
| Smartchip™ Magenta toner for use in Ricoh Ipsio SP C 710, 711, | 13268 |
| Smartchip™ Yellow toner for use in Ricoh Ipsio SP C 710, 711   | 13270 |
| Drum unit sealing cover for use in Ricoh Ipsio SP C 710        | 15246 |

**RICOH IPSIO SP C 810, 811 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811   | 12562 |
| Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811    | 12563 |
| Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811 | 12564 |
| Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811  | 12565 |
| Absolute Black® toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811        | 12566 |
| Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811         | 12567 |
| Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811      | 12568 |
| Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811       | 12569 |
| Smartchip™ Black for use in Ricoh Ipsio SPC 810, 811                             | 13722 |
| Smartchip™ Cyan for use in Ricoh Ipsio SPC 810, 811                              | 13723 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta for use in Ricoh Ipsio SPC 810, 811

13724

Smartchip™ Yellow for use in Ricoh Ipsio SPC 810, 811

13725

Uni Drum® with gears for use in Ricoh Ipsio SPC 810, Aficio SPC 811

17522

**RICOH IPSIO SP C 820, 821, 811 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ Black for use in Ricoh Aficio SPC 811

13727

Smartchip™ Cyan for use in Ricoh Aficio SPC 811

13728

Smartchip™ Magenta for use in Ricoh Aficio SPC 811

13729

Smartchip™ Yellow for use in Ricoh Aficio SPC 811

13730

Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17943

Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17944

Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17945

Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17946

Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17947

Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17948

Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17949

Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17950

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Black® Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821   | 17951 |
| Absolute Cyan™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821    | 17952 |
| Absolute Magenta™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821 | 17953 |
| Absolute Yellow™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821  | 17954 |
| Absolute Black® Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821   | 19195 |
| Absolute Cyan™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821,   | 19196 |
| Absolute Magenta™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821 | 19197 |
| Absolute Yellow™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821  | 19198 |

**RICOH AFICIO 1515, MP 301 SP 301 SPF, 201, 171, 161**

|  |       |
|--|-------|
| Uni Drum® gearless for use in Ricoh Aficio 1515, MP 201, 171, 161                                    | 19237 |
| Upper Fuser roller for use in Ricoh Aficio 1515, MP 171F, 201 SPF (AE01-1061/AE01-1086)              | 19382 |
| Upper Fuser roller for use in Ricoh Aficio MP 301 SP, 301 SPF (AE01-1131)                            | 19383 |
| Lower sleeved fuser roller for use in Ricoh Aficio 1515, 161 F, 171 F (AE02-0107)                    | 19386 |
| Wiper blade for use in Ricoh Aficio 1515, MP 201, 171, 161   | 19417 |
| Lower Fuser roller for use in Ricoh Aficio MP 301 SP, 301 SPF (AE02-0207)                            | 19601 |
| Paper feed roller for use in Ricoh Aficio 1515, 1013, 120, MP 301, 201, 171, 161, SP 220 (AF03-1061) | 19682 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Developer for use in Ricoh Aficio 1515, MP 301, 201, 171, 161, 275 bag (Type 1515, 411844)

20648

Upper fuser roller bushing set (2) for use in Ricoh Aficio 1515, 1013, 120, MP 201, 171, 161 (AE03-1034)

21004

Fuser thermistor for use in Ricoh Aficio 1515, MP 301, 201, 171, 161 (AW100088)

21008

**RICOH AFICIO MP C 6000, 6501, 7500, 7501**

Absolute Black toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501 (841084, 841288)

20375

**RICOH AFICIO MP 8000, 7500, 6500, 6000, 5500**

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500

17925

**RICOH AFICIO 1224 C, 1232 C**

Absolute Black® toner for use in Ricoh Aficio 1224 C, 1232 C

9755

Absolute Cyan™ toner for use in Ricoh Aficio 1224 C, 1232 C

9756

Absolute Magenta™ toner for use in Ricoh Aficio 1224 C, 1232 C

9757

Absolute Yellow™ toner for use in Ricoh Aficio 1224 C, 1232 C

9758

Absolute Black® toner for use in Ricoh Aficio 1224 C, 1232 C

13193

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Cyan™ toner for use in Ricoh Aficio 1224 C, 1232 C

13194

Absolute Magenta™ toner for use in Ricoh Aficio 1224 C, 1232 C

13195

Absolute Yellow™ toner for use in Ricoh Aficio 1224 C, 1232 C

13196

**RICOH AFICIO 2105**

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

7270

Uni Drum™ with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

8547

Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105

12553

Absolute Black® toner for use in Ricoh Aficio 2105

16340

Paper separation roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085, 1050, 1055, MP 8000, 7500, 6500, 6000, 5500, 1350, 1100, 5560C, 3260C (AF032080, AF030240)

19465

Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)

19650

ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295)

19838

ADF Separation (Reverse) Roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, MP 9000, 8000, 7000, 6000, 5000 (A859-2241)

19847

**RICOH AFICIO 3228, 3235, 3245 C**

Absolute Black® toner for use in Ricoh Aficio 3228, 3235 3245 C

10019

Absolute Cyan™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10020



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10021

Absolute Yellow™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10022

Uni Drum® with gears for use in Ricoh Aficio 3228, 3235, 3245 C (B1809511)

19446

**RICOH AFICIO MP C 2800, 2880, 3001, 3300, 4501, 5000, 5050, 5501**

Absolute Black® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5050, 5501

19766

Absolute Cyan® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19767

Absolute Magenta® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19768

Absolute Yellow® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19769

Absolute Black® toner for use in Ricoh Aficio MPC 2800, 2880, 3300, 4000, 5000, 5050

20054

Absolute Cyan® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20055

Absolute Magenta® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20056

Absolute Yellow® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20057

**RICOH AFICIO SP 311, 311 SFN**

SuMMiT® drum with gears for use in Ricoh Aficio SP 311, 310, 300

17835

Wiper blade for use in Ricoh SP 311, 310, 300

19234

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip® for use in Ricoh Aficio SP 311, 310 (407246)(EU)

19256

Absolute Black® toner for use in Ricoh Aficio SP 311, 311 SFN, 310

19281

Absolute Black® toner for use in Ricoh SP 311, 311 SFN, 300

19282

**RICOH 4510, 4520, 3610, 3600**

Smartchip® for use in Ricoh SP 4510 (407316)(US)

19808

Smartchip® for use in Ricoh SP 4510, 3610, 3600 (407319)(US)

19809

Smartchip® for use in Ricoh SP 4510 (407318)(EU)

19810

Smartchip® drum unit for use in Ricoh SP 4510, 3610, 3600 (407324)(WW)

19812

Absolute Black® toner for use in Ricoh Aficio SP 4510, 4500

20325

Absolute Black® toner for use in Ricoh Aficio SP 4520, 4510, 3610, 3600

20326

Absolute Black® toner for use in Ricoh Aficio SP 4510, 3610, 3600

20328

**RICOH AFICIO SP 5200, 5210**

Smartchip™ for use in Ricoh Aficio SP 5200, 5210 (406685, 406683, 406689 )(WW)

18256

Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210,

18257

Wiper blade for use in Ricoh Aficio SP 5200, 5210 SF, 5210 SR

18799

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| SuMMiT® Drum with gears for use in Ricoh Aficio SP 5200, 5210                | 19024 |
| Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210                  | 19084 |
| Upper Fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4101)         | 19384 |
| Lower sleeved fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4059) | 19385 |
| Doctor blade for use in Ricoh Aficio SP 5210, 5200                           | 20432 |
| Developer roller for use in Ricoh SP 5200, 5210, MFP 5200S, 5210SF           | 20729 |

**RICOH AFICIO MP C 3002, 3502**

|   |       |
|---|-------|
| Uni Drum® with gears for use in Ricoh Aficio MPC 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001 (D144-2253) | 19480 |
| Absolute Black® toner for use in Ricoh Aficio MPC 3502, 3002  | 21102 |
| Absolute Cyan® toner for use in Ricoh Aficio MPC 3502, 3002,  | 21103 |
| Absolute Magenta® toner for use in Ricoh Aficio MPC 3502, 3002  | 21104 |
| Absolute Yellow® toner for use in Ricoh Aficio MPC 3502, 3002   | 21105 |
| Absolute Black® toner for use in Ricoh Aficio MPC 3502, 3002  | 21106 |
| Absolute Cyan® toner for use in Ricoh Aficio MPC 3502, 3002   | 21107 |
| Absolute Magenta® toner for use in Ricoh Aficio MPC 3502, 3002  | 21108 |
| Absolute Yellow® toner for use in Ricoh Aficio MPC 3502, 3002   | 21109 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH AFICIO MP C 2030, 2050, 2350, 2550**

Smartchip™ Black for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841280)(EU) 18435

Smartchip™ Cyan for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841281)(EU) 18436

Smartchip™ Magenta for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841282)(EU) 18437

Smartchip™ Yellow for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841283)(EU) 18438

Uni Drum® with gears for use in Ricoh Aficio MPC Color 2551, 2550, 2530, 2051, 2050, 2030 (D8092000, D8092001, D8092002, D8092003) 19476

Lower Fuser roller for use in Ricoh Aficio MP C 2550, 2530, 2050, 2030 (AE02-0175) 19603

Hot roller for use in Ricoh Aficio MP C 2550, 2530, 2050, 2030 (AE01-0074) 19604

Smartchip™ Black for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841280)(US) 20329

Smartchip™ Cyan for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841281)(US) 20330

Smartchip™ Magenta for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841282)(US) 20331

Smartchip™ Yellow for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841283)(US) 20332

**RICOH AFICIO SP 5310, 5300, MP 601, 501 SPF**

Smartchip® toner for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF (407823)(US) 20997

Absolute Black® toner for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF 20998

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Waste toner bottle for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF

20999

**RICOH AFICIO SP 5310, 5300, MP 601, 501 SPF**

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

17301

Uni Drum® with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735

Absolute Black® toner for use in Ricoh SP 3500, 3510, 3510SF

17743

Absolute Black® toner for use in Ricoh SP 3500, 3510, 3510SF, 3400, 3410, 3410SF

17770

Wiper blade for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19149

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19151

SuMMiT® drum with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19152

**RICOH AFICIO MP C 4420, 4410, 4400**

Absolute Black® toner for use in Ricoh Aficio SP 4420 SF, 4410 SF, 4400 SF

18839

Smartchip™ for use in Ricoh Aficio SP 4420, 4410, 4400 (406978)

18840

**RICOH MP C 2503, 2003**

Smartchip® Black toner for use in Ricoh MPC 2503, 2003 (841918)

20351

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® Cyan toner for use in Ricoh MPC 2503, 2003 (841921)    | 20352 |
| Smartchip® Magenta toner for use in Ricoh MPC 2503, 2003 (841920) | 20353 |
| Smartchip® Yellow toner for use in Ricoh MPC 2503, 2003 (841919)  | 20354 |
| Uni Drum® with gears for use in Ricoh Aficio MPC 2503, 2003       | 20938 |

**RICOH MP C 6003, 5503, 4503, 3503, 3003**

|  |       |
|--|-------|
| Smartchip® Black toner for use in Ricoh MPC 6003, 5503, 4503 (841849)(US)      | 20359 |
| Smartchip® Cyan toner for use in Ricoh MPC 6003, 5503, 4503 (841852)(US)       | 20360 |
| Smartchip® Magenta toner for use in Ricoh MPC 6003, 5503, 4503 (841851)(US)    | 20361 |
| Smartchip® Yellow toner for use in Ricoh MPC 6003, 5503, 4503 (841850)(US)     | 20362 |
| Uni Drum® with gears for use in Ricoh Aficio MP C 6003, 5503, 4503, 3503, 3003 | 20533 |

**RICOH AFICIO MP C 401 SR, 400, 300**

|  |       |
|--|-------|
| Uni Drum® with gears for use in Ricoh Aficio MPC Color 401 SR, 400, 300 (M0262015)   | 19478 |
| Paper feed roller for use in Ricoh Aficio 3045, 3035, MP 4500, 4001, 4000, 3500, 3353, 3352, 3053, 2852, 2553, 2352, MPC 401 (AF03-1090) | 19681 |
| Pickup roller for use in Ricoh Aficio 3045, 3035, MP 4500, 4001, 4000, 3500, 3353, 3352, 3053, 2852, 2553, 2352, MPC 401 (AF030090)      | 19690 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH MP 401 SF, SP 4520**

Smartchip® for use in Ricoh MP 401 SF, SP 4520 (841886)(US)

20539

Smartchip® for use in Ricoh MP 401 SF, SP 4520 (841887)(EU)

20540

Smartchip® drum unit for use in Ricoh MP 401 SF, SP 4520 (M906-0118)(US)

20658

SuMMiT® drum with gears for use in Ricoh MP 401, SP 4520, 4510, 3610, 3600

20659

Absolute Black® toner for use in Ricoh Aficio SP 4520, MP 401 SF

20699

**RICOH AFICIO PRO 901, 900, 720**

Uni Drum® with gears for use in Ricoh Aficio Pro Color 901, 900, 720 (D0169510)

19479

**RICOH AFICIO MP 9000, 1350, 1100, Pro 1107, 907**

Uni Drum® with gears for use in Ricoh Aficio MP 9000, 1100, 1350, Pro 1106

19239

ADF Separation (Reverse) Roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, MP 9000, 8000, 7000, 6000, 5000 (A859-2241)

19847

Wiper blade for use in Ricoh Aficio MP 9000, 1350, 1100 (B2343564)

20440

Upper Fuser Roller for use in Ricoh Aficio MP 9000, 1100, Pro 1107, 907 (AE011108)

21010

Developer for use in Ricoh Aficio MP 9000, 1350, 1100, Pro 1357, 1107, 907 (B2349640)

21011

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****RICOH AFICIO MP 5002, 5001, 5000, 4002, 4001, 4000**

|   |       |
|---|-------|
| Wiper blade for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000   | 18301 |
| Uni Drum® with gears for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000  | 19238 |
| Transfer belt for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 1045, 2035, 2045, 3035, 3045, MP 3500, 4000, 5000, 5001, 5002, SP 8100 (A232-3880) | 19504 |
| Drum cleaning blade for use in Ricoh Aficio MP 4000, 4001, 4002, 5000, 5002 (D0092351)  | 19505 |
| Upper Fuser roller for use in Ricoh Aficio MP 4000, 4001, 4002, 5000, 5001, 5002 (AE010099)   | 19507 |
| Lower Fuser roller for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (AE020199)   | 19689 |
| Upper fuser picker finger for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (AE04-4099)   | 19855 |
| Fuser thermistor for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (D009-4177)  | 19856 |
| Developer for use in Ricoh Aficio MP 5002, 5001, 5000, 4500, 4002, 4001, 4000, 3500 (B2969640)  | 21009 |

**RICOH AFICIO MP C 7501, 7500, 6501, 6000, Pro C550 EX**

|  |       |
|--|-------|
| Uni Drum® with gears for use in Ricoh Aficio MPC 7501, 7500, 6501, 6000, Pro C550 EX (D0149510)  | 19629 |
| Absolute Black toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 900g (841084, 841288)   | 20375 |
| Absolute Cyan toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841085, 841289)    | 20376 |
| Absolute Magenta toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841086- 841290) | 20377 |
| Absolute Yellow toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841087, 841291)  | 20378 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Wiper blade for use in Ricoh Aficio MPC 7501, 7500, 6501, 6000

20441

**RICOH MP C 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001**

Uni Drum® with gears for use in Ricoh Aficio MPC 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001 (D144-2253)

19480

**RICOH CL 7000**

Black toner for use in Ricoh CL 7000, 7100

10382

Drum with gears for use in Ricoh CL 7000

9695

**RICOH CL 7200, 7300**

Absolute Black® toner for use in Ricoh CL 7200, 7300

10023

Absolute Cyan™ toner for use in Ricoh CL 7200, 7300

10024

Absolute Magenta™ toner for use in Ricoh CL 7200, 7300

10025

Absolute Yellow™ toner for use in Ricoh CL 7200, 7300

10026

Absolute Black® toner for use in Ricoh CL 7200, 7300

11426

Absolute Cyan™ toner for use in Ricoh CL 7200, 7300

11427

Absolute Magenta™ toner for use in Ricoh CL 7200, 7300

11428

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Yellow™ toner for use in Ricoh CL 7200, 7300

11429

**SAMSUNG®****SAMSUNG CLX 4195, 6260, SLC 2680, 2670, 2620, CLP 415 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

SuMMiT® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260

17870

Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260

17871

Smartchip® Black for use in Samsung CLP 415, CLX 4195

17906

Smartchip® Cyan for use in Samsung CLP 415, CLX 4195

17907

Smartchip® Magenta for use in Samsung CLP 415, CLX 4195

17908

Smartchip® Yellow for use in Samsung CLP 415, CLX 4195

17909

Absolute Black® toner for use in Samsung CLX 4195

17959

Absolute Cyan™ toner for use in Samsung CLX 4195

17960

Absolute Magenta™ toner for use in Samsung CLX 4195

17961

Absolute Yellow™ toner for use in Samsung CLX 4195

17962

PCR roller for use in Samsung CLX 4195, 6260

17963

Smartchip® Black for use in Samsung CLP 415, CLX 4195

18051

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip® Cyan for use in Samsung CLP 415, CLX 4195   | 18052 |
| Smartchip® Magenta for use in Samsung CLP 415, CLX 4195  | 18053 |
| Smartchip® Yellow for use in Samsung CLP 415, CLX 4195   | 18054 |
| Smartchip® Black for use in Samsung CLP 415, CLX 4195  | 18097 |
| Smartchip® Cyan for use in Samsung CLP 415, CLX 4195   | 18098 |
| Smartchip® Magenta for use in Samsung CLP 415, CLX 4195  | 18099 |
| Smartchip® Yellow for use in Samsung CLP 415, CLX 4195   | 18100 |
| Shipping lock and drum cover set for use in Samsung CLX 4195   | 18217 |
| Doctor blade for use in Samsung CLP 415, 680, CLX 4195, 6260, SLC 2680, 2670, 2620 (CLT504/505/506)    | 18488 |
| Absolute Black® toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW   | 18803 |
| Absolute Cyan™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW    | 18804 |
| Absolute Magenta™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW | 18805 |
| Absolute Yellow™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860     | 18806 |
| X-Generation® Black toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620,       | 19036 |
| X-Generation® Cyan toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620         | 19037 |
| X-Generation® Magenta toner for use in Samsung CLP 680, 415, CLX 6260, 4195                            | 19038 |
| X-Generation® Yellow toner for use in Samsung CLP 680, 415, CLX 6260, 4195                             | 19039 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| X-Generation® Black toner for use in Samsung CLP 415, CLX 4195                    | 19045 |
| X-Generation® Cyan toner for use in Samsung CLP 415, CLX 4195                     | 19046 |
| X-Generation® Magenta toner for use in Samsung CLP 415, CLX 4195                  | 19047 |
| X-Generation® Yellow toner for use in Samsung CLP 415, CLX 4195                   | 19048 |
| Clear adhesive seal for use in Samsung CLP 415, CLX 4195, SL-C 1860               | 19246 |
| Wiper blade for use in Samsung CLP 680, 415, CLX 4195, 6260, SLC 2680, 2670, 2620 | 20428 |

**SAMSUNG CLP 365, CLX 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Seal toner hopper fill plug for use in Samsung CLP 365, 300, CLX 3305, 3160 FN, SL-C 410, 430, 432, 433, 460, 462, 480, 482, 483 (32mm) | 11625 |
| Smartchip® Black for use in Samsung CLP 365, CLX 3305   | 17964 |
| Smartchip® Cyan for use in Samsung CLP 365, CLX 3305  | 17965 |
| Smartchip® Magenta for use in Samsung CLP 365, CLX 3305   | 17966 |
| Smartchip® Yellow for use in Samsung CLP 365, CLX 3305  | 17967 |
| Absolute Black® toner for use in Samsung CLP 365, CLX 3305  | 17968 |
| Absolute Cyan™ toner for use in Samsung CLP 365, CLX 3305   | 17969 |
| Absolute Magenta™ toner for use in Samsung CLP 365, CLX 3305  | 17970 |
| Absolute Yellow™ toner for use in Samsung CLP 365, CLX 3305   | 17971 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip® Black for use in Samsung CLP 365, CLX 3305

18047

Smartchip® Cyan for use in Samsung CLP 365, CLX 3305

18048

Smartchip® Magenta for use in Samsung CLP 365, CLX 3305

18049

Smartchip® Yellow for use in Samsung CLP 365, CLX 3305

18050

Absolute Black® toner for use in Samsung CLP 365, CLX 3305

18061

Absolute Cyan® toner for use in Samsung CLP 365, CLX 3305

18062

Absolute Magenta® toner for use in Samsung CLP 365, CLX 3305

18063

Absolute Yellow® toner for use in Samsung CLP 365, CLX 3305

18064

Smartchip® Black for use in Samsung CLP 365, CLX 3305

18093

Smartchip® Cyan for use in Samsung CLP 365, CLX 3305

18094

Smartchip® Magenta for use in Samsung CLP 365, CLX 3305

18095

Smartchip® Yellow for use in Samsung CLP 365, CLX 3305

18096

Developer roller cover for use in Samsung CLP 365, CLX 3305

18218

Clear adhesive seal for use in Samsung CLP 365, CLX 3305

18344

Developer roller for use in Samsung CLP 360, 365, CLX 3305

18433

Smartchip™ drum fuse for use in Samsung CLP 365, 360, 325, 320, 315, 310, Xpress C410, CLX 3305, 3185, 3175, 3170

19088

Supply roller for use in Samsung CLP 365, CLX 3305

19721

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ drum fuse with holder for use in Samsung CLP 365, 360, 325, 320, 315, 310, Xpress C410, CLX 3305, 3185, 3175, 3170

19863

**SAMSUNG CLX 3160 FN, CLP 300**

Absolute Black® toner for use in Samsung CLX 3160 FN

10167

Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN

10168

Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN

10169

Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN

10170

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

10907

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

10908

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

10909

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

10910

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

11571

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

11572

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

11573

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

11574

Seal toner hopper fill plug for use in Samsung CLP 300, CLX 3160 FN

11625

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

11646

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

11647

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

11648

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

11649

Absolute Black® toner for use in Samsung CLX 3160 FN

11803

Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN

11804

Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN

11805

Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN

11806

PCR roller for use in Samsung CLP 300, CLX 3160 FN

12329

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

13492

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

13493

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

16149

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

16150

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

16151

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

16152

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

16153

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

16154

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

16155

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

16156

**SAMSUNG CLP 610, 660, CLX 6200, 6210, 6240**

Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12473

Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12499

Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12500

Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12501

Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12502

Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12503

Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12504

Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12505

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12506

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12507

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12508

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12509

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12510

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12511



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                        | 12512 |
| ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                         | 12513 |
| Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                          | 13099 |
| Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                           | 13100 |
| Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                        | 13101 |
| Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                         | 13102 |
| ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                          | 13813 |
| ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                           | 13814 |
| ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                        | 13815 |
| ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                         | 13816 |
| ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                          | 13817 |
| ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                           | 13818 |
| ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                        | 13819 |
| ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                         | 13820 |
| PCR roller for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                                     | 14214 |
| Uni Drum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250 | 14462 |
| SuMMiT™ OPC drum with gears for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240                    | 15289 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16390

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16391

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16393

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16394

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16395

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16396

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16397

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16398

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16399

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16400

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16402

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16403

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16404

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16405

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16406

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16407

Supply roller for use in Samsung CLP 610, 660

16962

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG CLX 6220, 6250, CLP 612, 620, 670**

|  |       |
|--|-------|
| Uni Drum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250 | 14462 |
| Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                           | 15583 |
| Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                            | 15584 |
| Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                         | 15585 |
| Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                          | 15586 |
| Smartchip™ Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                                | 15587 |
| ASiC Encrypto Smartchip® Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                  | 16424 |
| ASiC Encrypto Smartchip® Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                   | 16425 |
| ASiC Encrypto Smartchip® Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                | 16426 |
| ASiC Encrypto Smartchip® Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                 | 16427 |
| ASiC Encrypto Smartchip® Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                  | 16428 |
| ASiC Encrypto Smartchip® Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                   | 16429 |
| ASiC Encrypto Smartchip® Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                | 16430 |
| ASiC Encrypto Smartchip® Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                 | 16431 |
| Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250                           | 16440 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250    | 16442 |
| Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 | 16443 |
| Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250  | 16444 |
| Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250   | 19740 |
| Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250    | 19741 |
| Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 | 19742 |
| Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250  | 19743 |

**SAMSUNG CLP 680, 415, CLX 6260, SCL 2680, 2670, 2620 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| SuMMiT® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260  | 17870 |
| Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260 | 17871 |
| Smartchip® Black for use in Samsung CLP 680, CLX 6260                    | 17914 |
| Smartchip® Cyan for use in Samsung CLP 680, CLX 6260                     | 17915 |
| Smartchip® Magenta for use in Samsung CLP 680, CLX 6260                  | 17916 |
| Smartchip® Yellow for use in Samsung CLP 680, CLX 6260                   | 17917 |
| PCR roller for use in Samsung CLP 415, 680, CLX 4195, 6260               | 17963 |
| Smartchip® Black for use in Samsung CLP 680, CLX 6260                    | 18055 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® Cyan for use in Samsung CLP 680, CLX 6260  | 18056 |
| Smartchip® Magenta for use in Samsung CLP 680, CLX 6260   | 18057 |
| Smartchip® Yellow for use in Samsung CLP 680, CLX 6260  | 18058 |
| Smartchip® Black for use in Samsung CLP 680, CLX 6260   | 18101 |
| Smartchip® Cyan for use in Samsung CLP 680, CLX 6260  | 18102 |
| Smartchip® Magenta for use in Samsung CLP 680, CLX 6260   | 18103 |
| Smartchip® Yellow for use in Samsung CLP 680, CLX 6260  | 18104 |
| Drum cover for use in Samsung CLP 680, CLX 6260   | 18219 |
| X-Generation® Black toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620 | 19036 |
| X-Generation® Cyan toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620  | 19037 |
| X-Generation® Magenta toner for use in Samsung CLP 680, 415, CLX 6260, 4195                     | 19038 |
| X-Generation® Yellow toner for use in Samsung CLP 680, 415, CLX 6260, 4195                      | 19039 |
| X-Generation® Black toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620            | 19041 |
| X-Generation® Cyan toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620             | 19042 |
| X-Generation® Magenta toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620          | 19043 |
| X-Generation® Yellow toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620           | 19044 |
| Wiper blade for use in Samsung CLP 680, 415, CLX 4195, 6260, SLC 2680, 2670, 2620               | 20428 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG CLX 8380 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black for use in Samsung CLX 8380        | 15946 |
| Smartchip™ Cyan for use in Samsung CLX 8380         | 15947 |
| Smartchip™ Magenta for use in Samsung CLX 8380      | 15948 |
| Smartchip™ Yellow for use in Samsung CLX 8380       | 15949 |
| Absolute Black® toner for use in Samsung CLX 8380   | 17926 |
| Absolute Cyan™ toner for use in Samsung CLX 8380    | 17927 |
| Absolute Magenta™ toner for use in Samsung CLX 8380 | 17928 |
| Absolute Yellow™ toner for use in Samsung CLX 8380  | 17929 |
| Smartchip™ Black for use in Samsung CLX 8380        | 18153 |
| Smartchip™ Cyan for use in Samsung CLX 8380         | 18154 |
| Smartchip™ Magenta for use in Samsung CLX 8380      | 18155 |
| Smartchip™ Yellow for use in Samsung CLX 8380       | 18156 |
| Smartchip™ Black for use in Samsung CLX 8380        | 18157 |
| Smartchip™ Cyan for use in Samsung CLX 8380         | 18158 |
| Smartchip™ Magenta for use in Samsung CLX 8380      | 18159 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Yellow for use in Samsung CLX 8380              | 18160 |
| SuMMiT® drum gearless for use in Samsung CLX 8380          | 18997 |
| Absolute Black® toner for use in Samsung CLX 8385, 8380    | 19121 |
| Absolute Cyan™ toner for use in Samsung CLX 8385, 8380     | 19122 |
| Absolute Magenta™ toner for use in Samsung CLX 8385, 8380, | 19123 |
| Absolute Yellow™ toner for use in Samsung CLX 8385, 8380   | 19124 |

**SAMSUNG CLX 8385 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black for use in Samsung CLX 8385            | 17451 |
| Smartchip™ Cyan for use in Samsung CLX 8385             | 17452 |
| Smartchip™ Magenta for use in Samsung CLX 8385          | 17453 |
| Smartchip™ Yellow for use in Samsung CLX 8385           | 17454 |
| Smartchip™ Black for use in Samsung CLX 8385            | 17839 |
| Smartchip™ Cyan for use in Samsung CLX 8385             | 17840 |
| Smartchip™ Magenta for use in Samsung CLX 8385          | 17841 |
| Smartchip™ Yellow for use in Samsung CLX 8385           | 17842 |
| Absolute Black® toner for use in Samsung CLX 8385, 8380 | 17926 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Cyan™ toner for use in Samsung CLX 8385, 8380     | 17927 |
| Absolute Magenta™ toner for use in Samsung CLX 8385, 8380  | 17928 |
| Absolute Yellow™ toner for use in Samsung CLX 8385, 8380   | 17929 |
| Absolute Black® toner for use in Samsung CLX 8385, 8380    | 19121 |
| Absolute Cyan™ toner for use in Samsung CLX 8385, 8380     | 19122 |
| Absolute Magenta™ toner for use in Samsung CLX 8385, 8380, | 19123 |
| Absolute Yellow™ toner for use in Samsung CLX 8385, 8380   | 19124 |

**SAMSUNG CLX 9250, 9258, 9350, 9358 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358   | 18162 |
| Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358   | 18166 |
| Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358   | 18170 |
| Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358    | 18221 |
| Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358 | 18222 |
| Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358  | 18223 |
| Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358    | 18224 |
| Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358 | 18225 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358

18226

Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358

18227

Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358

18228

Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358

18229

Absolute Black® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250

21115

Absolute Cyan® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250

21116

Absolute Magenta® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250

21117

Absolute Yellow® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250,

21118

**SAMSUNG SCX 6345**

Absolute Black® toner for use in Samsung SCX 6345

11415

Absolute Black® toner for use in Samsung SCX 6345

11416

Smartchip™ toner cartridge for use in Samsung SCX 6345

11417

Doctor blade for use in Samsung SCX 6345

11418

Wiper blade for use in Samsung SCX 6345

11420

Mag Roller Sleeve for use in Samsung SCX 6345

11473

PCR roller for use in Samsung SCX 6345

11475

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® developer carrier for drum unit for use in Samsung SCX 6345

11645

Smartchip™ drum unit for use in Samsung SCX 6345

13478

Clear adhesive seal for use in Samsung SCX 6345

14584

Uni Drum® with gears for use in Samsung SCX 6555, 6545, 6345

17527

**SAMSUNG SCX 6555, 6545 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Wiper blade for use in Samsung SCX 6555, 6455, 6345

11420

TEXT grade toner for use in Samsung SCX 6555, 6545

14093

Smartchip™ toner with connector for use in Samsung SCX 6555, 6545

14094

TEXT grade toner for use in Samsung SCX 6555, 6545

17317

Absolute Black® toner for use in Samsung SCX 6555, 6545

17525

Uni Drum® OPC with gears for use in Samsung SCX 6555, 6545

17527

Absolute Black® toner for use in Samsung SCX 6555, 6545

17536

Smartchip™ drum unit for use in Samsung SCX 6555, 6545

17537

Absolute Black® developer for use in Samsung SCX 6555, 6545

17571

OEM style cable for use in Samsung SCX 6555

17648

PCR roller for use in Samsung SCX 6555, 6545

18615

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| X-Generation® Black toner for use in Samsung SCX 6555, 6545   | 19750 |
| X-Generation® Black toner for use in Samsung SCX 6555, 6545   | 19752 |
| Upper fuser roller for use in Xerox WorkCentre 4250, 4260, Samsung SCX 6555, 6545 (022N02372, JC66-01871A)    | 20410 |
| Fuser cleaning roller for use in Xerox WorkCentre 4250, 4260, Samsung SCX 6555, 6545 (006N01329, JC66-01870A) | 20412 |
| SuMMiT® drum with gears for use in Samsung SCX 6555, 6545   | 20667 |

**SAMSUNG SCX 3405, SF 760**

|  |       |
|--|-------|
| Drum cover for use in Samsung ML 2165, 2160, 1860, 1665, 1660, SL-M 2070, 2022, 2020, SCX 3405, 3205, 3200 | 15957 |
| Smartchip® for use in Samsung ML 2160, 2165, SCX 3405, SF 760  | 17069 |
| Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760  | 17071 |
| Uni Drum® with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165                 | 17473 |
| SuMMiT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165              | 17474 |
| Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165                | 17475 |
| Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165                | 17476 |
| Wiper blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165                          | 17477 |
| Doctor blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160 1165                          | 17478 |
| PCR roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165                           | 17479 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Developer roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165

17480

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760

18040

SuMMiT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165

18112

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760

18206

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/XAA)

18518

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/ELS)

18519

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/XIL)

18949

**SAMSUNG SCX 4300, 4200, 4116, 4100**

Absolute Black® toner for Samsung SCX 4300

13323

PCR roller for use in Samsung SCX 4300

13325

Doctor blade for use in Samsung SCX 4300

13326

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

Absolute Black® toner for use in Samsung SCX 4300

15343

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16412

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16413

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 4500**

|  |       |
|--|-------|
| Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500       | 11939 |
| ASiC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500             | 11940 |
| Fill plug for use in Samsung ML 1630, 1631, SCX 4500                   | 12189 |
| Uni Drum™ with gears for use in Samsung ML 1630, 1631, SCX 4500        | 12203 |
| X-Generation® Doctor blade for use in Samsung ML 1630, 1631, SCX 4500  | 12351 |
| Wiper blade for use in Samsung ML 1630, 1631, SCX 4500                 | 12352 |
| Developer roller for use in Samsung ML 1630, 1631, SCX 4500            | 12733 |
| PCR roller for use in Samsung ML 1630, 1631, SCX 4500                  | 12734 |
| Supply roller for use in Samsung ML 1630, 1631, SCX 4500               | 12735 |
| Developer Roller End Felt for use in Samsung ML 1630, 1631, SCX 4500   | 13009 |
| Toner Adder Roller End Foam for use in Samsung ML 1630, 1631, SCX 4500 | 13010 |
| Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500       | 13868 |
| ASiC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500             | 16364 |
| X-Generation® Wiper blade for use in Samsung ML 1630, 1631, SCX 4500   | 17081 |
| SuMMiT® drum with gears for use in Samsung ML 1630, 1631, SCX 4500     | 18121 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 4600, 4623, SF 650**

|  |       |
|--|-------|
| Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650    | 14073 |
| Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650              | 14074 |
| Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 | 14501 |
| Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650                       | 15119 |
| X-Generation® Wiper blade for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623, SF 650             | 15124 |
| Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650                       | 15127 |
| ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F                   | 16414 |
| Uni Drum™ with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623                          | 16415 |
| SuMMiT™ drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623                       | 16416 |
| ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2580, SCX 4600, 4610, 4623, 650F(MLT-D1052S)             | 16417 |
| ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F                   | 16418 |
| ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2580, SCX 4600, 4610, 4623, 650F                         | 16419 |
| Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650                       | 17270 |
| SuMMiT™ drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623                       | 18108 |
| PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650                | 18759 |
| ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F (MLT-D105L/SEE)   | 20145 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 4824, 4825, 4826, 4828**

Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828 12106

Absolute Black® toner for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 12107

Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828 12109

Developer roller sealing blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 13007

Recovery blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 13008

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(US & AUS) 13858

Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650 14073

Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 14074

Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 14501

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209L)(US & AUS) 15970

Smartchip cover for use in Samsung® ML 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, (MLT-D209) 16453

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D2092L)(Europe) 16731

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(EU) 16732

X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, (MLT-D209) 17078

PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 18759

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 4833, 4835, 5639, 5737, 5739, ML 3310, 3312, 3710 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| X-Generation® toner for use in Samsung ML 4550, 4050, 3710, 3712, 3750, 3312, 3312, SCX 4833, 4835, 5639, 5737, 5739  | 16075 |
| ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5637 (MLT-D205S)(USA)  | 16331 |
| ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 5637 (MLT-D205L)(USA)  | 16332 |
| Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739  | 16333 |
| Uni Drum™ with gears for use in Samsung ML 2950, 2955, 3310, 3312, 3712, 3750, SL-M 2870, 2820, 2670, 2620, SCX 4833, 5737 (MLT-D205)                           | 16334 |
| X-Generation® Wiper blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5737  | 16335 |
| Wiper blade for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5737  | 16335 |
| Doctor blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3820, 4020, 4070, 4072, SCX 4833, 4835, 5737  | 16336 |
| Developer roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3325, 3820, 3825, 4020, 4025, 4030,4035, 4070, 4075, 4080, SCX 4833, 4835, 5737 | 16337 |
| PCR roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3820, 4020, 4030, 4070, 4080, SCX 4833, 4835, 5737                                    | 16338 |
| Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, SCX 4833, 4835, 5737  | 16773 |
| Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739  | 16794 |
| Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5639, 5737, 5739  | 16912 |
| ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5637 (MLT-D205S)(EU)   | 16949 |
| ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5737 (MLT-D205L)(EU)   | 16950 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| ASiC Encrypto Smartchip® for use in Samsung ML 3312, 3710, SCX 4833, 5639, 5739 (MLT-D205S)(EXP)   | 16991 |
| ASiC Encrypto Smartchip® for use in Samsung ML 3312, 3710, 3712, SCX 4833, 5639, 5739 (MLT-D205L)(EXP)   | 16992 |
| SuMMiT® OPC drum w gears for use in Samsung ML 2950, 2955, 3310, 3312, 3712, 3750, SL-M 2870, 2820, 2670, 2620, SCX 4833, 5737 (MLT-D205)                    | 17094 |
| Shipping lock for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5737 (MLT D205)  | 17749 |
| Clear Seal for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3325, 3820,3825, 3870, 4070, 4075, SCX 4833, 4835, 5737                            | 17881 |
| Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739   | 18555 |
| SuMMiT® drum with gears for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 5737 (MLT-D205)  | 18694 |
| Developer Roller Sealing Blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, 3753, SL-M 3320, 3325, 3820, 3825, 3870, 4070, 4075, SCX 4833, 4835, 5737 | 20430 |

**SAMSUNG SCX 4016, 4216, SF 560, 755**

|  |       |
|--|-------|
| Wiper blade for use in Samsung SCX 4016, 4216, SF 560, 755           | 4948  |
| Developer roller for use in Samsung SCX 4016, 4216, SF 560, 755      | 5292  |
| PCR roller for use in Samsung SCX 4016, 4216, SF 560, 755            | 5293  |
| Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560      | 9168  |
| Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560, 755 | 9610  |
| Smartchip™ fuse for use in Samsung SCX 4016, 4216, SF 560, 755       | 10203 |
| SuMMiT™ drum w/gears for use in Samsung SCX 4016, 4216, SF 560, 755  | 12035 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Uni Drum™ with gears for use in Samsung SCX 4016, 4216, SF 560, 755

15207

**SAMSUNG SCX 4100, 4116**

Absolute Black® toner for use in Samsung SCX 4100, 4116

9639

Absolute Black® toner for use in Samsung SCX 4100, 4116

9640

Wiper blade for use in Samsung SCX 4200,4100, 4116

10549

Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116

10550

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

**SAMSUNG SCX 4200**

Absolute Black® toner for use in Samsung SCX 4200

10545

Absolute Black® toner for use in Samsung SCX 4200

10546

Smartchip™ for use in Samsung SCX 4200

10548

Wiper blade for use in Samsung SCX 4200,4100, 4116

10549

Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116

10550

Top cover for use in Samsung SCX 4200

11465

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ for use in Samsung SCX 4200

16120

**SAMSUNG SCX 4300**

Absolute Black® toner for Samsung SCX 4300

13323

PCR roller for use in Samsung SCX 4300

13325

Doctor blade for use in Samsung SCX 4300

13326

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

Absolute Black® toner for use in Samsung SCX 4300

15343

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16412

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16413

**SAMSUNG SCX 4521, 4321**

Absolute Black® toner for use in Samsung SCX 4521, 4321

10438

Absolute Black® toner for use in Samsung SCX 4521, 4321

10439

Wiper blade for use in Samsung SCX 4725, 4521, 4321

10441

Developer roller for use in Samsung SCX 4521, 4321

10443

PCR roller for use in Samsung SCX 4521, 4321

10444

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Supply roller for use in Samsung SCX 4521, 4321

10445

Smartchip™ fuse for use in Samsung SCX 4521, 4321

10446

Uni Drum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321

16113

Doctor blade for use in Samsung SCX 4521, 4321

16818

**SAMSUNG SCX 4720, 4520**

Universal cover top for use in Samsung ML 2250, 2251, 2252, SCX 4720, 4520, Dell 1600

6298

Absolute Black® toner for use in Samsung SCX 4720, 4520

9528

Absolute Black® toner for use in Samsung SCX 4720, 4520

9529

Absolute Black® toner for use in Samsung SCX 4720, 4520

9530

Developer roller for use in Samsung SCX 4720, 4520

9533

PCR roller for use in Samsung SCX 4720, 4520

9534

Wiper blade for use in Samsung SCX 4720, 4520

9535

Doctor blade for use in Samsung SCX 4720, 4520

9536

Smartchip™ for use in Samsung SCX 4720, 4520

9537

SuMMiT™ drum w/gears for use in Samsung SCX 4720, 4520

12036

Smartchip™ for use in Samsung SCX 4720, 4520

12256

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Uni Drum™ with gears for use in Samsung SCX 4720, 4520

15196

Smartchip™ for use in Samsung SCX 4720, 4520

16122

Smartchip™ for use in Samsung SCX 4720, 4520

16125

**SAMSUNG SCX 4725**

Wiper blade for use in Samsung SCX 4725, 4521, 4321

10441

Developer roller for use in Samsung SCX 5530, 5330, 4725

10993

Absolute Black® toner for use in Samsung SCX 4725

11665

Absolute Black® toner for use in Samsung SCX 4725

11666

ASiC Smartchip® for use in Samsung SCX 4725

11667

PCR roller for use in Samsung SCX 4725

11672

SuMMiT™ drum w/gears for use in Samsung SCX 4725

12037

Smartchip™ for use in Samsung SCX 4725

12051

Conversion kit for Samsung ML 1640, 2240, SCX 4725

14425

Uni Drum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321

16113

ASiC Smartchip® for use in Samsung SCX 4725

16277

Doctor blade for use in Samsung SCX 4725

16817

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 5112, 5312, 5315**

|   |       |
|---|-------|
| Smartchip™ drum unit fuse for use in Samsung SCX 5112, 5312, 5315 | 5083  |
| Developer roller for use in Samsung SCX 5112, 5312, 5315          | 5180  |
| Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315     | 5472  |
| Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315     | 8977  |
| Wiper blade for use in Samsung SCX 5112, 5312, 5315               | 8978  |
| Doctor blade for use in Samsung SCX 5112, 5312, 5315              | 8979  |
| SuMMiT™ drum w/gears for use in Samsung SCX 5112, 5312, 5315      | 12038 |

**SAMSUNG SCX 5530, 5330**

|  |       |
|--|-------|
| Absolute Black® toner for use in Samsung SCX 5530, 5330  | 10960 |
| Absolute Black® toner for use in Samsung SCX 5530, 5330  | 10961 |
| ASiC Smartchip® for use in Samsung SCX 5530, 5330        | 10963 |
| Developer roller for use in Samsung SCX 5530, 5330, 4725 | 10993 |
| PCR roller for use in Samsung SCX 5530, 5330             | 10994 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| ASiC Smartchip® for use in Samsung SCX 5530, 5330            | 11946 |
| Absolute Black® toner for use in Samsung SCX 5530, 5330      | 11947 |
| SuMMiT™ drum w/gears for use in Samsung SCX 5530, 5330       | 12039 |
| Uni Drum™ with gears for use in Samsung SCX 5530, 5330       | 15774 |
| ASiC Smartchip® for use in Samsung SCX 5530, 5330            | 16372 |
| ASiC Smartchip® for use in Samsung SCX 5530, 5330            | 16375 |
| X-Generation® Doctor blade for use in Samsung SCX 5530, 5330 | 18086 |
| X-Generation® Wiper blade for use in Samsung SCX 5530, 5330  | 18120 |

**SAMSUNG SCX 5935, 5835, 5635 MFP**

|   |       |
|---|-------|
| Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP   | 13878 |
| Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP   | 13880 |
| SuMMiT™ drum with gears for use in Samsung SCX 5935, 5835, 5635 MFP | 13885 |
| Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP   | 14904 |
| Smartchip™ for use in Samsung SCX 5935 MFP                          | 15741 |
| Wiper blade for use in Samsung SCX 5935, 5835, 5635                 | 15870 |
| Doctor blade for use in Samsung SCX 5935, 5835, 5635                | 18626 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® black toner for use in Samsung SCX 5935, 5835, 5635 MFP

19391

X-Generation® Black toner for use in Samsung SCX 5935, 5835, 5635 MFP

19393

Developer roller for use in Samsung SCX 5935, 5835, 5635

19404

PCR Roller for use in Samsung SCX 5935, 5835, 5635

19406

Uni Drum™ drum with gears for use in Samsung SCX 5935, 5835, 5635 MFP

20295

**SAMSUNG SCX 6320, 6220, 6120, 6520**

Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520

9556

Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520

9557

PCR roller for use in Samsung SCX 6320, 6220, 6120, 6520

9560

Smartchip™ drum unit fuse for use in Samsung SCX 6322, 6320, 6220, 6120, 6520

9866

Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520

9867

Doctor blade for use in Samsung SCX 6320, 6220, 6120, 6520

11553

SuMMiT™ drum with gears for use in Samsung SCX 6320, 6220, 6120, 6520

14937

Developer roller for use in Samsung SCX 6320, 6220, 6120, 6520

15746

Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520

16127

X-Generation® Wiper blade for use in Samsung SCX 6320, 6220, 6120, 6520

17973



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 7128, 7135, 7145**

|   |       |
|---|-------|
| Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145 | 5285  |
| Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145 | 5287  |
| Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145   | 5288  |
| Ecographics toner for use in Samsung SCX 7128, 7135, 7145     | 5289  |
| Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145    | 5924  |
| Ecographics toner for use in Samsung SCX 7128, 7135, 7145     | 16933 |

**SAMSUNG SCX 3200, 3205, ML 1860, 165, 1660**

|  |       |
|--|-------|
| X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200  | 15906 |
| X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200 | 15908 |
| Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200          | 15950 |
| PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200                | 15951 |
| Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200                | 15957 |
| Name plate for use in Samsung ML 1665, 1660, SCX 3205, 3200                      | 15975 |
| SuMMiT™ OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200          | 16014 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200                     | 16105 |
| X-Generation® Doctor blade for use in Samsung ML 1865, 1665, 1660, SCX 3205, 3200                    | 16158 |
| ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1860, 1865, SCX 3200, 3205                      | 16432 |
| ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1865, SCX 3200                      | 16433 |
| ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660,, 1675, 1865, SCX 3200, 3205         | 17246 |
| SuMMiT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200                              | 17418 |
| X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200                     | 17674 |
| ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1865, SCX 3200 (MLT-D104S/SEE)(EXP) | 20144 |

**SAMSUNG SCX 4828, 4826, 4825, 4824**

|   |       |
|---|-------|
| Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828    | 12106 |
| Absolute Black® toner for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828          | 12107 |
| Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828    | 12109 |
| Developer roller sealing blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 | 13007 |
| Recovery blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828                 | 13008 |
| PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 | 13488 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                   | 13858 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650    | 14073 |
| Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650              | 14074 |
| Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 | 14501 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                                  | 15970 |
| Smartchip cover for use in Samsung® ML 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828                              | 16453 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                                  | 16731 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                                  | 16732 |
| X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828               | 17078 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                                  | 17320 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824                                  | 17321 |
| PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650                | 18759 |

**SAMSUNG SCX 4728, 4729 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| ASiC Encrypto Smartchip® for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(US)    | 16790 |
| X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729 | 16913 |
| X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729 | 16914 |
| ASiC Encrypto Smartchip® for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729  | 16986 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

ASiC Encrypto Smartchip® for use in Samsung ML 2955, 2951, 2955, SCX 4728, 4729

16987

ASiC Encrypto Smartchip® for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(EXP)

17280

Developer roller for use in Samsung ML 2950, 2955, SCX 4729, 4728

18889

PCR roller for use in Samsung ML 2950, 2955, 2820, 2620, SCX 4729, 4728

18897

**SAMSUNG SCX 3205, 3200**

X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200

15906

X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15908

Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15950

PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15951

Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15957

SuMMiT™ OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

16014

X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

16105

ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1860, 1865, SCX 3200, 3205 (MLT-D1042S)(EU)

16432

ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1675, 1865, SCX 3200, 3205 (MLT-D104S)(EXP)

17246

SuMMiT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

17418

X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205

17674

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SAMSUNG SCX 7128, 7135, 7145**

|   |       |
|---|-------|
| Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145 | 5285  |
| Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145 | 5287  |
| Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145   | 5288  |
| Ecographics toner for use in Samsung SCX 7128, 7135, 7145     | 5289  |
| Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145    | 5924  |
| Ecographics toner for use in Samsung SCX 7128, 7135, 7145     | 16933 |

**SHARP®****SHARP AL 1000, 2021, 2031, 2041, 2051 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |      |
|--|------|
| Developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 55 lb              | 5620 |
| X-Generation® Wiper blade for use in Sharp AL 1000, 2021, 2031, 2041, 2051     | 6015 |
| Absolute Black® toner for use in Sharp AL 1000, 2021, 2030, 2031, 2041, 2051   | 6031 |
| Absolute Black® developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051     | 6032 |
| Seal shipping cover protector for use in Sharp AL 1000, 2021, 2031, 2041, 2051 | 6532 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Developer for use in Sharp AL 1000  | 6975  |
| Absolute Black® toner for use in Sharp AL 1000, 2021, 2031, 2041, 2051  | 8128  |
| SuMMiT™ drum with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051  | 12708 |
| Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051   | 16098 |
| Uni Drum™ with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051   | 16785 |
| Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051   | 17296 |
| Absolute Black® toner for use in Sharp AL 1000, 2020, 2030, 2030, 2040  | 18631 |
| Upper Fuser roller for use in Sharp AL1000, 1020, 1200, 1220, 1240, 1641, 1651, AR153, 115, 156, 157, 168, 208 (NROLI-11140-FCZZ) | 19474 |

**SHARP AR 650, 800**

|   |       |
|---|-------|
| Developer for use in Sharp AR 650, AR 800 | 14219 |
|---|-------|

**SHARP AR 162, 162s, 163, 164**

|   |       |
|---|-------|
| OPC drum cleaning wiper blade for use in Sharp AR 160, 161, 162, 163, 164, 200, 201, 206, 207, 205, 5015, 5316, 5516, 5520, MX-M 200, 232, AL 1600, 1620, 1640 (SH200BDC) | 5974  |
| Absolute Black® developer for use in Sharp AR 162, 163, 164, 201, 202, 206, 207   | 8281  |
| Smartchip™ w/housing for use in Sharp AR 162,162s, 163, 164, 201, 202, 207 T  | 11384 |
| Smartchip™ w/ housing for use in Sharp AR 162, 162s, 163, 164   | 13832 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

SuMMiT® drum with gears for use in Sharp AR 160, 161, 162, 163, 164, 201, 206, 5015, 5316, M 207, 205, 165, 160 (AR-200DR, 201-DR)

17521

Absolute Black® toner for use in Sharp AR 162, 163, 164, 201, 202, 206, 207

20666

**SHARP AR 450, 350, 280, AR M 280, 450, P 350, 450, DX B 450**

Absolute Black® toner for use in Sharp AR 450, 350, 280

7090

Uni Drum™ OPC with gears for use in Sharp AR-M 280, 450, 350 NT

7436

Absolute Black® toner for use in Sharp AR 450, 350, 280

8817

Absolute Black® developer carrier for use in Sharp AR 450, 350, 280

10954

Smartchip™ for use in Sharp AR 350, 450 T (Europe)

13919

Smartchip™ for use in Sharp AR 350, 450 NT (US, Canada, Mexico)

13949

Absolute Black® toner for use in Sharp DX B 450 P

14356

Smartchip™ for use in Sharp DX B 450 P (DX-B45DTH)

14357

Uni Drum™ with gears for use in Sharp DX B 450 P

14358

SuMMiT® drum with gears for use in Sharp AR 337, 336, 335, 287, 285, 280, 250, M 450, 350, P 450, 350 (AR-451DR)

19290

Upper Fuser Roller for use in Sharp AR M 350, 450 ( NROLT-1313-FCZZ)

19456

**SHARP AR 455 MD**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ for use in Sharp AR 455 T (EU)                    | 13920 |
| Smartchip™ for use in Sharp AR 455 NT, (US, Canada, Mexico)  | 13950 |
| Absolute Black® toner for use in Sharp AR 455 NT/T           | 14209 |
| Absolute Black® developer carrier for use in Sharp AR 455 MD | 14211 |
| Uni Drum™ OPC for use in Sharp AR 455 DR                     | 14212 |
| Absolute Black® developer for use in Sharp AR 455 MD         | 14550 |

**SHARP AR 500, 501, 505, 507**

|  |      |
|--|------|
| Absolute Black® toner for use in Sharp AR 500, 501, 505, 507 | 9093 |
|--|------|

**SHARP AR M 550, 620, 700**

|   |       |
|---|-------|
| Absolute Black® developer for use in Sharp AR 270, 310 ND   | 8820  |
| Absolute Black® toner for use in Sharp AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317          | 9094  |
| Absolute Black® toner for use in Sharp AR 270 NT  | 10194 |
| Uni Drum™ with gears for use in Sharp AR 270 ND   | 10296 |
| Absolute Black® toner for use in Sharp AR M 550, 620, 700   | 15873 |
| Wiper Blade for use in Sharp AR M 700 620, 550, MX M 753, 700, 623, 620, 550 (AR-620BL, CCLEZ0173FC34 ) | 19189 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Sharp AR 270, 310 NT, AR M 208, 236, 237, 257, 276, 277, 317

19473

Uni Drum® with gears for use in Sharp AR M 700, 620, 550, MX M 700, 620, 550

20937

**SHARP AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317**

Absolute Black® developer for use in Sharp AR 270, 310 ND

8820

Absolute Black® toner for use in Sharp AR 270 NT,

10194

Absolute Black® toner for use in Sharp AR 270, 310 NT, AR M 208, 236, 237, 257, 276, 277, 317

19473

**SHARP AR AR-5618D, AR-5623D, MX-M182, MX-M182D, MX-M202D, MX-M232D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ for use in Sharp AR-5618D, AR-5623D, MX-M182, MX-M182D, MX-M202D, MX-M232D

18259

Absolute Black® toner for use in Sharp AR 5623, 5618, MX-M 182, 202, 232(MX235NT)

19032

Lower Fuser pressure roller for use in Sharp AR5516, 5520, ARM257, 317, MX-M160, M200D, M260, M264N, M310(NROLR0156QSAZ)

19648

Absolute Black® toner for use in Sharp AR 5623, 5618, MX-M 182, 202, 232

19877

**SHARP AR020ST, AR5516, 5520**

Smartchip™ for use in Sharp AR020ST, AR5516, 5520 (Asia Pacific)

18262

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SHARP DX B 350 P (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| X-Generation® Black toner for use in Sharp DX B 350 P | 14348 |
| Smartchip™ for use in Sharp DX B 350 P                | 14349 |
| Uni Drum™ with gears for use in Sharp DX B 350 P      | 14350 |
| PCR (recosted) roller for use in Sharp DX B 350 P     | 14352 |
| Clear Seal™ adhesive for use in Sharp DX B 350 P      | 14353 |
| Doctor blade for use in Sharp DX B 350 P              | 14354 |
| Absolute Black® toner for use in Sharp DX B 350 P     | 17809 |

**SHARP FO DC 550, FO 55 ND, 4400, 4450,**

|   |       |
|---|-------|
| Absolute Black® toner for use in Sharp FO 55 ND, 4400, 4450, DC 550     | 10462 |
| Smartchip™ for use in Sharp FO 55 ND, 4400, 4450, DC 550                | 10463 |
| SuMMiT™ drum with gear for use in Sharp FO 55 ND, 4400, 4450, DC 550    | 16591 |
| Absolute Black® developer for use in Sharp FO 55 ND, 4400, 4450, DC 550 | 17387 |
| X-Generation® wiper blade for use in Sharp FO 55 ND, 4400, 4450, DC 550 | 17388 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SHARP FO 2081 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Uni Drum™ F with gears for use in Sharp FO 2081            | 16785 |
| Smartchip™ for use in Sharp FO-2081                        | 17449 |
| Absolute Black® toner for use in Sharp FO-2081             | 17481 |
| Absolute Black® developer for use in Sharp FO-2081 (FO56ND | 17760 |
| SuMMiT™ drum with gears for use in Sharp FO 2081           | 17838 |

**SHARP MX 2300N, 2700N, 3500N, 3501N, 4501 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501   | 13757 |
| Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501   | 13758 |
| Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501    | 13759 |
| Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501 | 13760 |
| Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501  | 13761 |
| Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501    | 13762 |
| Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501 | 13763 |
| Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501  | 13764 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****SHARP MX-M 200, 160, 181, 211, MX-M 200 D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| OPC drum cleaning wiper blade for use in Sharp AR 160, 161, 162, 163, 164, 200, 201, 206, 207, 205, 5015, 5316, 5516, 5520, MX-M 200, 232, AL 1600, 1620, 1640 (SH200BDC) | 5974  |
| Smartchip® toner for use in Sharp MX-M 200 D  | 17583 |
| Absolute Black® toner for use in Sharp MX-M 200 D   | 17668 |
| Absolute Black® developer for use in Sharp MX M 200, 160, 181, 211 (MX-206NT)   | 17700 |
| Uni Drum® with gears for use in Sharp MX M 503, 453, 363, 283 (MX-500NR)  | 19482 |
| Lower Fuser pressure roller for use in Sharp AR5516, 5520, ARM257, 317, MX-M160, M200D, M260, M264N, M310(NROLR0156QSAZ)  | 19648 |
| Smartchip™ toner for use in Sharp MX M 200, 160 (MX-206GT)(EU)  | 20511 |
| Smartchip® toner for use in Sharp MX-B 201, 200 D (MX-20NT)(US)   | 20990 |
| Smartchip® toner for use in Sharp MX-B 201, 200 D (MX-20GT)(EU)   | 20991 |

**SHARP SF 1014**

|  |       |
|--|-------|
| Toner refill bottle for use in Sharp SF 1014 | 11820 |
|--|-------|

**SHARP SF 7300, 7320, 7350, 7370**

|   |       |
|---|-------|
| Refill bottles for use in Sharp SF 7300, 7320, 7350, 7370 | 11839 |
|---|-------|

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****TOSHIBA®****TOSHIBA E STUDIO 205 CP**

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 163, 165, 166, 167, 181, 182, 195, 200, 203, 205, 212, 223, 225, 230, 232, 233, 237, 242, 245, 250, 280, 282, 283 (OD-1600) 8543

Absolute Black® toner for use in Toshiba e Studio 163, 165, 203, 205 (T-1640) 11513

Absolute Black® developer for use in Toshiba e Studio 163, 165, 166, 181, 182, 195, 200, 202, 203, 205, 206, 207, 121, 223, 225, 230, 232, 233, 242, 245, 280, 282, 283, (D2320) 11514

Absolute Black® toner for use in Toshiba e Studio 205 CP 11691

Absolute Cyan™ toner for use in Toshiba e Studio 205 CP 11692

Absolute Magenta™ toner for use in Toshiba e Studio 205 CP 11693

Absolute Yellow™ toner for use in Toshiba e Studio 205 CP 11694

Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205 (T-1640) 11701

Toshiba e Studio CP 220, 205 (see Lexmark C 520, 522, 530, 532, 534) 14066

Uni Drum® with gears for use in Toshiba e-STUDIO 205, 206, 255, 256, 305, 306, 355, 356, 455, 456, 506 (OD4530) 19510

Upper Fuser Roller for use in Toshiba E-Studio 506, 456, 455, 356, 355, 306, 305, 255, 206, 205 (6LH58424000) 19622

**TOSHIBA E STUDIO 12, 15, 120, 150**

Absolute Black® toner for use in Toshiba e Studio 12, 15, 120, 150 11509

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Developer for use in Toshiba e-Studio 12, 15, 120, 150

11510

X-Generation® Wiper blade for use in Toshiba e Studio 12, 15, 120, 150

11512

**TOSHIBA E STUDIO 16, 20, 25, 250**

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 200, 230, 250, 280

8543

Absolute Black® toner for use in Toshiba e Studio 16, 20, 25, 250

8822

**TOSHIBA E STUDIO 161, T 1620**

Absolute Black® toner for use in Toshiba e Studio 161, T 1620

11567

Absolute Black® compatible developer for use in Toshiba e Studio 161, T 1620

11568

Wiper blade for use in Toshiba e Studio 161, T 1620

11570

SuMMiT™ drum with gears for use in Toshiba e Studio 161, T 1620

16382

**TOSHIBA E STUDIO 163, 165, 203, 205, T 1640**

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 163, 165, 166, 167, 181, 182, 195, 200, 203, 205, 212, 223, 225, 230, 232, 233, 237, 242, 245, 250, 280, 282, 283 (OD-1600)

8543

Absolute Black® toner for use in Toshiba e Studio 163, 165, 203, 205, T 1640

11513

Absolute Black® drum unit carrier developer for use in Toshiba e Studio 163, 165, 203, 205

11514

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205, T 1640

11701

**TOSHIBA E STUDIO 168, 208, 258**

Uni Drum™ with gears for use in Toshiba e Studio 168, 208, 258

12673

Wiper blade for use in Toshiba e-studio 168, 208, 258

12669

**TOSHIBA E STUDIO 20 P, 25 P**

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 200, 230, 250, 280

8543

Toshiba e Studio 20 P, 25 P matched system

10579

**TOSHIBA E STUDIO 30 P, 40 P**

Toshiba e Studio 30 P, 40 P matched system

10578

**TOSHIBA E STUDIO 320 P**

Toshiba e Studio 320 P matched system

10577

Toshiba e-Studio 270 P, 300 P (use 13435 Lexamrk E/X 240, 340 Super Universal™ chip)

11699

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****TOSHIBA E STUDIO CP 220, 205**

Toshiba e Studio CP 220, 205 matched system

14066

**TOSHIBA E STUDIO 520, 550, 600, 650, 720, 810, 850**

Uni Drum™ F with gears for use in Toshiba e Studio 520, 550, 600, 650, 720, 810, 850

5161

**TOSHIBA E STUDIO 350, 450**

Wiper blade for use in Toshiba e Studio 28, 35, 45, 350, 450

12583

Upper Fuser Roller for use in Toshiba E-Studio 350, 450

15085

Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458

15086

Absolute Black toner for use in Toshiba e-Studio 350, 352, 353, 450, 452, 453 (T3520)

18503

Paper Pickup Roller kit for use in Toshiba E-Studio 450, 350, 280, 230

19354

Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)

19356

Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000)

19359

SuMMiT® OPC drum with gears for use in Toshiba e Studio 28, 35, 45, 350, 353, 450, 452, 453 (OD-3500)

19511

**TOSHIBA E STUDIO 28, 35, 45, T 3500**



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Black® toner for use in Toshiba e Studio 28, 35, 45, T 3500                                  | 8823  |
| Uni Drum™ F with gears for use in Toshiba e Studio 28, 35, 45, 350, 450                               | 8991  |
| Wiper blade for use in Toshiba e Studio 28, 35, 45, 350, 450  | 12583 |
| Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458 (44202983000)                      | 15086 |
| Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)                  | 19356 |
| Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000)                      | 19359 |
| SuMMiT® OPC drum with gears for use in Toshiba e Studio 28, 35, 45, 350, 353, 450, 452, 453 (OD-3500) | 19511 |

**TOSHIBA E STUDIO 358,458, DP2800,3500,4500**

|  |       |
|--|-------|
| Paper Feed Tire kit for use in Toshiba E-Studio 358,458, DP2800,3500,4500              | 15083 |
| Upper Fuser Roller for use in Toshiba E-Studio 358,458, DP2800,3500,4500 (44299019000) | 15084 |
| Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458 (44202983000)       | 15086 |
| Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)   | 19356 |
| Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000),      | 19359 |

**TOSHIBA E STUDIO 2500C, 3500C, 3510C**

|   |       |
|---|-------|
| Uni Drum® with gears for use in Toshiba e Studio 4520C, 3530C, 3520C, 3510C, 2830C, 2820C, 2330C, 2020C | 19611 |
|---|-------|

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****TOSHIBA E STUDIO 500 P**

Smartchip™ for use in Toshiba e-Studio 500 P

11154

**TOSHIBA E STUDIO 250 CP**

Smartchip for toner cartridge for use in Toshiba e Studio 250 CP

6713

**TOSHIBA E STUDIO 270 P, 300 P**

Toshiba e-Studio 270 P, 300 P Superchip Universal™

11699

**TOSHIBA E STUDIO 170 F**

Absolute Black® toner for use in Toshiba e Studio 170 F

11817

Smartchip™ for use in Toshiba e Studio 170 F

12050

SuMMiT™ drum with gears for use in Toshiba e Studio 170 F

16594

**TOSHIBA E STUDIO 190 P**

Toshiba e Studio 190 P

5659

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****TOSHIBA BD 1340, 1350, 1370**

Wiper blade for use in Toshiba BD 1340, 1350, 1370

12581

**TOSHIBA T 2060, 2860, 2870**

Uni Drum™ F with gears for use in Toshiba T 2060, 2860, 2870

9004

Wiper blade for use in Toshiba T 2060, 2860, 2870

12582

Upper fuser roller for use in Toshiba 3560, 2860, 2060, DP 3580, 2570, 2460 (4409890600)

19785

**XEROX®****XEROX PHASER 7500**

Smartchip™ Black for use in Xerox Phaser 7500

15958

Smartchip™ Cyan for use in Xerox Phaser 7500

15959

Smartchip™ Magenta for use in Xerox Phaser 7500

15960

Smartchip™ Yellow for use in Xerox Phaser 7500

15961

Smartchip™ CMYK drum unit for use in Xerox Phaser 7500

15962

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ Black for use in Xerox Phaser 7500                         | 16680 |
| Smartchip™ Cyan for use in Xerox Phaser 7500                          | 16681 |
| Smartchip™ Magenta for use in Xerox Phaser 7500                       | 16690 |
| Smartchip™ Yellow for use in Xerox Phaser 7500                        | 16691 |
| X-Generation® Glossy Black toner for use in Xerox Phaser 7500         | 17493 |
| X-Generation® Glossy Cyan toner for use in Xerox Phaser 7500          | 17494 |
| X-Generation® Glossy Magenta toner for use in Xerox Phaser 7500       | 17495 |
| X-Generation® Glossy Yellow toner for use in Xerox Phaser 7500        | 17496 |
| X-Generation® drum with gears and insert for use in Xerox Phaser 7500 | 17569 |
| SuMMiT® drum with gears and insert for use in Xerox Phaser 7500       | 17647 |
| Wiper blade for use in Xerox Phaser 7500                              | 19125 |

**XEROX PHASER 6121 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black for use in Xerox Phaser 6121 MFP   | 16189 |
| Smartchip™ Cyan for use in Xerox Phaser 6121 MFP    | 16190 |
| Smartchip™ Magenta for use in Xerox Phaser 6121 MFP | 16191 |
| Smartchip™ Yellow for use in Xerox Phaser 6121 MFP  | 16192 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Xerox Phaser 6121 MFP

17877

Absolute Cyan™ toner for use in Xerox Phaser 6121 MFP

17878

Absolute Magenta™ toner for use in Xerox Phaser 6121 MFP

17879

Absolute Yellow™ toner for use in Xerox Phaser 6121 MFP

17880

Developer roller cover for use in Xerox Phaser 6121 MFP

18289

**XEROX PHASER 6500, WORKCENTRE 6505, 6500**

Smartchip™ Black for use in Xerox Phaser 6500, WC 6505

16546

Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505

16547

Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505

16548

Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505

16549

X-Generation® Black toner for use in Xerox Phaser 6500, WC 6505

16635

X-Generation® Cyan toner for use in Xerox Phaser 6500, WC 6505

16636

X-Generation® Magenta toner for use in Xerox Phaser 6500, WC 6505

16637

X-Generation® Yellow toner for use in Xerox Phaser 6500, WC 6505

16638

Smartchip™ Black for use in Xerox Phaser 6500, WC 6505

17349

Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505

17350

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505

17352

Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505

17353

X-Generation® Black toner for use in Xerox Phaser 6500, WC 6505

18775

X-Generation® Cyan toner for use in Xerox Phaser 6500, WC 6505

18776

X-Generation® Magenta toner for use in Xerox Phaser 6500, WC 6505

18777

X-Generation® Yellow toner for use in Xerox Phaser 6500, WC 6505

18778

**XEROX PHASER 7400**

Absolute Yellow™ toner for use in Xerox Phaser 7400

9439

Uni Drum™ with gears for use in Xerox Phaser 7400

9599

Smartchip™ Black for use in Xerox Phaser 7400

10840

Smartchip™ Cyan for use in Xerox Phaser 7400

10841

Smartchip™ Magenta for use in Xerox Phaser 7400

10842

Smartchip™ Yellow for use in Xerox Phaser 7400

10843

Smartchip™ drum unit fuse for use in Xerox Phaser 7400

10848

Absolute Yellow glossy toner™ for use in Xerox Phaser 7400

13517

Absolute Black® Glossy toner for use in Xerox Phaser 7400

14787

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Absolute Cyan glossy toner® for use in Xerox Phaser 7400        | 14788 |
| Absolute Magenta glossy toner® for use in Xerox Phaser 7400     | 14789 |
| Absolute Yellow glossy toner® for use in Xerox Phaser 7400      | 14790 |
| X-Generation® Black glossy toner for use in Xerox Phaser 7400   | 20277 |
| X-Generation® Cyan glossy toner for use in Xerox Phaser 7400    | 20278 |
| X-Generation® Magenta glossy toner for use in Xerox Phaser 7400 | 20279 |
| X-Generation® Yellow glossy toner for use in Xerox Phaser 7400  | 20280 |
| X-Generation® Black glossy toner for use in Xerox Phaser 7400   | 20281 |
| X-Generation® Cyan glossy toner for use in Xerox Phaser 7400    | 20282 |
| X-Generation® Magenta glossy toner for use in Xerox Phaser 7400 | 20283 |
| X-Generation® Yellow glossy toner for use in Xerox Phaser 7400  | 20284 |

**XEROX PHASER 7760**

|  |       |
|--|-------|
| Absolute Cyan™ toner for use in Xerox Phaser 7760    | 11188 |
| Absolute Magenta™ toner for use in Xerox Phaser 7760 | 11189 |
| Absolute Yellow™ toner for use in Xerox Phaser 7760  | 11190 |
| Smartchip™ Black toner for use in Xerox Phaser 7760  | 11271 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Smartchip™ Cyan toner for use in Xerox Phaser 7760                             | 11272 |
| Smartchip™ Magenta toner for use in Xerox Phaser 7760                          | 11273 |
| Smartchip™ Yellow toner for use in Xerox Phaser 7760                           | 11274 |
| Uni Drum™ drum gearless for use in Xerox Phaser 7760                           | 11887 |
| Smartchip™ Black, Cyan, Magenta, Yellow drum unit for use in Xerox Phaser 7760 | 11920 |
| PCR roller for use in Xerox Phaser 7760  | 14124 |
| Wiper blade for use in Xerox Phaser 7760                                       | 14309 |
| Absolute Black® toner for use in Xerox Phaser 7760                             | 14881 |
| Absolute Cyan® toner for use in Xerox Phaser 7760                              | 14882 |
| Absolute Magenta® toner for use in Xerox Phaser 7760                           | 14883 |
| Absolute Yellow® toner for use in Xerox Phaser 7760                            | 14884 |
| Absolute Color® KCMY Carrier for use in Xerox Phaser 7760                      | 14885 |
| Absolute Black® toner for use in Xerox Phaser 7760                             | 14886 |
| ABsolute Cyan® toner for use in Xerox Phaser 7760                              | 14887 |
| Absolute Magenta® toner for use in Xerox Phaser 7760                           | 14888 |
| Absolute Yellow® toner for use in Xerox Phaser 7760                            | 14889 |
| X-Generation® drum gearless with insert for use in Xerox Phaser 7760           | 17559 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Black toner for use in Xerox Phaser 7760

17595

X-Generation® Cyan toner for use in Xerox Phaser 7760

17596

X-Generation® Magenta toner for use in Xerox Phaser 7760

17598

X-Generation® Yellow toner for use in Xerox Phaser 7760

17599

**XEROX PHASER 6700**

Absolute Black® toner for use in Xerox Phaser 6700

17272

Absolute Cyan® toner for use in Xerox Phaser 6700

17273

Absolute Magenta® toner for use in Xerox Phaser 6700

17274

Absolute Yellow® toner for use in Xerox Phaser 6700

17275

Smartchip® Black for use in Xerox Phaser 6700

17313

Smartchip® Cyan for use in Xerox Phaser 6700

17314

Smartchip® Magenta for use in Xerox Phaser 6700

17315

Smartchip® Yellow for use in Xerox Phaser 6700

17316

Smartchip™ Black drum unit for use in Xerox Phaser 6700

18175

Smartchip™ Cyan drum unit for use in Xerox Phaser 6700

18176

Smartchip™ Magenta drum unit for use in Xerox Phaser 6700

18177

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip™ Yellow drum unit for use in Xerox Phaser 6700

18178

Absolute Black® toner for use in Xerox Phaser 6700

18674

Absolute Cyan® toner for use in Xerox Phaser 6700

18675

Absolute Magenta® toner for use in Xerox Phaser 6700

18676

Absolute Yellow® toner for use in Xerox Phaser 6700

18677

X-Generation® Black toner for use in Xerox Phaser 6700

18879

X-Generation® Cyan toner for use in Xerox Phaser 6700

18880

X-Generation® Magenta toner for use in Xerox Phaser 6700

18881

X-Generation® Yellow toner for use in Xerox Phaser 6700

18882

SuMMiT® drum gearless for use in Xerox Phaser 6700

18961

X-Generation® Black toner for use in Xerox Phaser 6700

20404

X-Generation® Cyan toner for use in Xerox Phaser 6700

20405

X-Generation® Magenta toner for use in Xerox Phaser 6700

20406

X-Generation® Yellow toner for use in Xerox Phaser 6700

20407

**XEROX PHASER 7700**

Absolute Magenta™ toner for use in Xerox Phaser 7700

9402

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Yellow™ toner for use in Xerox Phaser 7700

9403

Absolute Black® toner for use in Xerox Phaser 7700

9444

Absolute Cyan™ toner for use in Xerox Phaser 7700

9445

Absolute Magenta™ toner for use in Xerox Phaser 7700

9446

Absolute Yellow™ toner for use in Xerox Phaser 7700

9447

Uni Drum™ gearless for use in Xerox Phaser 7700, C 2220

9988

Recovery blade for use in Xerox Phaser 7700, C 2220

10900

PCR roller for use in Xerox Phaser 7750, 7700, C 2220

10948

Absolute Black® toner for use in Xerox Phaser 7700

11195

Absolute Cyan™ toner for use in Xerox Phaser 7700

11196

Wiper blade for use in Xerox Phaser 7700

12185

**XEROX PHASER 7750**

Recovery blade for use in Xerox Phaser 7700, C 2220, 7750

10900

PCR roller for use in Xerox Phaser 7750, 7700, C 2220

10948

Absolute Black® toner for use in Xerox Phaser 7750

11183

Absolute Cyan™ toner for use in Xerox Phaser 7750

11184

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ toner for use in Xerox Phaser 7750

11185

Absolute Yellow™ toner for use in Xerox Phaser 7750

11186

Wiper blade for use in Xerox Phaser 7750, C 2220

11464

Uni Drum™ gearless for use in Xerox Phaser 7750

11922

**XEROX PHASER 7800**

Smartchip® Black for use in Xerox Phaser 7800

17681

Smartchip® Cyan for use in Xerox Phaser 7800

17682

Smartchip® Magenta for use in Xerox Phaser 7800

17683

Smartchip® Yellow for use in Xerox Phaser 7800

17684

Smartchip™ CMYK drum unit for use in Xerox Phaser 7800

17693

Uni Drum® with gears and insert for use in Xerox Phaser 7800

17698

SuMMiT® drum with gears and insert for use in Xerox Phaser 7800

17699

Smartchip® Black for use in Xerox Phaser 7800

18179

Smartchip® Cyan for use in Xerox Phaser 7800

18180

Smartchip® Magenta for use in Xerox Phaser 7800

18181

Smartchip® Yellow for use in Xerox Phaser 7800

18182

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Xerox Phaser 7800

19442

Absolute Cyan® toner for use in Xerox Phaser 7800

19443

Absolute Magenta® toner for use in Xerox Phaser 7800

19444

Absolute Yellow® toner for use in Xerox Phaser 7800

19445

Soft PCR roller for use in Xerox Phaser 7800

19558

Hard PCR roller for use in Xerox Phaser 7800

19593

Wiper blade for use in Xerox Phaser 7800

19613

**XEROX PHASER 3320, WORKCENTRE 3315, 3325**

Smartchip® for use in Xerox Phaser 3320

17657

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17658

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17659

Developer roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17660

Doctor blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17661

PCR roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17662

SuMMit® drum with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17663

Uni Drum® with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17664

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

X-Generation® Wiper blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17665

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17669

Shipping lock for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17750

Clear Seal for use in Xerox Phaser 3320, WC 3315, 3325

17897

SuMMiT® drum with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

18896

Smartchip® for use in Xerox Phaser 3320 (106R02306)(Eastern Europe and S. America)

18965

Smartchip® for use in Xerox Phaser 3320, WorkCentre 3325, 3315

19284

**XEROX PHASER 6000, 6010, WORKCENTRE 6015, DP CP 105, 205, CM 205, Dell 1250, 1355**

Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015

16607

Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015

16608

Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015

16609

Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015

16610

Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355

16808

Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355

16809

Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015

17355

Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015

17356

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015  | 17357 |
| Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015   | 17358 |
| Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP105, 205, CM 205, Dell 1250, 1355 | 17802 |
| Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP105, 205, CM 205, Dell 1250, 1355  | 17803 |
| Absolute Black® toner for use in Xerox Phaser 6600, WC 6605   | 18323 |
| Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605  | 18324 |
| Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605   | 18325 |
| Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605  | 18326 |
| Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (WW)   | 18327 |
| Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (WW)  | 18328 |
| Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (WW)   | 18329 |
| Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (WW)  | 18330 |
| Absolute Black® toner for use in Xerox Phaser 6600, WC 6605   | 18779 |
| Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605  | 18780 |
| Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605   | 18781 |
| Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605  | 18782 |
| Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (106R02232)(EU)                                      | 19142 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (106R02229)(EU)                               | 19143 |
| Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (106R02230)(EU)                            | 19144 |
| Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (106R02231)(EU)                             | 19145 |
| PCR roller for use in Xerox Phaser 6600, WorkCentre 6605  | 19550 |
| Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (106R02236)(E.Europe, S.Africa, L.America)   | 19605 |
| Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (106R02233)(E.Europe, S.Africa, L.America)    | 19606 |
| Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (106R02234)(E.Europe, S.Africa, L.America) | 19607 |
| Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (106R02235)(E.Europe, S.Africa, L.America)  | 19608 |

**XEROX PHASER 3040, 3010, WORKCENTRE 3045 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 | 17489 |
| Smartchip® toner for use in Xerox Phaser 3040, WorkCentre 3045            | 17490 |
| Smartchip® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045      | 17491 |
| Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 | 17492 |
| Smartchip® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045      | 17696 |
| Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 | 17771 |
| Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 | 18246 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX WORKCENTRE 5020, 5016 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Smartchip™ drum unit for use in Xerox Workcentre 5020, 5016    | 16963 |
| Absolute Black® toner for use in Xerox Workcentre 5020, 5016   | 16965 |
| SuMMiT™ drum with gears for use in Xerox Workcentre 5020, 5016 | 16966 |
| Wiper blade for use in Xerox WorkCentre 5020, 5016             | 16967 |
| Absolute Black® toner for use in Xerox Workcentre 5020, 5016   | 19023 |

**XEROX WORKCENTRE 4118, FAXCENTRE 2218**

|  |       |
|--|-------|
| X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218 | 5341  |
| X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218 | 9509  |
| Doctor blade for use in Xerox WorkCentre 4118, FaxCentre 2218                    | 10873 |
| Smartchip™ drum unit fuse for use in Xerox WorkCentre 4118, FaxCentre 2218       | 11589 |
| SuMMiT™ Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218         | 15198 |
| Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218                | 15748 |
| Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218                      | 16128 |
| X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218       | 18045 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX WORKCENTRE 5222, 5225, 5230 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® developer for use in Xerox XC 5210, 5220, 5222 (6R333) | 5335  |
| Absolute Black® toner for use in Xerox XC 5210, 5220, 5222 (6R333)     | 5337  |
| Uni Drum™ OPC with gears for use in Xerox WorkCentre 5222, 5225, 5230  | 14107 |
| Doctor blade for use in Xerox WorkCentre 5222, 5225, 5230              | 14108 |
| Smartchip™ drum unit for use in Xerox WorkCentre 5222, 5225, 5230      | 14109 |
| Absolute Black® toner for use in Xerox WorkCentre 5222, 5225,5230      | 15889 |
| Absolute Black® toner for use in Xerox WorkCentre 5222, 5225, 5230     | 15890 |
| Developer for drum unit for use in Xerox WorkCentre 5222, 5225,5230    | 15891 |
| Seal for developer unit for use in Xerox WorkCentre 5222, 5225,5230    | 15893 |
| Uni Drum™ with gears for use in Xerox WorkCentre 5222, 5225,5230       | 15894 |
| Wiper blade for use in Xerox WorkCentre 5222, 5225,5230                | 15896 |
| Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230          | 15897 |
| Smartchip™ drum for use in Xerox WorkCentre 5222, 5225,5230            | 15898 |
| Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230          | 16531 |
| SuMMit® drum with gears for use in Xerox WorkCentre 5222, 5225, 5230   | 17013 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Smartchip® toner for use in Xerox WorkCentre 5222, 5225, 5230 (106R01304)

18641

**XEROX WORKCENTRE 4150**

Absolute Black® toner for use in Xerox WorkCentre 4150

11554

Absolute Black® toner for use in Xerox WorkCentre 4150

11555

Smartchip™ toner cartridge for use in Xerox WorkCentre 4150

11556

Doctor blade for use in Xerox WorkCentre 4150

11557

Wiper blade for use in Xerox WorkCentre 4150

11559

Developer roller for use in Xerox WorkCentre 4150

11560

PCR roller for use in Xerox WorkCentre 4150

11561

Absolute Black® developer carrier for drum unit for use in Xerox WorkCentre 4150

11643

Smartchip™ drum unit for use in Xerox WorkCentre 4150

11644

Smartchip™ toner cartridge for use in Xerox WorkCentre 4150

14452

**XEROX WORKCENTRE 4260, 4250 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ with connector for use in Xerox Workcentre 4250, 4260

15605

TEXT grade toner for use in Xerox Workcentre 4260, 4250

16073

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|  |       |
|--|-------|
| Absolute Black® toner for use in Xerox Workcentre 4260, 4250           | 17538 |
| Absolute Black® toner developer for use in Xerox Workcentre 4260, 4250 | 17572 |
| Smartchip™ drum unit for use in Xerox WorkCentre 4250, 4260            | 17642 |
| Uni Drum® OPC with gears for use in Xerox WorkCentre 4250, 4260        | 17833 |

**XEROX WORKCENTRE 7120, 7125 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Absolute Black® toner for use in Xerox Workcentre 7120, 7125    | 17539 |
| Absolute Cyan® toner for use in Xerox Workcentre 7120, 7125     | 17540 |
| Absolute Magenta® toner for use in Xerox Workcentre 7120, 7125  | 17541 |
| Absolute Yellow® toner for use in Xerox Workcentre 7120, 7125   | 17542 |
| Smartchip® Black toner for use in Xerox Workcentre 7120, 7125   | 17543 |
| Smartchip® Cyan toner for use in Xerox Workcentre 7120, 7125    | 17544 |
| Smartchip® Magenta toner for use in Xerox Workcentre 7120, 7125 | 17545 |
| Smartchip® Yellow toner for use in Xerox Workcentre 7120, 7125  | 17546 |
| Smartchip® Black toner for use in Xerox Workcentre 7120, 7125   | 18184 |
| Smartchip® Cyan toner for use in Xerox Workcentre 7120, 7125    | 18185 |
| Smartchip® Magenta toner for use in Xerox Workcentre 7120, 7125 | 18186 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip® Yellow toner for use in Xerox Workcentre 7120, 7125          | 18187 |
| Smartchip® Black drum unit for use in Xerox Workcentre 7120, 7125       | 18188 |
| Smartchip® Cyan drum unit for use in Xerox Workcentre 7120, 7125        | 18189 |
| Smartchip® Magenta drum unit for use in Xerox Workcentre 7120, 7125     | 18190 |
| Smartchip® Yellow drum unit for use in Xerox Workcentre 7120, 7125      | 18191 |
| Uni Drum® with gears for use in Xerox WorkCentre 7125, 7120, 7220, 7225 | 19268 |
| Wiper blade for use in Xerox WorkCentre 7125, 7120                      | 19392 |

**XEROX WORKCENTRE 7525, 7530, 7535, 7545, 7556 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|   |       |
|---|-------|
| Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556   | 17056 |
| Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556    | 17057 |
| Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 | 17058 |
| Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556  | 17059 |
| Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556   | 17060 |
| Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556    | 17061 |
| Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 | 17062 |
| Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556  | 17063 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ CMYK drum unit for use in Xerox WC 7525, 7530, 7535, 7540, 7545, 7556  | 17558 |
| SuMMiT® drum with gears for use in Xerox Work Centre 7425, 7428, 7435, 7525, 7530, 7535, 7545, 7556, 7830, 7835, 7845, 7855 | 17646 |
| X-Generation® Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556  | 20844 |
| X-Generation® Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556   | 20845 |
| X-Generation® Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556  | 20846 |
| X-Generation® Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556   | 20847 |

**XEROX WORKCENTRE 7425, 7428, 7435 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

|  |       |
|--|-------|
| Absolute Black® toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128  | 10956 |
| Absolute Yellow™ toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 | 10959 |
| Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435                                | 17048 |
| Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435                                 | 17049 |
| Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435                              | 17050 |
| Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435                               | 17051 |
| Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435                                | 17052 |
| Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435                                 | 17053 |
| Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435                              | 17054 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

|   |       |
|---|-------|
| Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435  | 17055 |
| X-Generation® Black toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128                       | 17127 |
| X-Generation® Cyan toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128                        | 17128 |
| X-Generation® Magenta toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128                     | 17129 |
| X-Generation® Yellow toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128                      | 17130 |
| X-Generation® Black toner for use in Xerox Work Centre 7425, 7428, 7435   | 17131 |
| X-Generation® Cyan toner for use in Xerox Work Centre 7425, 7428, 7435  | 17132 |
| X-Generation® Magenta toner for use in Xerox Work Centre 7425, 7428, 7435   | 17133 |
| X-Generation® Yellow toner for use in Xerox Work Centre 7425, 7428, 7435  | 17134 |
| X-Generation® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435                                      | 17601 |
| Smartchip™ CMYK drum unit for use in Xerox WorkCentre 7435, 7428, 7425  | 17613 |
| SuMMiT® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435  | 17646 |
| SuMMiT® drum with gears for use in Xerox Work Centre 7425, 7428, 7435, 7525, 7530, 7535, 7545, 7556, 7830, 7835, 7845, 7855 | 17646 |
| Wiper blade for use in Xerox WorkCentre C 7425, 7428, 7435  | 18302 |
| Uni Drum™ gearless for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228                               | 19952 |
| Recovery blade for use in Xerox WorkCentre C 7425, 7428, 7435, 7830, 7835, 7845, 7855                                       | 20111 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX WORKCENTRE PRO C 7346, 7345, 7336, 7328, 3545, 2636, 2128**

|   |       |
|---|-------|
| Absolute Black® toner for use in Xerox WorkCentre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128        | 10956 |
| Absolute Yellow™ toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128      | 10959 |
| Smartchip™ drum for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228              | 19176 |
| Uni Drum™ gearless for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228           | 19952 |
| X-Generation® Black toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128   | 17127 |
| X-Generation® Cyan toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128    | 17128 |
| X-Generation® Magenta toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 | 17129 |
| X-Generation® Yellow toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128  | 17130 |

**XEROX WORKCENTRE PRO C 32, 40**

|   |       |
|---|-------|
| Absolute Black® toner for use in Xerox WorkCentre Pro C 32, 40  | 9813  |
| Absolute Cyan™ toner for use in Xerox WorkCentre Pro C 32, 40   | 9814  |
| Absolute Magenta™ toner for use in Xerox WorkCentre Pro C 32    | 9815  |
| Absolute Yellow™ toner for use in Xerox WorkCentre Pro C 32, 40 | 9816  |
| Uni Drum™ gearless for use in Xerox WorkCentre Pro C 32, 40     | 11886 |



**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX WORKCENTRE PRO C 320, 315**

|   |       |
|---|-------|
| GEAR set for drum for use in Xerox WC Pro 320, 315                      | 5851  |
| Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315          | 8329  |
| Wiper blade for use in Xerox WorkCentre Pro 320, 315                    | 8526  |
| Mag roller sleeve for use in Xerox WorkCentre Pro 320, 315              | 8527  |
| Doctor blade for use in Xerox WorkCentre Pro 320, 315                   | 9257  |
| Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315          | 9260  |
| SuMMiT™ drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315 | 12361 |
| X-Generation® Wiper blade for use in Xerox WorkCentre Pro 320, 315      | 17997 |

**XEROX WORKCENTRE PRO C 420, 415**

|  |      |
|--|------|
| Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415 | 8901 |
| Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415 | 8902 |
| Wiper blade for use in Xerox WorkCentre Pro 420, 415           | 8911 |
| Mag roller sleeve for use in Xerox WorkCentre Pro 420, 415     | 8914 |
| Doctor blade for use in Xerox WorkCentre Pro 420, 415          | 9256 |
| Smartchip™ for use in Xerox WorkCentre Pro 420, 415            | 9872 |

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

SuMMiT™ drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315

12361

**XEROX DOCUPRINT C 3210, 2100**

Toner fill hole plastic seal for use in Xerox DocuPrint C 3210, 2100

8300

Absolute Cyan™ toner for use in Xerox DocuPrint C 3210, 2100

11202

Absolute Magenta™ toner (6,000 pages) for use in Xerox DocuPrint C 3210, 2100

11203

Absolute Yellow™ toner for use in Xerox DocuPrint C 3210, 2100

11204

Uni Drum™ with gears for use in Xerox DocuPrint C 3210, 2100

11206

Wiper blade for use in Xerox DocuPrint C 3210, 2100

11207

Smartchip™ Black for use in Xerox DocuPrint C 3210, 2100

11208

Drum cover for use in Xerox DocuPrint C 3210, 2100

11242

Absolute Black® toner developer for use in Xerox DocuPrint C 3210, 2100

13559

Absolute Cyan™ toner developer for use in Xerox DocuPrint C 3210, 2100

13560

Absolute Magenta™ toner developer for use in Xerox DocuPrint C 3210, 2100

13564

Absolute Yellow™ toner developer for use in Xerox DocuPrint C 3210, 2100

13584

Absolute Black® toner for use in Xerox DocuPrint C 3210, 2100

14861

Absolute Cyan® toner for use in Xerox DocuPrint C 3210, 2100

14862

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta® toner for use in Xerox DocuPrint C 3210, 2100

14863

Absolute Yellow® toner for use in Xerox DocuPrint C 3210, 2100

14864

Black, Cyan, Magenta, Yellow carrier®

14865

**XEROX DOCUPRINT C 3290 SF**

Absolute Black® toner for use in Xerox Docuprint C 3290 SF

13955

Absolute Cyan™ toner for use in Xerox Docuprint C 3290 SF

13956

Absolute Magenta™ toner for use in Xerox Docuprint C 3290 SF

13957

Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF

13958

Absolute Black® toner developer for use in Xerox Docuprint C 3290 SF

13965

Absolute Cyan™ toner developer for use in Xerox Docuprint C 3290 SF

13966

Absolute Magenta™ toner developer for use in Xerox Docuprint C 3290 SF

13967

Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF

13968

Drum cover for use in Xerox Docuprint C 3290 SF

13969

Unidrum™ with gears for use in Xerox Docuprint C 3290 SF

16498

**XEROX DOCUPRINT 220, 230, 240, 332, 340, 425, 440, DC 220, 230, 420**

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

5271

OPC Drum with gears for use in Xerox DC 220, 230

5639

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00484

5773

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00313

5782

PCR roller for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

5909

Doctor blade for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

7011

Xerox DC 220, 230, 420, Smartchip™ w/housing

8170

Smartchip™ with housing for use in Xerox DC 220, 230, 420

8171

Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

8508

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

8768

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00318

8769

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

9103

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

9104

**XEROX DOCUPRINT 2050**

Absolute Black® toner for use in Xerox DocuPrint 2050

11290

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX WORKCENTRE 4118, FAXCENTRE 2218**

X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218

5341

X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218

9509

SuMMiT™ Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218

15198

Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218

15748

Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218

16128

X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218

18045

X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218

18045

**XEROX FAXCENTRE F 116, 1012**

Absolute Black® toner for use in Xerox FaxCentre F 116, 1012

9811

Absolute Black® toner for use in Xerox FaxCentre F 116, 1012

16128

SuMMiT™ drum with gears for use in Xerox FaxCentre F 116, 1020

16600

**XEROX DOCUCENTRE C 450, 400, 320**

Absolute Black® toner for use in Xerox Document Centre C 250, 360, 450

10031

Absolute Cyan™ toner for use in Xerox Document Centre C 250, 360, 450

10032

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ toner for use in Xerox Document Centre C 250, 360, 450

10033

Absolute Yellow™ toner for use in Xerox Document Centre C 250, 360, 450

10034

Upper heat roller for use in Xerox Docucentre 450, 400, 320

16244

**XEROX DOCUCENTRE 6550, 5540**

Upper heat roller for use in Xerox Docucentre 6550, 5540

16242

Wiper blade for use in Xerox DC C 7780, 7600, 7550, 7500, 6680, 6550, 6500, 5580, 5540, 5500, 5400, 5065 Black drum unit

19232

Wiper blade for use in Xerox DC C 7780, 7600, 7550, 7500, 6680, 6550, 6500, 5580, 5540, 5500, 5400, 5065 CMY drum unit

19337

**XEROX DOCUCOLOR C 3535, 2240, 1632**

Absolute Black® toner for use in Xerox DocuColor C 3535, 2240, 1632

9709

Absolute Cyan™ toner for use in Xerox DocuColor C 3535, 2240, 1632

9710

Absolute Magenta™ toner for use Xerox DocuColor C 3535, 2240, 1632

9711

Absolute Yellow™ toner for use in Xerox DocuColor C 3535, 2240, 1632

9712

Uni Drum™ gearless for use in Xerox DocuColor C 3535, 2240, 1632

11884

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #****XEROX DOCUCOLOR 12, 1256, 50**

Absolute Black® toner for use in Xerox Docucolor 12, 1256, 50

8333

Universal toner carrier for use in Xerox Docucolor 12, 1256, 50

9088

Absolute Magenta™ toner for use in Xerox Docucolor 12, 1256, 50

9090

Absolute Yellow™ toner for use in Xerox Docucolor 12, 1256, 50

9091

Universal toner carrier K/C/M/Y carrier for use in Xerox Docucolor 12, 1256, 50

10652

**XEROX DOCUCOLOR 2045, 2060, 5252, 6060**

Universal toner carrier K/C/M/Y for use in Xerox Docucolor 2045, 2060, 5252, 6060

8299

Absolute Black® toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8337

Absolute Cyan™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8338

Absolute Magenta™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8339

Absolute Yellow™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8340

**XEROX DOCUCOLOR 4 LP**

Absolute Black® toner for use in Xerox Docucolor 4 LP

8043

Absolute Cyan™ toner for use in Xerox Docucolor 4 LP

8044

**COPIER SUPPLIES & PARTS - ENGINE MODEL****UNINET PART #**

Absolute Magenta™ toner for use in Xerox Docucolor 4 LP

8046

Absolute Yellow™ toner for use in Xerox Docucolor 4 LP

8045

Universal toner carrier for use in Xerox Docucolor 4 LP

9057

**XEROX 5318, 5320**

Absolute Black® toner for use in Xerox 5318, 5320

782

Smartchip™ reset fuse for use in Xerox 5318, 5320, 5322

5892

**XEROX 5614, 5114, 5113**

Absolute Black® toner for use in Xerox 5614, 5114, 5113

7472

Smartchip™ for use in Xerox 5614, 5114, 5113

7725

Smartchip™ for use in Xerox 5614, 5114, 5113

7726

**XEROX XC 5210, 5220, 5222**

Absolute Black® developer for use in Xerox XC 5210, 5220, 5222

5335

Absolute Black® toner for use in Xerox XC 5210, 5220, 5222

5337



**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS****BROTHER®**

Replacement toner cartridge for use in Brother TN 460, 6600

TN 460

5021

Replacement toner cartridge for use in Brother HL 1650

TN 560

11037

Replacement toner cartridge for use in Brother HL 5250, 5270, TN 580, 550, 3170, 3130, 3185, 3145

TN 650, 580

11050

Replacement toner cartridge for use in Brother HL 5140, 5150, 5170, TN 570, 540, 3030, 3060

TN 570

11059

Replacement toner cartridge for use in Brother HL 2040, 2050, 2070

TN 350, 2000, 2025

11239

Replacement toner cartridge for use in Brother HL 5340, 5350, 5370, 5380, MFC 8480

TN 650, 3280, 3290

15029

Replacement toner cartridge for use in Brother HL 2140, 2150, 2170,

TN 360, 2150, 2120

16810

Replacement toner cartridge for use in Brother HL 2240, 2242, 2250, 2270

TN 450, 420, 2220, 2250

16811

Replacement toner cartridge for use in Brother HL 1650, 1670, 1870, 5040, 5050, 5070

TN 7600, 7300

16812

Replacement toner cartridge for use in Brother HL 5470, 5450, 5440

TN 750

18483

Replacement toner cartridge for use in Brother HL 1110, 1111, 1112, 1118

TN 1040, 1050, 1060, 1070

19296

Replacement toner cartridge for use in Brother HL L 2380, 2360, 2340, 2320, 2305 2300, DCP-L 2540, 2520,  
MFC L 2740, 2720, 2700

TN 660

20035

Replacement toner cartridge for use in Brother HL 1110, 1111, 1112, 1118

TN 1000, 1010, 1020, 1030,

20076

Replacement Black toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970,  
9960, 9560, 9465, 9460

TN315, 318, 328, 348BK

20317

Replacement Cyan toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970,  
9960, 9560, 9465, 9460

TN315, 325, 345C

20318

Replacement Magenta toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC  
9970, 9960, 9560, 9465, 9460

TN315, 325, 345M

20319

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>   | <b>OEM #</b>                           | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--|----------------------|--------------------------------|
| Replacement Yellow toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970, TN315, 325, 345Y 9960, 9560, 9465, 9460 |  | 20320                |                                |
| Replacement Black toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, TN-210K 9010                           |  | 20321                |                                |
| Replacement Cyan toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, TN-210C 9010                            |  | 20322                |                                |
| Replacement Magenta toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, 9010                                 | TN-210M                                | 20323                |                                |
| Replacement Yellow toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, 9010                                  | TN-210Y                                | 20324                |                                |
| Replacement toner cartridge for use in Brother HL 6180, MFC 8950, DCP 8250   | TN 780                                 | 20349                |                                |
| Replacement Black toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850                                     | TN-900, 369, 359, 349, 339, 329, 319BK | 20554                |                                |
| Replacement Cyan toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850                                      | TN-900, 369, 359, 349, 339, 329, 319C  | 20555                |                                |
| Replacement Magenta toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850                                   | TN-900, 369, 359, 349, 339, 329, 319M  | 20556                |                                |
| Replacement Yellow toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850                                    | TN-900, 369, 359, 349, 339, 329, 319Y  | 20557                |                                |
| <b>Drum Unit</b>   |  |                      |                                |
| Replacement drum unit cartridge for use in Brother HL 2040, 2050, 2070, DR 350, 2000, 2025,  | DR 350                                 | 16751                |                                |
| Replacement drum unit cartridge for use in Brother HL 2140, 2150, 2170, DR 360, 2100, 2125,  | DR 360                                 | 16752                |                                |
| Replacement drum unit cartridge for use in Brother HL 5240, 5250, 5270, DR 550, 520, 3100, 3115,   | DR 620                                 | 16753                |                                |
| Replacement drum unit cartridge for use in Brother HL 5340, 5350, 5370, DR 650, 620, 3200, 3215  | DR 620                                 | 16754                |                                |
| Replacement drum unit cartridge for Brother DR 450, 420, 2200, 2225, HL 2130, 2132, 2230, 2240, 2242, 2250, 2270                                   | DR 450                                 | 16756                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>  | <b>OEM #</b>      | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|-------------------|----------------------|--------------------------------|
| Replacement drum unit cartridge for use in Brother DR 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110                                | DR 720            | 18484                |                                |
| Replacement drum unit cartridge for use in Brother DR 1000, 1020, 1035, 1050, 1060, 1070, HL 1110, 1111, 1112, 1118                     | DR 1000           | 19295                |                                |
| Replacement drum unit cartridge for use in Brother DR-630, 2320, HL-L 2380, 2360, 2340, 2300, DCP-L 2540, MFC L 2740, 2720, 2700        | DR 630            | 20702                |                                |
| Replacement drum cartridge for use in Brother DR 720, HL 6180, 5470, 5450, 5440, MFC 8950, 8910, 8810, 8710, 8510, DCP 8155, 8150, 8110 | DR 720            | 20549                |                                |
| <b>CANON®</b>   |                   |                      |                                |
| Replacement black toner cartridge for use in Canon NP 1010, 1020  | F41-6601-000      | 101                  |                                |
| Replacement black toner cartridge for use in Canon NP 6080, 6150, 6080,6550, 6650, 7000, 7050, 8070, 8530, 8570                         | F41-9502-740      | 107                  |                                |
| Replacement black toner cartridge for use in Canon IR 1600, 2000, 2010  | GPR8              | 213                  |                                |
| Replacement black toner cartridge for use in Canon NP 1215, 2020, 2120  | NPG1              | 457                  |                                |
| Replacement toner cartridge for use in Canon NP 4050, 4080, 4145, C 400   | NPG 4/1375A004AA  | 5274                 |                                |
| Replacement toner cartridge for use in Canon NP 3030, 3050, C 300   | NPG 5             | 5275                 |                                |
| Replacement black toner cartridge for use in Canon IR 1210, 1230, 1270, 1300, 1310, 1330, 1370, 1510, 1530, 1570 1630, 1670             | GPR 10            | 5613                 |                                |
| Replacement black toner cartridge for use in Canon NP 6030, 6025, 6330  | NPG 7 /1377A002AA | 5824                 |                                |
| Replacement toner cartridge for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130  | NPG 11            | 6354                 |                                |
| Replacement toner cartridge for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130  | NPG 11            | 6354                 |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                   | <b>OEM #</b>                | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|-----------------------------|----------------------|--------------------------------|
| Replacement black toner cartridge for use in Canon NP 6050                         | NPG 10                      | 6973                 |                                |
| Replacement black toner cartridge for use in Canon IR 2200, 2220, 2800, 3300, 3320 | GPR-6 /6647A003A/AA         | 7068                 |                                |
| Replacement black toner cartridge for use in Canon GP 40                           | F42-3201-700                | 7179                 |                                |
| Replacement black toner cartridge for use in Canon NP 4335, 4835                   | F41-6001-100                | 7231                 |                                |
| Replacement black toner cartridge for use in Canon IR 550, 600                     | F42-1401-200D               | 7497                 |                                |
| Replacement black toner cartridge for use in Canon IR 200, 330, 400                | F42-3201-700                | 7498                 |                                |
| Replacement black toner cartridge for use in Canon GP 30, 55                       | F41-8601-000                | 7502                 |                                |
| Replacement black toner cartridge for use in Canon NP 6045, 6545, 6551, 6560       | NPG 14 / F41-1923-740       | 7548                 |                                |
| Replacement black toner cartridge for use in Canon IR 6000, 6020, 5000, 5020, 4600 | NPG-16/ GPR 4/F42-1401-200D | 7549                 |                                |
| Replacement black toner cartridge for use in Canon NP 6085, 6285                   | NPG 12/ F41-7901-000        | 7550                 |                                |
| Replacement black toner cartridge for use in Canon NP 6035                         | NPG-13                      | 7551                 |                                |
| Replacement toner cartridge for use in Canon Laser Class 710, A10                  | 7621A001AA                  | 9216                 |                                |
| Replacement Black toner cartridge for use in Canon IR C 3100, 3170                 | GPR-13K                     | 11106                |                                |
| Replacement Cyan toner cartridge for use in Canon IR C 3100, 3170                  | GPR-13C                     | 11107                |                                |
| Replacement Magenta toner cartridge for use in Canon IR C 3100, 3170               | GPR-13M                     | 11108                |                                |
| Replacement Yellow toner cartridge for use in Canon IR C 3100, 3170                | GPR-13Y                     | 11109                |                                |
| Replacement black toner cartridge for use in Canon GP 200,200F, 210, 210E, 210G    | F42-1401-700                | 12289                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>  | <b>OEM #</b>       | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|---|--------------------|----------------------|---|
| Replacement Black toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550, GPR 23       | 0452B003AA         | 12749                |   |
| Replacement Cyan toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550                | 0453B003AA         | 12750                |   |
| Replacement Magenta toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550             | 0454B004AA         | 12751                |   |
| Replacement Yellow toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550              | 0455B004AA         | 12752                |   |
| Replacement black toner cartridge for use in Canon™ Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025 | GPR22              | 12888                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement black toner cartridge for use in Canon™ Imagerunner 1018,1020, 1022, 1023, 1024,1025        | GPR22              | 12888                |   |
| Replacement black toner cartridge for use in Canon GP 200   | F42-1401-700       | 12889                |   |
| Replacement black toner cartridge for use in Canon™ IR 2016, 2018, 2020, 2022, 2025, 2030               | 0384B003AA         | 12890                |   |
| Replacement black toner cartridge for use in Canon Imagerunner 2520, 2525, 2530                         | GPR35/2785B003AA   | 15088                |   |
| Replacement Black toner cartridge for use in Canon Imagerunner Advance C 7065, 7055                     | 2792B003AA/GPR33   | 17290                |   |
| Replacement Cyan toner cartridge for use in Canon Imagerunner Advance C 7065, 7055                      | 2796B003AA/GPR33   | 17291                |   |
| Replacement Magenta toner cartridge for use in Canon Imagerunner Advance C 7065, 7055                   | 2800B003AA/GPR33   | 17292                |   |
| Replacement Yellow toner cartridge for use in Canon Imagerunner Advance C 7065, 7055                    | 2804B003AA/GPR33   | 17293                |   |
| Replacement black toner cartridge for use in Canon Imagerunner 6055, 6065, 6075                         | GPR 38             | 17329                |   |
| Replacement black toner cartridge for use in Canon Imagerunner 8085, 8105                               | GPR37              | 17590                |   |
| Replacement toner cartridge for use in Canon Imagerunner 1730, 1740, 1750                               | GPR-39/48          | 18705                |   |
| Replacement toner cartridge for use in Canon IR 8500, 9070  | 6748A003AA / GPR-7 | 19208                |   |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                         | <b>OEM #</b>        | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|---------------------|----------------------|--------------------------------|
| Replacement toner cartridge for use in Canon IR 2230, 2270, 2830, 2870, 3530, 3570, 4570 | 9634A003AA / GPR-16 | 19209                |                                |
| Replacement toner cartridge for use in Canon Imagerunner 5570                            | 0279B003AA/GPR-17   | 19210                |                                |
| Replacement toner cartridge for use in Canon Imagerunner 7105, 7086, 7095                | 0387B003AA/GPR-19   | 19211                |                                |
| Replacement toner cartridge for use in Canon Imagerunner 2545, 2535                      | GPR -34             | 19458                |                                |
| Replacement Black toner cartridge for use in Canon IR C 3220, 3200, 2620                 | 7629A001AA / GPR-11 | 19491                |                                |
| Replacement Cyan toner cartridge for use in Canon IR C 3220, 3200, 2620                  | 7628A001AA / GPR-11 | 19492                |                                |
| Replacement Magenta toner cartridge for use in Canon IR C 3220, 3200, 2620               | 7627A001AA - GPR-11 | 19493                |                                |
| Replacement Yellow toner cartridge for use in Canon IR C 3220, 3200, 2620                | 7626A001AA / GPR-11 | 19494                |                                |
| Replacement Black toner cartridge for use in Canon IR C 5180, 5185                       | 1069B001AA / GPR-20 | 19498                |                                |
| Replacement Cyan toner cartridge for use in Canon IR C 5180, 5185                        | 1068B001AA / GPR-20 | 19499                |                                |
| Replacement Magenta toner cartridge for use in Canon IR C 5180, 5185                     | 1067B001AA / GPR-20 | 19500                |                                |
| Replacement Yellow toner cartridge for use in Canon IR C 5180, 5185                      | 1066B001AA / GPR-20 | 19501                |                                |
| Replacement Black toner cartridge for use in Canon IR 5050, 5055, 5065, 5075             | 1872B003AA / GPR-24 | 19502                |                                |
| Replacement Black toner cartridge for use Canon Imagerunner C 4080, 4580                 | 0262B001AA / GPR-21 | 19532                |                                |
| Replacement Cyan toner cartridge for use Canon Imagerunner C 4080, 4580                  | 0261B001AA / GPR-21 | 19533                |                                |
| Replacement Magenta toner cartridge for use Canon Imagerunner C 4080, 4580               | 0260B001AA / GPR-21 | 19534                |                                |
| Replacement Yellow cartridge for use Canon Imagerunner C 4080, 4580                      | 0259B001AA / GPR-21 | 19535                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>  | <b>OEM #</b>        | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|---------------------|----------------------|--------------------------------|
| Replacement Black cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020   | 3782B003AA / GPR-36 | 20041                |                                |
| Replacement Cyan cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020    | 3783B003AA / GPR-36 | 20042                |                                |
| Replacement Magenta cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020 | 3784B003AA / GPR-36 | 20043                |                                |
| Replacement Yellow cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020  | 3785B003AA / GPR-36 | 20044                |                                |
| Replacement Black cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030               | 2790B003AA / GPR-31 | 20045                |                                |
| Replacement Cyan cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030                | 2794B003AA / GPR-31 | 20046                |                                |
| Replacement Magenta cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030             | 2798B003AA / GPR-31 | 20047                |                                |
| Replacement Yellow cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030              | 2802B003AA / GPR-31 | 20048                |                                |
| Replacement Black cartridge for use in Canon Imagerunner Advance 4251, 4245, 4225, 4057, 4051           | 4791B003AA / GPR-42 | 20049                |                                |
| <b>REPLACEMENT DRUM UNIT CARTRIDGE</b>  |                     |                      |                                |
| Replacement drum unit cartridge for use in Canon NP 1215  | 1316A001AA          | 9212                 |                                |
| <b>FUJI XEROX®</b>  |                     |                      |                                |
| Replacement toner cartridge, Black for use in Fuji Xerox Docuprint C 1190 FS                            | CT201260            | 14956                |                                |
| Replacement toner cartridge, Cyan for use in Fuji Xerox Docuprint C 1190 FS                             | CT201261            | 14957                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement toner cartridge, Magenta for use in Fuji Xerox Docuprint C 1190 FS

CT201262

14958

Replacement toner cartridge, Yellow for use in Fuji Xerox Docuprint C 1190 FS

CT201263

14959

**KYOCERA®**

Replacement black toner cartridge for use in Kyocera KM 4230, 5230, Ai 4040, 5050

37015011

4969

Replacement black toner cartridge for use in Kyocera KM 4530, 5530, 6330, 7530

TK601

5075

Replacement black toner cartridge for use in Kyocera KM Ai 2310, 3010

37016011

5079

Replacement black toner cartridge for use in Kyocera KM 1505, 1510, 1810

37029011

5249

Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035

370AB011

5251

Replacement black toner cartridge for use in Kyocera KM 1500 LA

TK 17 LA

5931

Replacement black toner cartridge for use in Kyocera FS 1700

TK 20 H

5995

Replacement black toner cartridge for use in Kyocera FS 1920

TK 57 H, 55 H

6809

Replacement black toner cartridge for use in Kyocera FS 3820

TK 67, 65

6810

Replacement black toner cartridge for use in Kyocera KM 1500, 1815

TK100

7047



**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>        | <b>OEM #</b>          | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|-----------------------|----------------------|--------------------------------|
| Replacement black toner cartridge for use in Kyocera FS 1700            | TK 20 H               | 7612                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 9100, 9500      | TK 70 H               | 7764                 |                                |
| Replacement toner cartridge for use in Kyocera Mita DC 1560, 1860, 2360 | 37090011              | 7913                 |                                |
| Replacement toner cartridge for use in Kyocera Mita DC 2255             | 37037011              | 6075                 |                                |
| Replacement toner cartridge for use in Kyocera Mita DC 3555, 3585,4585  | 3,705,601,137,050,010 | 5273                 |                                |
| Replacement toner cartridge for use in Kyocera Mita DC 1605             | 37046011              | 6458                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 1020, 1118      | TK 18 H               | 8664                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 1900            | TK 50                 | 9607                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 3800            | TK 60 H               | 9608                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 720, 820, 1016  | TK 112, 110           | 9630                 |                                |
| Replacement Black toner cartridge for use in Kyocera KM C 2230          | 0T5HNOUS              | 9795                 |                                |
| Replacement Cyan toner cartridge for use in Kyocera KM C 2230           | 0T5HNCUS              | 9796                 |                                |
| Replacement Magenta toner cartridge for use in Kyocera KM C 2230        | 0T5HNBUS              | 9797                 |                                |
| Replacement Yellow toner cartridge for use in Kyocera KM C 2230         | (0T5HNAUS)            | 9798                 |                                |
| Replacement Black toner cartridge for use in Kyocera KM C 2030, 3130    | TK 621(370-AJ011)     | 9799                 |                                |
| Replacement Cyan toner cartridge for use in Kyocera KM C 2030, 3130     | TK 621(370-AJ511)     | 9800                 |                                |
| Replacement Magenta toner cartridge for use in Kyocera KM C 2030, 3130  | TK 621(370-AJ411)     | 9801                 |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                           | <b>OEM #</b>           | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|------------------------|----------------------|--------------------------------|
| Replacement Yellow toner cartridge for use in Kyocera KM C 2030, 3130                      | TK 621(370-AJ311)      | 9802                 |                                |
| Replacement black toner cartridge for use in Kyocera FS 1000                               | TK 17 H                | 9817                 |                                |
| Replacement black toner cartridge for use in Kyocera KM 6230                               | TK 623 (37026011)      | 9980                 |                                |
| Replacement black toner cartridge for use in Kyocera KM Ai 6060, 5555                      | 37013011               | 10009                |                                |
| Replacement black toner cartridge for use in Kyocera KM 1620, 1650, 2020, 2050             | TK 420, 421, 410, 411, | 10300                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1030                               | TK 122, 120            | 10420                |                                |
| Replacement black toner cartridge for use in Kyocera FS 2000                               | TK 312, 310            | 11117                |                                |
| Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900                           | TK 322, 320            | 11118                |                                |
| Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900                           | TK 322, 320            | 11119                |                                |
| Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 | (370AB011, TK 2530)    | 11319                |                                |
| Replacement black toner cartridge for use in Kyocera FS 9530, 9130                         | TK 712                 | 11372                |                                |
| Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050                   | TK 717, 719            | 11375                |                                |
| Replacement black toner cartridge for use in Kyocera KM 8530                               | TK 631                 | 11639                |                                |
| Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050                   | TK 715                 | 13093                |                                |
| Replacement black toner cartridge for use in Kyocera KM 2540, 2560, 3040, 3060             | TK 675, 679            | 13533                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1100                               | TK 137, 140, 142       | 14103                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1300, 1350                         | TK 132, 130            | 14366                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                  | <b>OEM #</b>       | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|--------------------|----------------------|--------------------------------|
| Replacement black toner cartridge for use in Kyocera FS 4020                                      | TK 360, 362, 364   | 14802                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1320, 1370                                | TK 170,172,173,174 | 15967                |                                |
| Replacement black toner cartridge for use in Kyocera Mita TASKalfa 180, 220, KM 1620              | TK 437             | 16245                |                                |
| Replacement black toner cartridge for use in Kyocera Mita TaskAlfa 420i, 520i                     | TK 725             | 16246                |                                |
| Replacement black toner cartridge for use in Kyocera KM 1525, 1530, 1570, 2030, 2070              | 37028011           | 16748                |                                |
| Replacement black toner cartridge for use in Kyocera Mita TASKalfa 255, 255 B, 305, FS 6025, 6030 | TK 477             | 17029                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP                            | TK 1142            | 17535                |                                |
| Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP                            | TK 1140            | 17582                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe                  | TK865K             | 18275                |                                |
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe                   | TK865C             | 18276                |                                |
| Replacement Magenta toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe                | TK865M             | 18277                |                                |
| Replacement Yellow toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe                 | TK865Y             | 18278                |                                |
| Replacement Black toner cartridge for use in Kyocera Taskalfa 350ci, 250ci USA                    | TK867              | 18279                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500                    | TK6305             | 18313                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500                    | TK6307             | 18314                |                                |
| Absolute Black® Replacement toner cartridge for use in Kyocera FS 1030 MFP, 1130 MFP              | TK-1130            | 18479                |                                |
| Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP                  | TK 1142            | 18480                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                       | <b>OEM #</b>    | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|-----------------|----------------------|--------------------------------|
| Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP                       | TK 1147         | 18481                |                                |
| Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP                       | TK 1140         | 18482                |                                |
| Replacement toner cartridge for use in Kyocera FS 1024, 1110, 1124                                     | TK 1102         | 18706                |                                |
| Replacement toner cartridge for use in Kyocera FS 6950   | TK 442, 440,430 | 18707                |                                |
| Absolute Black® Replacement toner cartridge for use in Kyocera TASKalfa 255, 255 B, 305, FS 6025, 6030 | TK479           | 19294                |                                |
| Replacement toner cartridge for use in Kyocera TK 710, FS 9530, 9130 EU                                | TK710           | 19429                |                                |
| Replacement toner cartridge for use in Kyocera TASKalfa 255, 255 B, 305, FS 6025, 6030                 | TK 475          | 19554                |                                |
| Replacement toner cartridge for use in Kyocera FS 1100 EU  | TK 140          | 19625                |                                |
| Replacement toner cartridge for use in Kyocera KM 2820, 2810   | TK 137          | 19626                |                                |
| Replacement toner cartridge for use in Kyocera FS 1120, ECOSYS P 2035                                  | TK 162          | 19790                |                                |
| Replacement toner cartridge for use in Kyocera FS 4000   | TK 332          | 19791                |                                |
| Replacement toner cartridge for use in Kyocera FS 3900   | TK 322          | 19792                |                                |
| Replacement toner cartridge for use in Kyocera FS 4200, M 3550   | TK 3122         | 19793                |                                |
| Replacement toner cartridge for use in Kyocera FS 2100, ECOSYS M 3540, 3040                            | TK 3102         | 19926                |                                |
| Replacement Black toner cartridge for use in Kyocera Mita FSC 5350, 5300, Ecosys P 6030 US             | TK 562          | 19972                |                                |
| Replacement Cyan toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US             | TK 562          | 19973                |                                |
| Replacement Magenta toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US          | TK 562          | 19974                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                 | <b>OEM #</b>        | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|---------------------|----------------------|--------------------------------|
| Replacement Yellow toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US     | TK 562              | 19975                |                                |
| Replacement toner cartridge for use in Kyocera ECOSYS FS 1120, 1040, 1020                        | TK 1112             | 19976                |                                |
| Replacement toner cartridge for use in Kyocera ECOSYS FS 1125, 1060, 1025                        | TK 1122             | 19977                |                                |
| Replacement Black toner cartridge for use in Kyocera Mita FS 3920, 3640, 3540, 3140, 3040 MFP US | TK 352              | 20023                |                                |
| Replacement Black toner cartridge for use in Kyocera Mita FS 4300, M 3560                        | TK 3132             | 20024                |                                |
| Replacement Black toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US      | TK8307K             | 20959                |                                |
| Replacement Cyan toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US       | TK8307C             | 20960                |                                |
| Replacement Magenta toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US    | TK8307M             | 20961                |                                |
| Replacement Yellow toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US     | TK8307Y             | 20962                |                                |
| Replacement Black toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US      | TK8507K             | 20963                |                                |
| Replacement Cyan toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US       | TK8507C             | 20964                |                                |
| Replacement Magenta toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US    | TK8507M             | 20965                |                                |
| Replacement Yellow toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US     | TK8507Y             | 20966                |                                |
| Replacement cartridge for use in Kyocera Taskalfa 2201, 2200, 1801, 1800 MFP                     | TK-4109, 4107, 4105 | 21071                |                                |
| Replacement cartridge for use in Kyocera TaskAlfa 3011i, 3010i US                                | TK 7107             | 21074                |                                |
| Replacement Black toner cartridge for use in Kyocera TaskAlfa 820, 620 MFP                       | TK 665              | 21083                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 552, 500, 400                      | TK-855K             | 21204                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                           | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 552, 500, 400                 | TK-857C      | 21205                |                                |
| Replacement Yellow toner cartridge for use in Kyocera TASKalfa 552, 500, 400               | TK-857Y      | 21207                |                                |
| Replacement Magenta toner cartridge for use in Kyocera TASKalfa 552, 500, 400              | TK-855M      | 21210                |                                |
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2550ci MFP                    | TK-8317C     | 21213                |                                |
| Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2550ci MFP                 | TK-8317M     | 21214                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 2550ci MFP                   | TK-8315K     | 21216                |                                |
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2550ci MFP                    | TK-8315C     | 21217                |                                |
| Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2550ci MFP                 | TK-8315M     | 21218                |                                |
| Replacement Yellow toner cartridge for use in Kyocera TASKalfa 2550ci MFP                  | TK-8315Y     | 21219                |                                |
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2551ci MFP                    | TK-8327C     | 21221                |                                |
| Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2551ci MFP                 | TK-8325M     | 21222                |                                |
| Replacement Black toner cartridge for use in Kyocera TASKalfa 2551ci MFP                   | TK-8325K     | 21224                |                                |
| Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2551c MFP                     | TK-8325C     | 21225                |                                |
| Replacement Yellow toner cartridge for use in Kyocera TASKalfa 2551ci MFP                  | TK-8325Y     | 21227                |                                |
| Replacement Black toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP   | TK8505K      | 21231                |                                |
| Replacement Cyan toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP    | TK8505C      | 21232                |                                |
| Replacement Magenta toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP | TK8505M      | 21233                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

|  | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Replacement Yellow toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP  | TK8505Y      | 21234                |                                |
| Replacement Black toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP   | TK8305K      | 21235                |                                |
| Replacement Cyan toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP    | TK8305C      | 21236                |                                |
| Replacement Magenta toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP | TK8305M      | 21237                |                                |
| Replacement Yellow toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP  | TK8305Y      | 21238                |                                |

**KONICA MINOLTA®**

|   |              |      |  |
|---|--------------|------|--|
| Replacement black toner cartridge for use in Konica Minolta EP 1030, 1031             | 8935-802     | 7684 |  |
| Replacement black toner cartridge for use in Konica Minolta EP 2120, 2130, 2150       | 8931-602     | 7905 |  |
| Replacement black toner cartridge for use in Konica Minolta EP 2080                   | 8936-202     | 8158 |  |
| Replacement black toner cartridge for use in Konica Minolta EP 8015, 6001, 6000, 5050 | MT601A, 602A | 8162 |  |
| Replacement black toner cartridge for use in Konica Minolta Di 200, 250, 350          | TN211        | 8969 |  |
| Replacement black toner cartridge for use in Konica Minolta Di 450, 470, 550          | 502A,B       | 9977 |  |
| Replacement Black toner cartridge for use in Konica Minolta CF 2002, 3102             | 8937-905     | 9745 |  |
| Replacement Cyan toner cartridge for use in Konica Minolta CF 2002, 3102              | 8937-908     | 9746 |  |
| Replacement Magenta toner cartridge for use in Konica Minolta CF 2002, 3102           | 8937-907     | 9747 |  |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                            | <b>OEM #</b>    | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|-----------------|----------------------|--------------------------------|
| Replacement Yellow toner cartridge for use in Konica Minolta CF 2002, 3102                  | 8937-906        | 9748                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Bizhub C 350, 450               | 4053-401        | 9749                 |                                |
| Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 350, 450                | 4053-701        | 9750                 |                                |
| Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 350, 450             | 4053-601        | 9751                 |                                |
| Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 350, 450              | 4053-501        | 9752                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 551, 650, 5510, 7210         | 604A,B          | 9974                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 450, 470, 550                | 502A,B          | 9977                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 520, 620                     | 603A,B          | 9978                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 1810, 2010, 2510, 3010, 3510 | 205 A,B/305 A,B | 9979                 |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 750                          | 8971-111        | 10226                |                                |
| Replacement black toner cartridge for use in Konica Minolta Di 850                          | 8937-807        | 10230                |                                |
| Replacement black toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252         | TN 210          | 11098                |                                |
| Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252          | 8938-508        | 11099                |                                |
| Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252       | 8938-507        | 11100                |                                |
| Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252        | 8938-506        | 11101                |                                |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 350                      | 8938-402        | 11613                |                                |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250                 | 8938-415        | 11614                | (EU)                           |



**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                           | <b>OEM #</b>                               | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|--|--|----------------------|---|
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 350                     | 8938-402                                   | 11615                |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250, 360           | 8938-413                                   | 11616                | (US)  |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 152,162,180,181 210     | 8937-884                                   | 11617                |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 360, 420, 421, 500, 501 | 8938-402                                   | 11619                |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 600, 750                | TN710                                      | 11620                |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 920                     | TN910                                      | 11621                |   |
| Replacement black toner cartridge for use in Konica Minolta EP 4000, 5000                  | 8935-502, MT 501                           | 11705                |   |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C- 500              | A0YM131, A0YM130, TN-510K, TN510K, 020V    | 11741                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C- 500               | A0YM431, A0YM430, TN-510C, TN510C, 020Y    | 11742                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C- 500            | A0YM331, A0YM330, TN-510M, TN510M,<br>020X | 11743                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C- 500             | A0YM231, A0YM230, TN-510Y, TN510Y, 020W    | 11744                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement toner cartridge for use in Konica Minolta 7030, 7025, 7020                     | 950-236,01QJ                               | 15409                |   |
| Replacement toner cartridge for use in Konica Minolta 7022, 7130, 7222, 7228               | 950-246, TN301K,O17Q                       | 15410                |   |
| Replacement toner cartridge for use in Konica Minolta 7035                                 | 950-251, O1WK                              | 15411                |   |
| Replacement toner cartridge for use in Konica Minolta 7135, 7235                           | 950-367, TN303K, O2BP                      | 15412                |   |
| Replacement toner cartridge for use in Konica Minolta 7145                                 | 960-420, TN401K, O2AS                      | 15413                |   |
| Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652          | A0TM430                                    | 15738                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| OEM #  | UNINET PART # | SPECIAL CHARACTERISTICS |   |
|--|---------------|-------------------------|---|
| Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652   | A0TM330       | 15739                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652    | A0TM230       | 15740                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub C 253, 353          | A0D7132       | 16293                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 253, 353           | A0D7432       | 16295                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 253, 353        | A0D7332       | 16296                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 253, 353         | A0D7232       | 16297                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 223, 283            | TN 217        | 17014                   |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 363, 423            | TN414         | 17015                   |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub C 451               | TN411K        | 17119                   |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub C 550, 650          | TN611K        | 17120                   |   |
| Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650      | TN611C        | 17121                   |   |
| Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650   | TN611M        | 17122                   |   |
| Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650    | TN611Y        | 17123                   |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42              | TN415         | 17591                   |   |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42              | TN415         | 17592                   |   |
| Replacement Black toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690 | AOV301F       | 17604                   |   |
| Replacement Cyan toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690  | AOV301HF      | 17605                   |   |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                  | <b>OEM #</b>           | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|---|------------------------|----------------------|---|
| Replacement Magenta toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690          | AOV301CF               | 17606                |   |
| Replacement Yellow toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690           | AOV306F                | 17607                |   |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510   | TN 610, 612 universal) | 17850                |   |
| Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510    | TN 610, 612 universal  | 17851                |   |
| Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510 | TN 610, 612 universal  | 17852                |   |
| Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510  | TN 610, 612 universal  | 17853                |   |
| Replacement toner cartridge for use in Konica Minolta Bizhub 164, 184, 215                        | TN 116, 117            | 18292                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Minolta Bizhub C 220, 280, 360                       | TN216K                 | 18308                |   |
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 220, 280, 360                        | TN216C                 | 18309                |   |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 220, 280, 360                     | TN216M                 | 18310                |   |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 220, 280, 360                      | TN216Y                 | 18311                |   |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652                | A0TM430, A0TM131       | 18312                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement black toner cartridge for use in Konica Minolta Bizhub 223, 283, 363, 423             | TN 217 /TN414          | 18315                |   |
| Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652                 | A0TM430, A0TM131       | 18340                |   |
| Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652              | A0TM430, A0TM131       | 18341                |   |
| Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652               | A0TM430, A0TM131       | 18342                |   |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 652, 552                       | (TN-618)(A0TM132)      | 19089                |   |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                             | <b>OEM #</b>         | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|----------------------|----------------------|--------------------------------|
| Absolute Black® Replacement toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650 | TN411K/TN611K        | 19090                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub C 224                            | TN321K               | 19091                |                                |
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 224                             | TN321C               | 19092                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 224                          | TN321M               | 19093                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 224                           | TN321Y               | 19094                |                                |
| Replacement toner cartridge for use in Minolta Bizhub 360, 361, 420, 421, 500, 501 EU        |                      | 19289                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub C 554, 454                       | TN512K, A33K132      | 20015                |                                |
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 554, 454                        | TN512C, A33K432      | 20016                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 554, 454                     | TN512M, A33K332      | 20017                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 554, 454                      | TN512Y, A33K232      | 20018                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub C 754, 654                       | TN 711, 712, A3VU330 | 20019                |                                |
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 754, 654                        | TN711C, A3VU430      | 20020                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 754, 654                     | TN711M, A3VU330      | 20021                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 754, 654                      | TN711Y, A3VU230      | 20022                |                                |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 3320                      | TNP41, TNP43         | 20656                |                                |
| Replacement Black toner cartridge for use in Konica Minolta Bizhub 4020                      | TNP40                | 20657                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub C 3850, 3350                     | TNP-48K, A5X0130     | 20955                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                 | <b>OEM #</b>     | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|------------------|----------------------|--------------------------------|
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 3850, 3350          | TNP-48C, A5X0430 | 20956                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 3850, 3350       | TNP-48M, A5X0330 | 20957                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 3850, 3350        | TNP-48Y, A5X0230 | 20958                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub Press C 7000, 6000   | TN 616K, A1U9130 | 21040                |                                |
| Replacement Cyan toner cartridge for use in Minolta Bizhub Press C 7000, 6000    | TN 616C, A1U9433 | 21041                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub Press C 7000, 6000 | TN 616M, A1U9333 | 21042                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub Press C 7000, 6000  | TN 616Y, A1U9233 | 21043                |                                |
| Replacement Black toner cartridge for use in Minolta Bizhub C 287, 227 MFP       | TN 221K, A8K3130 | 21200                |                                |
| Replacement Cyan toner cartridge for use in Minolta Bizhub C 287, 227 MFP        | TN 221C, A8K3430 | 21201                |                                |
| Replacement Magenta toner cartridge for use in Minolta Bizhub C 287, 227 MFP     | TN 221M, A8K3330 | 21202                |                                |
| Replacement Yellow toner cartridge for use in Minolta Bizhub C 287, 227 MFP      | TN 221Y, A8K3230 | 21203                |                                |

**LANIER®**

|  |        |      |  |
|--|--------|------|--|
| Replacement black toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C  | 885317 | 9563 |  |
| Replacement cyan toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C   | 885320 | 9564 |  |
| Replacement magenta oner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C | 885319 | 9565 |  |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement yellow toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C

885318

9566

Replacement black toner cartridge for use in Lanier 7355, 7365

1170227

16284

**NASHUATEC®**

Replacement black toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

885372BK

8138

Replacement cyan toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888037

8139

Replacement magenta toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888036

8140

Replacement yellow toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888035

8141

**OKIDATA®**

Replacement black toner cartridge for use in Okidata Okipage 4W

52106201

477

Replacement black toner cartridge for use in Okidata OL 400e

52107201

492

Replacement black toner cartridge, compatible for use in Okidata Okipage 8W, 6W

52111701

7033

Replacement toner cartridge for use in Okidata 14, 14ex, 14i

TYPE 8

8894

Replacement toner cartridge for use in Okidata C 5100

42127404 / 42127408

10217

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                 | <b>OEM #</b>        | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|---------------------|----------------------|--------------------------------|
| Absolute Cyan™ Replacement toner cartridge for use in Okidata C 5100             | 42127403 / 42127407 | 10218                |                                |
| Absolute Magenta™ Replacement toner cartridge for use in Okidata C 5100          | 42127402 / 4212740  | 10219                |                                |
| Absolute Yellow™ Replacement toner cartridge for use in Okidata C 5100           | 42127401 / 42127405 | 10220                |                                |
| Replacement Black Glossy toner cartridge for use in Okidata C 9000               | 41963604 / 41963600 | 10221                |                                |
| Replacement Cyan Glossy toner cartridge for use in Okidata C 9000                | 41963603 / 41963607 | 10222                |                                |
| Replacement Magenta glossy toner cartridge for use in Okidata C 9000             | 41963602/ 41963606  | 10223                |                                |
| Replacement Yellow glossy toner cartridge for use in Okidata C 9000              | 41963601/41963605   | 10224                |                                |
| Replacement Black Glossy toner cartridge for use in Okidata C 5100               | 42127404 /42127408  | 10433                |                                |
| Absolute Cyan™ Glossy Replacement toner cartridge for use in Okidata C 5100      | 42127403 /42127407  | 10434                |                                |
| Absolute Magenta™ Glossy Replacement toner cartridge for use in Okidata C 5100   | 42127402 / 42127406 | 10435                |                                |
| Absolute Yellow™ Glossy Replacement toner cartridge for use in Okidata C 5100    | 42127401 / 42127405 | 10436                |                                |
| Replacement Black glossy toner cartridge for use in Okidata C 7000, 7300, 7500   | 41304208            | 10844                |                                |
| Replacement Cyan glossy toner cartridge for use in Okidata C 7000, 7300, 7500    | 41304207            | 10845                |                                |
| Replacement Magenta glossy toner cartridge for use in Okidata C 7000, 7300, 7500 | 41304206            | 10846                |                                |
| Replacement yellow glossy toner cartridge for use in Okidata C 7000, 7300, 7500  | 41304205            | 10847                |                                |
| Replacement black toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP    | 43459304            | 12855                |                                |
| Replacement cyan toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP     | 43459331            | 12856                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|--------------|----------------------|--------------------------------|
| Replacement magenta toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP | 43459330     | 12857                |                                |
| Replacement yellow toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP  | 43459329     | 12858                |                                |
| Replacement Absolute Black® toner cartridge for use in Okidata C 831            | 44844512     | 20387                |                                |
| Replacement Absolute Cyan® toner cartridge for use in Okidata C 831             | 44844511     | 20388                |                                |
| Replacement Absolute Magenta® toner cartridge for use in Okidata C 831          | 44844510     | 20389                |                                |
| Replacement Absolute Yellow® toner cartridge for use in Okidata C 831           | 44844509     | 20390                |                                |
| Replacement Absolute Black® toner cartridge for use in Okidata C 711, 710 US    | 44318604     | 21000                |                                |
| Replacement Absolute Cyan® toner cartridge for use in Okidata C 711, 710 US     | 44318603     | 21001                |                                |
| Replacement Absolute Magenta® toner cartridge for use in Okidata C 711, 710 US  | 44318602     | 21002                |                                |
| Replacement Absolute Yellow® toner cartridge for use in Okidata C 711, 710 US   | 44318601     | 21003                |                                |

**PANASONIC®**

|  |                |       |  |
|--|----------------|-------|--|
| Replacement black toner cartridge for use in Panasonic KX P 4420                       | KX P 4420      | 527   |  |
| Replacement black toner cartridge for use in Panasonic DP 1520, 1820                   | DQ-TU10J-PU/PB | 11680 |  |
| Replacement black toner cartridge for use in Panasonic DP 1510, 1810, 2010             | DQ-TU10C       | 11681 |  |
| Replacement black toner cartridge for use in Panasonic DP 6530, 7240, 8130, 8540, 8570 | T6510, T6510E  | 11685 |  |



**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement black toner cartridge for use in Panasonic FP 7781, 7760

FQ-TE70

11838

Replacement black toner cartridge for use in Panasonic FP7728, 7735, 7742, 7750, 7830, 7835, 7845, 7850

FQTK20

13321

**RICOH®**

Replacement black toner cartridge for use in Ricoh FT 4118, 3813

885117

5245

Replacement black toner cartridge for use in Ricoh Aficio 1015, 1018, 1113

888086

5246

Replacement black toner cartridge for use in Ricoh Aficio 1022, 2022, 2032, 3030

888169

5247

Replacement black toner cartridge for use in Ricoh FT 4022, 4622

887718

5248

Replacement black toner cartridge for use in Ricoh 4080, 4150

5397-30

5278

Replacement black toner cartridge for use in Ricoh Aficio 1013, 1013F

885257

5894

Replacement black toner cartridge for use in Ricoh Type 310

889264

6456

Replacement black toner cartridge for use in Ricoh Aficio 200, 250

889613

7552

Replacement black toner cartridge for use in Ricoh Aficio 220, 270

885208

7553

Replacement black toner cartridge for use in Ricoh Aficio 350, 450

887725

7554

Replacement black toner cartridge for use in Ricoh Aficio 550, 650

887740

7555

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                               | <b>OEM #</b>    | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|-----------------|----------------------|--------------------------------|
| Replacement black toner cartridge for use in Ricoh FT 4215, 4415, 4418, 4421                   | 887523          | 7860                 |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio 3800, 3850                           | 885372BK        | 8138                 |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio 3800                                  | 888037          | 8139                 |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio 3800                               | 888036          | 8140                 |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio 3800                                | 888035          | 8141                 |                                |
| Replacement toner cartridge for use in Ricoh Imagio MF 200                                     | 889613          | 8147                 |                                |
| Replacement black toner cartridge for use in Ricoh Imagio MF 250                               | TYPE 5          | 8149                 |                                |
| Replacement cyan toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000        | 636341          | 8273                 |                                |
| Replacement Black toner cartridge toner for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000 | 636338          | 8274                 |                                |
| Replacement Magenta toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000     | 636340          | 8275                 |                                |
| Replacement Yellow toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000      | 636339          | 8276                 |                                |
| Replacement toner cartridge for use in Ricoh Imagio  | TYPE 20         | 8704                 |                                |
| Replacement black toner cartridge for use in Ricoh Imagio P                                    | TYPE 2          | 8706                 |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 551, 700, Type 5105                  | 887994          | 8827                 |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 1035, 1045, 4510                     | 885247, 888062  | 8828                 |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 850, 1050                            | 888008          | 8829                 |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 1085, 1105, 2090, 2105               | 888156, 8885340 | 8830                 |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                 | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Replacement Black toner cartridge toner for use in Ricoh CL 7000                 | 885406       | 8837                 |                                |
| Replacement Cyan toner cartridge for use in Ricoh CL 7000                        | 885409       | 8838                 |                                |
| Replacement Magenta toner cartridge for use in Ricoh CL 7000                     | 885408       | 8839                 |                                |
| Replacement Yellow toner cartridge for use in Ricoh CL 7000                      | 885407       | 8840                 |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio 1224 C, 1232 C         | 885317       | 9563                 |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio 1224 C, 1232 C          | 885320       | 9564                 |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio 1224 C, 1232 C       | 885319       | 9565                 |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio 1224 C, 1232 C        | 885318       | 9566                 |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio 2232 C, 2238 C         | 888231       | 9567                 |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio 2232 C, 2238 C          | 888234       | 9568                 |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio 2232 C, 2238 C       | 888233       | 9569                 |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio 2232 C, 2238 C        | 888232       | 9570                 |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 400, 401, 500          | 11D,10D      | 11842                |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 2035, 2045             | 3110, 3210D  | 11843                |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 2015, 2018             | 888215       | 12233                |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 1515                   | 888260       | 12234                |                                |
| Replacement black toner cartridge for use in Ricoh Aficio 1060, 1075, 2051, 2060 | 885400       | 12235                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                          | <b>OEM #</b>    | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|---|-----------------|----------------------|---|
| Replacement cyan toner cartridge for use in Ricoh Aficio MP C 3500, 4500                  | 888607          | 12559                |   |
| Replacement black toner cartridge for use in Ricoh Aficio MP C 3500, 4500                 | 888604          | 12757                |   |
| Replacement magenta toner cartridge for use in Ricoh Aficio MP C 3500, 4500               | 888606          | 12758                |   |
| Replacement yellow toner cartridge for use in Ricoh Aficio MP C 3500, 4500                | 888605          | 12759                |   |
| Replacement Black toner for use in Ricoh Aficio MP C 2000, 2500, 3000                     | 888636          | 12760                |   |
| Replacement cyan toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000            | 888639          | 12761                |   |
| Replacement magenta toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000         | 888638          | 12762                |   |
| Replacement yellow toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000          | 888637          | 12763                |   |
| Replacement Black toner for use in Ricoh Aficio MP 2500                                   | MP2500,A,E      | 13381                |   |
| Replacement black toner cartridge for use in Ricoh Aficio MP 3500, 4000, 4001, 4500, 5000 | 884922, 8400040 | 15936                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Ricoh Aficio CL 7200, 7300                   | 888442          | 16313                |   |
| Replacement Cyan toner cartridge for use in Ricoh Aficio CL 7200, 7300                    | 888445          | 16314                |   |
| Replacement Magenta toner cartridge for use in Ricoh Aficio CL 7200, 7300                 | 888444          | 16315                |   |
| Replacement Yellow toner cartridge for use in Ricoh Aficio CL 7200, 7300                  | 888443          | 16316                |   |
| Replacement Black toner for use in Ricoh Aficio MP 8000 SP                                | 885400          | 17028                |   |
| Replacement Black toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR           | MPC400E/A       | 17389                |   |
| Replacement Cyan toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR            | MPC400E/A       | 17391                |   |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                            | <b>OEM #</b>   | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|---|----------------|----------------------|---|
| Replacement Magenta toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR           | MPC400E/A      | 17392                |   |
| Replacement Yellow toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR            | MPC400E/A      | 17393                |   |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC-2051, 2551                    | 841500         | 17854                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-2051, 2551                     | 841501         | 17855                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-2051, 2551                  | 841502         | 17856                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-2051, 2551                   | 841503         | 17857                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC-4051, 5051                    | 841452         | 17858                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for in Ricoh Aficio MPC 4501, 5501                         | 841455         | 17859                |   |
| Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-4051, 5051                  | 841454         | 17860                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-4051, 5051                   | 841453         | 17861                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC-6000, 7000                    | 841084, 841288 | 20199                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-6000, 7000                     | 841085, 841289 | 17863                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-6000, 7000                  | 841086- 841290 | 17864                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-6000, 7000                   | 841087, 841291 | 17865                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333   | 841276         | 18467                |   |
| Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333    | 841279         | 18468                |   |
| Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333 | 841278         | 18469                |   |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                  | <b>OEM #</b>   | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|----------------|----------------------|--------------------------------|
| Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333        | 841277         | 18470                |                                |
| Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MPC 2030, 2050 ,2550          | 841280         | 18471                |                                |
| Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2030, 2550, 2551          | 841281         | 18472                |                                |
| Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2030, 2050, 2550, 2551 | 841282         | 18473                |                                |
| Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MPC 2030, 2050, 2550, 2551   | 841283         | 18474                |                                |
| Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050          | 841284         | 18475                |                                |
| Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050           | 841287         | 18476                |                                |
| Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050        | 841286         | 18477                |                                |
| Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050         | 841285         | 18478                |                                |
| Replacement toner cartridge for use in Ricoh Aficio MP 301 SP                                     | 841714         | 18560                |                                |
| Replacement Black cartridge for use in Ricoh Aficio MPC 3002, 3502                                | 841647         | 18561                |                                |
| Replacement Cyan cartridge for use in Ricoh Aficio MP C 3002, 3502                                | 841650         | 18562                |                                |
| Replacement Magenta cartridge for use in Ricoh Aficio MP C 3002, 3502                             | 841649         | 18563                |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MP C 3002, 3502                        | 841648         | 18564                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC 6000, 7500, 900g                    | 841084, 841288 | 18912                |                                |
| Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002         | 841751         | 19248                |                                |
| Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002          | 841754         | 19249                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                               | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002    | 841753       | 19250                |                                |
| Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002     | 841752       | 19251                |                                |
| Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU   |              | 19259                |                                |
| Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU    |              | 19260                |                                |
| Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU |              | 19261                |                                |
| Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU  |              | 19262                |                                |
| Replacement Black toner cartridge for use in Ricoh SP 3400, 3410, 3400SF, 3410SF               | 406465       | 19312                |                                |
| Replacement Black cartridge for use in Ricoh Aficio MPC 3002, 3502                             | 841647       | 19512                |                                |
| Replacement Cyan cartridge for use in Ricoh Aficio MP C 3002, 3502                             | 841650       | 19513                |                                |
| Replacement Magenta cartridge for use in Ricoh Aficio MP C 3002, 3502                          | 841649       | 19514                |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MP C 3002, 3502                     | 841648       | 19515                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC 3501, 3001                       | 841578       | 20025                |                                |
| Replacement Black toner cartridge for use in Ricoh MP C 3503, 3003 US                          | 841813       | 20027                |                                |
| Replacement Cyan toner cartridge for use in Ricoh MP C 3503, 3003 US                           | 841816       | 20028                |                                |
| Replacement Magenta toner cartridge for use in Ricoh MP C 3503, 3003 US                        | 841815       | 20029                |                                |
| Replacement Yellow toner cartridge for use in Ricoh MP C 3503, 3003 US                         | 841814       | 20030                |                                |
| Replacement Black toner cartridge for use in Ricoh MP C 3503, 3003 EU                          | 841817       | 20031                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>  | <b>OEM #</b>      | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|-------------------|----------------------|--------------------------------|
| Replacement Cyan toner cartridge for use in Ricoh MP C 3503, 3003 EU  | 841820            | 20032                |                                |
| Replacement Magenta toner cartridge for use in Ricoh MP C 3503, 3003  | 841819            | 20033                |                                |
| Replacement Yellow toner cartridge for use in Ricoh MP C 3503, 3003 EU  | 841818            | 20034                |                                |
| Replacement Black toner cartridge for use in Ricoh MPC 2503, 2003, 360g US  | 841918            | 20131                |                                |
| Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003, 275g US   | 841921            | 20132                |                                |
| Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003, 275g US  | 841920            | 20133                |                                |
| Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003, 275g US   | 841919            | 20134                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio SP C 831, 830   | 821181            | 20135                |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio SP C 831, 830  | 821184            | 20136                |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio SP C 831, 830   | 821183            | 20137                |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio SP C 831, 830  | 821182            | 20138                |                                |
| Replacement toner cartridge for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 5500, 6000, 6500, 7000, 7500, 885400 / Type 6110-D<br>8000 |                   | 20155                |                                |
| Replacement toner cartridge for use in Ricoh Aficio 1515, MP 161, 171   | Type 1170D, 1270D | 20156                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MP 3500, 4000, 4001, 4500, 5000, 5001, 5002                                     | 884922, 840040    | 20157                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC 6000, 7500  | 841084, 841288    | 20199                |                                |
| Replacement Black toner cartridge for use in Ricoh SP 3500, 3510, 3500SF, 3510SF  |                   | 20327                |                                |
| Replacement Black cartridge for use in Ricoh Aficio SP 5210, 5200   | SP5200HA          | 20543                |                                |



| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|--------------|----------------------|--------------------------------|
| Replacement Black cartridge for use in Ricoh Aficio SP 4310, 4210, 4110, 4100                   | Type 220     | 20565                |                                |
| Replacement Black Jumbo cartridge for use in Ricoh SP 3500, 3510, 3500SF, 3510SF                |              | 20567                |                                |
| Replacement toner cartridge for use in Ricoh MP 3554, 3054, 2554                                | 841993       | 20725                |                                |
| Replacement toner cartridge for use in Ricoh MP 6054, 5054, 4054                                | 842126       | 20726                |                                |
| Replacement toner cartridge for use in Ricoh Aficio MP 2501                                     |              | 20967                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US   | 841849       | 20968                |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US    | 841852       | 20969                |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US | 841851       | 20970                |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US  | 841850       | 20971                |                                |
| Replacement Black toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU   | 841853       | 20972                |                                |
| Replacement Cyan toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU    | 841856       | 20973                |                                |
| Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU | 841855       | 20974                |                                |
| Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU  | 841854       | 20975                |                                |
| Replacement Black toner cartridge for use in Ricoh MPC 2503, 2003 EU                            | 841925       | 20983                |                                |
| Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003 EU                             | 841928       | 20984                |                                |
| Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003 EU                          | 841927       | 20985                |                                |
| Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003 EU                           | 841926       | 20986                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement Black toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20992

Replacement Cyan toner cartridge for use in Ricoh Aficio Ricoh Aficio MPC 7501, 6001 WW

20993

Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20994

Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20995

Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003

841921

20132

Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003

841920

20133

Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003

841919

20134

Replacement Black cartridge for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF

407823

21039

Replacement cartridge for use in Ricoh Aficio SP 204, 203, 201, 200

407259 / 407254

21050

Replacement Black toner cartridge for use in Ricoh MPC 305

841621, 841618, 841622

21239

Replacement Cyan toner cartridge for use in Ricoh MPC 305

841591, 841595, 941607

21240

Replacement Magenta toner cartridge for use in Ricoh MPC 305

841592, 841596, 841608

21241

Replacement Yellow toner cartridge for use in Ricoh MPC 305

841593, 841597, 941609

21242

**SAVIN®**

Replacement Black toner cartridge for use in Savin® C 2408, 3210

9563

Replacement cyan toner cartridge for use in Savin® C 2408, 3210

9564

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement magenta toner cartridge for use in Savin® C 2408, 3210

9565

Replacement yellow toner cartridge for use in Savin® C 2408, 3210

9566

Replacement magenta toner cartridge for use in Savin® C 3224, 3828

9569

Replacement yellow toner cartridge for use in Savin® C 3224, 3828

9570

Replacement Black toner cartridge for use in Savin® 2235, 2238, 2245, 2535,2545

13802

**SHARP®**

Replacement black toner cartridge for use in Sharp AR 330, 400 NT

5326

Replacement black toner cartridge for use in Sharp SF 2022, 2027, 2035

222NT, 235NT

5977

Replacement black toner cartridge for use in Sharp SF 2216, 2220

(226NT)

7662

Replacement black toner cartridge for use in Sharp SF 2025,2030,2530,2040,2540

SF230,240NT

8984

Replacement black toner cartridge for use in Sharp AR 5120, 5015, 5220

AR016T,FT,ST

11601

(not for USA region)

Replacement black toner cartridge for use in Sharp AR 650, 800, 850

(AR650NT)

11641

Replacement black toner cartridge for use in Sharp™ SF 2050, 2052, 2060, 3062, 2260

AR360NT

12881

Replacement black toner cartridge™ for use in Sharp AR-M 162, 163, 164, 201

AR 201

13320

Replacement black toner cartridge for use in Sharp AR M 351, 355, 451, 455

AR455NT

14372

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| OEM #  | UNINET PART #   | SPECIAL CHARACTERISTICS |   |
|--|-----------------|-------------------------|---|
| Replacement Black toner cartridge for use in Sharp® MX 2300, 2700                                  | MX27NTBA        | 14715                   | USA, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE    |
| Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700                                   | MX-27NTCA       | 14716                   | USA, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE    |
| Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700                                | MX-27NTMA       | 14717                   | USA, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE    |
| Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700                                 | MX-27NTYA       | 14718                   | USA, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE    |
| Replacement Black toner cartridge for use in Sharp® MX 2300, 2700                                  | MX27GTBA        | 14719                   | Europe, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700                                   | MX27GTCA        | 14720                   | Europe, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700                                | MX27GTMA        | 14721                   | Europe, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700                                 | MX27GTMA        | 14722                   | Europe, THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Black toner cartridge for use in Sharp® MX 3501, 4501                                  | MX45NTBA        | 14723                   |   |
| Replacement Cyan toner cartridge for use in Sharp® MX 3501, 4501                                   | MX45NTCA        | 14724                   |   |
| Replacement Magenta toner cartridge for use in Sharp® MX 3501, 4501                                | MX45NTMA        | 14725                   |   |
| Replacement Yellow toner cartridge for use in Sharp® MX 3501, 4501                                 | MX45NTYA        | 14726                   |   |
| Replacement black toner cartridge for use in Sharp AL 2021, 2031, 2041, 2051                       | AL-204TD        | 16521                   |   |
| Replacement black toner cartridge for use in Sharp AR M 208, 236, 237, 256,257, 276, 277, 316, 317 | AR270NT/310NT/T | 17359                   |   |
| Replacement black toner cartridge for use in Sharp MX-M 283,363,453, 503                           | MX500GT/NT      | 17447                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE         |
| Replacement black toner cartridge for use in Sharp MX M 260  | MX312GT/N       | 17588                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE         |
| Replacement black toner cartridge for use in Sharp MX-M 200 D                                      | MX-206NT        | 17849                   | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE         |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                   | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>   |
|--|--------------|----------------------|--|
| Replacement Black toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501                       | MX45NTB      | 17866                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE<br>THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE<br>THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE<br>THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement Cyan toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501                        | MX45NTB      | 17867                |  |
| Replacement Magenta toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501                     | MX45NTB      | 17868                |  |
| Replacement Yellow toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501                      | MX45NTB      | 17869                |  |
| Replacement black toner cartridge for use in Sharp AR 5516, 5520                                   | AR020T       | 18029                |  |
| Replacement Black toner cartridge for use in Sharp MX 2600, 2601N, 3100N                           | MX-31NTBA    | 18807                |  |
| Replacement Cyan toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001    | MX31-C       | 18808                |  |
| Replacement Yellow toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001  | MX31Y        | 18809                |  |
| Replacement Magenta toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001 | MX31-M       | 18810                |  |
| Replacement toner cartridge for Sharp AR 100, AL-1000  | AL-100TD     | 19457                |  |
| Replacement Black toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402                   | MX-C40NTB    | 19527                |  |
| Replacement Cyan toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402                    | MX-C40NTC    | 19528                |  |
| Replacement Magenta toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402                 | MX-C40NTM    | 19529                |  |
| Replacement Yellow toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402                  | MX-C40NTY    | 19530                |  |
| Replacement Black toner cartridge for use in Sharp® MX 5500, 6200, 7000                            | MX70NTBA     | 19531                |  |
| Replacement Black toner cartridge for use in Sharp MX 5001, 5000, 4101, 4100                       | MX-50NTBA    | 20297                |  |
| Replacement toner cartridge for use in Sharp® MX-M 565, 564, 465, 464, 365, 364                    | MX560GT/NT   | 20418                |  |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>   | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Replacement Black toner cartridge for use in Sharp® MX-C 301, 300, 250   | MX-C30NTB    | 20703                |                                |
| Replacement Cyan toner cartridge for use in Sharp® MX-C 301, 300, 250  | MX-C30NTC    | 20705                |                                |
| Replacement Magenta toner cartridge for use in Sharp® MX-C 301, 300, 250   | MX-C30NTM    | 20706                |                                |
| Replacement Yellow toner cartridge for use in Sharp® MX-C 301, 300, 250  | MX-C30NTY    | 20707                |                                |
| Replacement Black toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310   | MX-23GTBA    | 21085                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU   | MX-23GTCA    | 21086                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU  | MX-23GTMA    | 21087                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU   | MX-23GTYA    | 21088                |                                |
| Replacement Black toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310   | MX-23NTBA    | 21089                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310  | MX-23NTCA    | 21090                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310   | MX-23NTMA    | 21091                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310  | MX-23NTYA    | 21092                |                                |
| Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050                   | MX-60NTBA    | 21170                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050                    | MX-60NTCA    | 21171                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050                 | MX-60NTMA    | 21172                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050                  | MX-60NTYA    | 21173                |                                |
| Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050 | MX-60GTBA    | 21174                |                                |

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>   | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|--------------|----------------------|--------------------------------|
| Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                    | MX-60GTCA    | 21175                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050 (special order) | MX-60GTMA    | 21176                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                  | MX-60GYA     | 21177                |                                |
| Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                   | MX-60FTBA    | 21178                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                    | MX-60FTCA    | 21179                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                 | MX-60FTMA    | 21180                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050                  | MX-60FTYA    | 21181                |                                |
| Replacement Black toner cartridge for use in Sharp MX M 356, 316, 266  | MX-315NT     | 21258                |                                |
| Replacement Black toner cartridge for use in Sharp MX M 356, 316, 266  | MX-315GT     | 21259                |                                |
| Replacement Black toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610   | MX-36NTBA    | 21288                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610  | MX-36NTCA    | 21289                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610   | MX-36NTMA    | 21290                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610  | MX-36NTYA    | 21291                |                                |
| Replacement Black toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP   | MX-51NTBA    | 21292                |                                |
| Replacement Cyan toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP  | MX-51NTCA    | 21293                |                                |
| Replacement Magenta toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP   | MX-51NTMA    | 21294                |                                |
| Replacement Yellow toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP  | MX-51NTYA    | 21295                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION****OEM #****UNINET PART #****SPECIAL CHARACTERISTICS****REPLACEMENT DRUM UNIT CARTRIDGE**

Replacement drum unit cartridge for use in Sharp AL 1000

AL100DR

19441

Replacement drum unit cartridge for use in Sharp FO-2081

FO55DR

17836

**TOSHIBA®**

Replacement copier black toner cartridge for use in Toshiba T 1550,1560

5960

Replacement black toner cartridge for use in Toshiba T 5560, 6560

5981

Replacement black toner cartridge for use in Toshiba T 1650, 1710, 2050, 2500

7967

Replacement black toner cartridge for use in Toshiba T 3550, 4550

7971

Replacement black toner cartridges for use in Toshiba T 120

8048

Replacement black toner cartridge for use in Toshiba E Studio 28, 35, 45, T 3500

8831

USA

Replacement black toner cartridge for use in Toshiba E Studio 16, 160, T 1600

8832

Replacement black toner cartridge for use in Toshiba E Studio 20, 25, T 2500

8989

Replacement black toner cartridge for use in Toshiba E Studio 55, 65, 80, T 6570

8990

USA



| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                             | <b>OEM #</b>   | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b>                |
|--|----------------|----------------------|---|
| Replacement black toner cartridge for use in Toshiba e Studio 163, 165, 203, 205             | T1640          | 11566                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 350, 352, 450, 452             | T-3520         | 11686                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 620, 600, 720, 850,            | T-6000, T6000E | 11687                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 200L, 202L, 230, 232, 280, 282 | T-2320, 2340E  | 11688                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 161,                           | T 1620         | 11689                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 55, 65, 80                     | T6570E         | 11690                | Europe  |
| Replacement black toner cartridge for use in Toshiba e Studio 28, 35, 45,                    | T 3500         | 11841                | Europe  |
| Replacement black toner cartridge for use in Toshiba E Studio T 203L, 233, 283,              | T2840          | 12595                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 12, 15, 120, 150,              | T1200          | 13430                |   |
| Replacement black toner cartridge for use in Toshiba e-Studio 202S, 203S,                    |                | 13953                |   |
| Replacement black toner cartridge for use in Toshiba e-Studio 242,212, 182, 181,             | T1810          | 15869                |   |
| Replacement black toner cartridge for use in Toshiba e Studio 205, 255, 305, 355, 455        | T4530          | 15883                |   |
| Replacement black toner cartridge for use in Toshiba E studio 195, 225, 243, 245             | T2450          | 17589                | THIS IS AN EASY TO<br>REMANUFACTURE CARTRIDGE |
| Replacement toner cartridge Black for use in Toshiba e-Studio 2820, 2830, 2330               | TCF28          | 18504                |   |
| Replacement toner cartridge Cyan for use in Toshiba e-Studio 2820, 2830, 2330                | TCF28          | 18505                |   |
| Replacement toner cartridge Magenta for use in Toshiba e-Studio 2820, 2830, 2330             | TCF28          | 18506                |   |
| Replacement toner cartridge Yellow for use in Toshiba e-Studio 2820, 2830, 2330              | TCF28          | 18507                |   |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                                | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|--------------|----------------------|--------------------------------|
| Replacement toner cartridge for use in Toshiba e Studio 550 , 650, 810                          | T6510        | 19614                |                                |
| Replacement toner cartridge for use in Toshiba e Studio 855, 853, 755, 723, 655, 603, 555, 523, | T7200, T8550 | 19263                |                                |
| Replacement toner cartridge for use in Toshiba e-STUDIO 206L, 256, 306, 356, 506                | T4590        | 19878                |                                |
| Replacement Black toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040      | TFC25K       | 21296                |                                |
| Replacement Cyan toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040       | TFC25C       | 21297                |                                |
| Replacement Magenta toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040    | TFC25M       | 21298                |                                |
| Replacement Yellow toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040     | TFC25Y       | 21299                |                                |
| Replacement Black toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040      | TFC25EK      | 21300                |                                |
| Replacement Cyan toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040       | TFC25EC      | 21301                |                                |
| Replacement Magenta toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040    | TFC25EM      | 21302                |                                |
| Replacement Yellow toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040     | TFC25EY      | 21303                |                                |

**XEROX®**

|   |             |      |  |
|---|-------------|------|--|
| Replacement toner cartridge for use in Xerox 1012             | 6R257       | 741  |  |
| Replacement toner cartridge for use in Xerox 5614, 5114, 5113 | 6R751,6R752 | 7724 |  |
| Replacement cartridge for use in Xerox WorkCentre Pro 421     | 106R647     | 8825 |  |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                             | <b>OEM #</b>      | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|--|-------------------|----------------------|--------------------------------|
| Replacement toner cartridge for use in Xerox XD 100  | 6R914             | 8985                 |                                |
| Absolute Black® Replacement toner cartridge for use in Xerox Phaser 6110                     | 106R01274         | 12764                |                                |
| Absolute Magenta® Replacement toner cartridge for use in Xerox Phaser 6110                   | 106R01272         | 12765                |                                |
| Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6110                    | 106R01273         | 12766                |                                |
| Absolute Cyan® Replacement toner cartridge for use in Xerox Phaser 6110                      | 106R01273         | 12768                |                                |
| Replacement Black toner cartridge for use in Xerox Phaser 3160, 3155, 3140                   | 108R00909         | 12854                |                                |
| Replacement toner cartridge, Black for use in Fuji Xerox Docuprint C 1190 FS                 | CT201260          | 14956                |                                |
| Replacement toner cartridge, Cyan for use in Fuji Xerox Docuprint C 1190 FS                  | CT201261          | 14957                |                                |
| Replacement toner cartridge, Magenta for use in Fuji Xerox Docuprint C 1190 FS               | CT201262          | 14958                |                                |
| Replacement toner cartridge, Yellow for use in Fuji Xerox Docuprint C 1190 FS                | CT201263          | 14959                |                                |
| Replacement Black toner cartridge for use in Xerox Phaser 7400                               | 10106R01080       | 15719                |                                |
| Replacement Cyan toner cartridge for use in Xerox Phaser 7400                                | 10106R01077       | 15720                |                                |
| Replacement Magenta toner cartridge for use in Xerox Phaser 7400                             | 10106R01078       | 15721                |                                |
| Replacement Yellow toner cartridge for use in Xerox Phaser 7400                              | 10106R01079       | 15722                |                                |
| Replacement toner cartridge for use in Xerox DocuCentre 535, 545, 555                        | 6R1046,006R010446 | 15933                |                                |
| Replacement toner cartridge for use in Xerox WorkCentre 232, 238, 245, 255, 5665, 5675, 5687 | 006R01146         | 16253                |                                |
| Replacement toner cartridge for use in Xerox WorkCentre M 20, C 20                           | 106R01047         | 16496                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

| <b>COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION</b>                | <b>OEM #</b> | <b>UNINET PART #</b> | <b>SPECIAL CHARACTERISTICS</b> |
|---|--------------|----------------------|--------------------------------|
| Replacement drum cartridge for use in Xerox WorkCentre M 20, C 20               | 113R00671    | 16497                |                                |
| Replacement Black toner cartridge for use in Xerox Phaser 6128 MFP              | 106R01459    | 16720                |                                |
| Replacement Cyan toner cartridge for use in Xerox Phaser 6128 MFP               | 106R01456    | 16721                |                                |
| Replacement Magenta toner cartridge for use in Xerox Phaser 6128 MFP            | 106R01457    | 16722                |                                |
| Replacement Yellow toner cartridge for use in Xerox Phaser 6128 MFP             | 106R01458    | 16723                |                                |
| Replacement toner cartridge for use in Xerox Phaser 4510                        |              | 17534                |                                |
| Replacement Black toner cartridge for use in Xerox Phaser 6140                  |              | 18041                |                                |
| Replacement Cyan toner cartridge for use in Xerox Phaser 6140                   |              | 18042                |                                |
| Replacement Magenta toner cartridge for use in Xerox Phaser 6140                |              | 18043                |                                |
| Replacement Yellow toner cartridge for use in Xerox Phaser 6140                 |              | 18044                |                                |
| Replacement toner cartridge for Xerox WorkCentre 3550                           | 106R01531    | 19599                |                                |
| Replacement toner cartridge for use in Xerox Phaser 3040, 3010, WorkCentre 3045 | 106R02182    | 19702                |                                |
| Absolute Black® replacement toner cartridge for use in Xerox Phaser 6700        |              | 20208                |                                |
| Absolute Cyan® replacement toner cartridge for use in Xerox Phaser 6700         |              | 20209                |                                |
| Absolute Magenta® replacement toner cartridge for use in Xerox Phaser 6700      |              | 20210                |                                |
| Absolute Yellow® replacement toner cartridge for use in Xerox Phaser 6700       |              | 20211                |                                |

**COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**

**OEM #**

**UNINET PART #**

**SPECIAL CHARACTERISTICS**

**REPLACEMENT DRUM UNIT CARTRIDGE**

Replacement drum unit cartridge for use in Xerox XD 100

13R551

8986