

➡ **COPIER SUPPLIES & PARTS CATALOG**

➡ **COPIER REPLACEMENT TONER CARTRIDGES CATALOG**

➡ **DOWNLOAD FORMS**

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****CANON®****CANON IMAGERUNNER 400, 330**

Uni Drum™ F with gears for use in Canon Imagerunner 330, 400	7316
SuMMiT® drum with gears for us in Canon IR 3320, 330, 2800, 2200, 400, 330, 220, 210, 200	12715
Uni Drum™ with gears for use in Canon Imagerunner 330, 400	12896
Wiper blade for use in Canon Imagerunner 330, 400	14593
Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030	19526

CANON IMAGERUNNER 6000, 5000, 600, 550

Absolute Black® toner for use in Canon Imagerunner 6000, 5000 (10K bag)	11038
Pick-Off finger upper for use in Canon iR 550, 5000, 5075, 6000, NP 6050, 6551, 6570, 7500	12122
Upper fuser heat roller for use in Canon IR 6020, 6000, 5000	16241
Absolute Black® toner for use in Canon Imagerunner 600, 550	17093
Absolute Black® toner for use in Canon IR 6000, 5000	18348
Paper pickup roller for use in Canon IR 550, 600, 5000, 6000, 7200	19348
Front Upper Fuser Roller Gear 52T for use in Canon IR 6000, 5000	19352
Upper Picker Finger for use in Canon iR 8500, 7200, 7105, 7095, 7086, 6570, 6020, 6000, 5570, 6065, 5055, 5050, 5020, 5000	19678

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****CANON IMAGERUNNER 1018, 1019, 1020, 1022, 1023, 1024, 1025**

SuMMiT® drum with gears for use in Canon™ Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025

17488

PCR for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024, 1025

17807

Absolute Black® toner for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024,1025

17843

Absolute Black® toner for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024,1025, 465g

18595

Wiper Blade for use in Canon IR 1025, 1024, 1023, 1022, 1019, 1018

19188

CANON IMAGERUNNER 1600, 2000, 2010

Absolute Black® toner for use in Canon IR 1600, 2000, 2010

6027

Clear Seal™ adhesive for use in Canon IR 1600, 2000, 2010

6949

Black Mag roller sleeve for use in Canon IR 1600, 2000, 2010

7161

Uni Drum™ with gears for use in Canon IR 1600, 2000, 2010

12716

X-Generation® Wiper blade for use in Canon IR 1600, 2000, 2010

17933

CANON IMAGERUNNER 2016, 2018, 2020, 2022, 2025, 2030

Uni Drum™ with gears for use in Canon IR 2016, 2020

12892

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Wiper blade for use in Canon IR 2016, 2020 12898

SuMMiT® OPC drum with gears for use in Canon IR Advance C 2030, 2020, 2016 GPR-36 19407

CANON IMAGERUNNER 2200, 2300, 2800, 3300

Uni Drum™ F with gears for use in Canon IR 2200, 2800, 3300 7056

Wiper blade for use in Canon IR 2200, 2800, 3300 , 10068

SuMMiT™ drum with gears for use in Canon IR 2200, 2800, 3300 12715

Absolute Black® toner for use in Canon IR 2200, 2800, 3300 16710

Fuser film for use in Canon IR 3300, 2800, 2200 19829

Fixing Film Assembly unit for use in Canon IR 2200, 2800, 3300, 3320 19637

CANON IMAGERUNNER 6000, 5000, 7095, 7085, 7200, 8500, NP 6050, 6020, 6551, 6570, 5570, 550, 600

Absolute Black® toner for use in Canon IR 6000, 5000 11038

Pick-Off finger upper for use in Canon iR 550, 5000, 5075, 6000, NP 6050, 6551, 6570, 7500, FB5-3625-000, FB5-8727-00 12122

Heat roller for Canon IR 5000, 6000 16241

Absolute Black® toner for use in Canon IR 6000, 5000, 1500g 18348

Upper fuser roller for use in Canon IR 9070, 8500, 8070, 7200, 7105, 7095, 7086, 105, 85 19346

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Paper pickup roller for use in Canon IR 550, 600, 5000, 6000, 7200	19348
Paper feed pick up roller for use in Canon iR 6570, 6020, 6000, 5570, 5050, 5020, 5000, FF5-9779-000, FB5-3435-000	19353
Lower fuser pressure roller for use in Canon IR 6020, 6000, 5000, FB5-3619-000	19460
Fuser Cleaning web for use in Canon IR 8500, 7200, 7105, 7095, 7085, 6570, 6020, 6000, 5070, 5065, 5050, 5020, 5000, 600, 500, 105, FY1-1157-000	19461
Lower fuser roller bearing for use in Canon IR 6020, 6000, 5020, 5000, 600, 60, XG9-0018-000	19675
Upper Picker Finger for use in Canon iR 8500, 7200, 7105, 7095, 7086, 6570, 6020, 6000, 5570, 6065, 5055, 5050, 5020, 5000, FA2-9037-000	19678

CANON IMAGERUNNER C 3380, 2880, 2550, 3480

Absolute Black® toner for use in Canon IR C 3380, 2880, 2550, 3480	13003
Absolute Cyan™ toner for use in Canon IR C 3380, 2880, 2550, 3480	13004
Absolute Magenta™ toner for use in Canon IR C 3380, 2880, 2550, 3480	13005
Absolute Yellow™ toner for use in Canon IR C 3380, 2880, 2550, 3480	13006
Uni Drum® with gears for use in Canon IR C 3580, 3480, 3380, 3080, 2880, 2550, 2380, GPR 23	19241
Fuser film OEM for use in Canon IR C 3580, 3380, 3080, 2880, 2380, FM3-1994	19831

CANON IMAGERUNNER C 3100, 3170

Black toner for use in Canon IR C 3100, 3170	11110
--	-------

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Cyan toner for use in Canon IR C 3100, 3170

11111

Magenta toner for use in Canon IR C 3100, 3170

11112

Yellow toner for use in Canon IR C 3100, 3170

11113

CANON EP 105, MF 7280, 7460, 7470, 7480 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11591

Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11590

Clear Seal™ adhesive with foam for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11595

Mag roller for use in Canon EP 105, MF 7280, 7460, 7470, 7480

11596

SuMMiT™ drum with gears for use in Canon EP 105, MF 7280, 7270, 7260, 7240

11592

CANON GP 200

Drum for use in Canon GP 200 F

7411

Uni Drum™ with gears for use in Canon GP 200

12895

Wiper blade for use in Canon GP 200

12897

CANON GP 40

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Canon GP 40

7235

Drum with gears for use in Canon GP 40

7181

CANON NP 6012, 6016

Uni Drum™ F with gears for use in Canon NP 6012, 6014,

11397

Uni Drum™ S with gears for use in Canon NP 6012, 6014,

12540

CANON NP 1510, 1215, 2120

Uni Drum™ F w/gears for use in Canon NP 1215, 2020, 2120

102

X-Generation® Wiper blade for use in Canon NP 1510, 1215, 2020, 2120

105

Uni Drum™ with gears for use in Canon NP 1215, 2020, 2120

12539

Absolute Black® toner for use in Canon NP 1510, 1215, 2120

16045

Absolute Black® toner for use in Canon NP 1510, 1215, 2120

16564

CANON NP 3030, 3050, 4050, 4080

Wiper blade for use in Canon NP 3325, 3030, 4050, 4835

7141

Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030

19526

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****CANON NP 6030, 6025, 6330, NPG 7**

Uni Drum™ F with gears for use in Canon NP 6030, 6025, 6330

7409

Absolute Black® toner for use in Canon NP 6030, 6025, 6330, NPG 7

8295

Uni Drum™ drum for use in Canon NP 6030, 6025, 6330

8545

Fuser Cleaning web for use in Canon C 250, 300, 400, IR 330, 400, NP 3025, 3030, 3050, 3225, 3325, 3525, 3725, 3825, 4035, 4040, 4080, 4540, 4835, 6025, 6230, 6330, 6545, 7050, 8070, 9030

19526

CANON NP 6045, 6050, 6060, 6085

Absolute Black® toner for use in Canon NP 6045, 6050, 6060, 6085

11746

DELCO AVANTI®**DELCO AVANTI 2600, 2650, 2690**

Absolute Black® toner for use in Delcop Avanti 2600, 2650, 2690

17939

Drum unit cover for use in Delcop Avanti 2600, 2650, 2690

17942

Smartchip® for use in Delcop Avanti 2600, 2650, 2690

17934

Uni Drum® with gears for use in Delcop Avanti 2600, 2650, 2690

17940

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****EPSON®****EPSON ACULASER C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ Black for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF	12526
Smartchip™ Cyan for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF	12527
Smartchip™ Magenta for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF	12528
Smartchip™ Yellow for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF	12529
Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	16659
Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	16660
Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	16661
Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	16662
Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	17344
Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	17345
Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	17346
Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C	17347

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****EPSON ACULASER M 1400, MX 14 NF (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF

16675

Smartchip™ Black for use in Epson Aculaser M 1400, MX 14 NF

16676

Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF

17553

EPSON ACULASER M 2400, 2300, MX 20 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20

16750

Smartchip™ for use in Epson Aculaser M 2400, MX 20, C13S050582

16750

Absolute Black® toner for use in Epson Aculaser M 2400, 2300, MX 20

17252

Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20

17438

Smartchip™ for use in Epson Aculaser M 2300, 2400, MX 20, C13S050583

19297

FUJI XEROX ®**FUJI XEROX DOCUPRINT C 2250, 3360, DOCUCENTRE C 2205, 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305

18295

Smartchip® CMYK drum unit for use in Fuji Xerox DocuPrint C 3360, 2250

18305

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****FUJI XEROX DOCUPRINT C 3305, 2205 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip® CMYK drum unit for use in Fuji Xerox DocuPrint C 3305, 2205 18306

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305 18295

FUJI XEROX DOCUPRINT C 3350

Smartchip® Black for use in Fuji Xerox Docuprint C 3350 18020

Smartchip® Cyan for use in Fuji Xerox Docuprint C 3350 18021

Smartchip® Magenta for use in Fuji Xerox Docuprint C 3350 18022

Smartchip® Yellow for use in Fuji Xerox Docuprint C 3350 18023

Absolute Black® toner for use in Fuji Xerox Docuprint C 3350 18024

Absolute Cyan® toner for use in Fuji Xerox Docuprint C 3350 18025

Absolute Magenta® toner for use in Fuji Xerox Docuprint C 3350 18026

Absolute Yellow® toner for use in Fuji Xerox Docuprint C 3350 18027

Absolute Cyan® toner for use in Fuji Xerox Docuprint C 3350 19771

Absolute Black® toner for use in Fuji Xerox Docuprint C 3350 19770

Absolute Magenta® toner for use in Fuji Xerox Docuprint C 3350 19772

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow® toner for use in Fuji Xerox Docuprint C 3350

19773

FUJI XEROX DOCUPRINT C 1190 FS

Smartchip® Black for use in Fuji Xerox Docuprint C 1190 FS

14895

Smartchip® Cyan for use in Fuji Xerox Docuprint C 1190 FS

14896

Smartchip® Magenta for use in Fuji Xerox Docuprint C 1190 FS

14897

Smartchip® Yellow for use in Fuji Xerox Docuprint C 1190 FS

14898

X-Generation® Black toner for use in Fuji Xerox Docuprint C 1190 FS

14899

X-Generation® Cyan toner for use in Fuji Xerox Docuprint C 1190 FS

14900

X-Generation® Magenta toner for use in Fuji Xerox Docuprint C 1190 FS

14901

X-Generation® Yellow toner for use in Fuji Xerox Docuprint C 1190 FS

14902

FUJI XEROX DOCUPRINT C 5000

Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000, 5005

17036

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000, 5005

17045

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint C 5000, 5005

17046

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000, 5005

17047

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000

17584

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000

17585

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000

17587

FUJI XEROX DOCUPRINT CM 505

Smartchip™ Black toner for use in Fuji Xerox Docuprint CM 505

17037

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CM 505

17038

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CM 505

17039

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CM 505

17040

X-Generation® Black toner for use in Fuji Xerox Docuprint CM 505 16,000 pages

18944

X-Generation® Cyan toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18945

X-Generation® Magenta toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18946

X-Generation® Yellow toner for use in Fuji Xerox Docuprint CM 505 12,000 pages

18947

FUJI XEROX DOCUPRINT CP 305, CM 305

Smartchip™ Black toner for use in Fuji Xerox Docuprint CP 305, CM 305

17041

Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305

17042

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305

17043

Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305

17044

X-Generation® Black toner for use in Fuji Xerox Docuprint CP 305, CM 305

17935

X-Generation® Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305

17936

X-Generation® Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305

17937

X-Generation® Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305

17938

C 2250, 3360, DOCUCENTRE C 2205, 3305

X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305

18295

FUJI XEROX DOCUCENTRE IV C 4430 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Fuji Xerox Docucentre IV C4430

17276

Absolute Cyan® toner for use in Fuji Xerox Docucentre IV C4430

17277

Absolute Magenta® toner for use in Fuji Xerox Docucentre IV C4430

17278

Absolute Yellow® toner for use in Fuji Xerox Docucentre IV C4430

17279

Smartchip® Black toner for use in Fuji Xerox Docucentre IV C4430

17286

Smartchip® Cyan toner for use in Fuji Xerox Docucentre IV C4430

17287

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Magenta toner for use in Fuji Xerox Docucentre IV C4430	17288
Smartchip® Yellow toner for use in Fuji Xerox Docucentre IV C4430, CT201679	17289
Smartchip® Black drum unit for use in Fuji Xerox Docucentre IV C4430	17469
Smartchip® Cyan drum unit for use in Fuji Xerox Docucentre IV C4430	17470
Smartchip® Magenta drum unit for use in Fuji Xerox Docucentre IV C4430	17471
Smartchip® Yellow drum unit for use in Fuji Xerox Docucentre IV C4430	17472

FUJI XEROX DOCUPRINT M 265, 225, P 265, 225

High Yield Reset Lever Gear for use in Fuji Xerox Docuprint M 265, 225, P 265, 225	19970
High Yield Reset Lever Gear w/ Spring and Fill Plug for use in Fuji Xerox DocuPrint P 265, 260, 225, M 265, 260z, 225	21048

HP®**HP CM 6030, 6040 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in HP CP 6015, CM 6030, 6040	13294
Absolute Black® toner for use in HP CP 6015, CM 6030, 6040	13290
Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040	13295

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040

13291

Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040

13296

Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040

13292

Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040

13297

Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040

13293

ASiC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040

15253

ASiC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040

13765

ASiC Smartchip® Black toner for use in HP CP 6015, CM 6030

15257

ASiC Smartchip® Black toner for use in HP CP 6015, CM 6030

13298

ASiC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040

15254

ASiC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040

13766

ASiC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040

15258

ASiC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040

13299

ASiC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040

15255

ASiC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040

13767

ASiC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040

15259

ASiC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040

13300

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040	15256
ASiC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040	13768
ASiC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040	15260
ASiC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040	13301
SuMMiT™ OPC drum with gears for use in HP CP 6015, CM 6030, 6040	13769
X-Generation® Wiper blade for use in HP CM 6040 MFP	16558
Uni Drum™ OPC with gears for use in HP CP 6015, CM 6030, 6040	16755
Drum cover for use in HP Color LaserJet CP 6015, CM 6040, 6030 MFP	20444

HP LASERJET PRO 401, MFP M425

Soft PCR roller for use in HP Laserjet Pro 401, MFP M425	7080
Seal pull tab for use in HP Laserjet Pro 401, MFP M 425	9955
Seal exit port plug for use in HP M 401, 425 MFP	9957
Universal Jumbo waste toner hopper conversion kit for use in HP M 401, 425 MFP	17450
Soft PCR roller for use in HP Laserjet Pro 401, MFP M 425	18610

HP CM 1312, 2320 MFP, M 476, 251, 276 MFP, Canon MF 8050

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ with gears for use in HP CM 1312, 2320 MFP, M 476, 251, 276 MFP, Canon MF 8050	12610
X-Generation® Wiper blade for use in HP CM 1312, 1415, 2320, Color Pro M 251, 276, 375, 451, 475, 476 MFP, Canon MF 8050,	12611
Seal pull tab for use in HP CM 1312, 1415, 476 MFP	13022
Shipping drum cover lock for use in HP CM 1312, 1415 MFP	13025
X-Generation® Black toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)	13537
X-Generation® Cyan toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)	13539
X-Generation® Magenta toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050 (MPT-251)	13541
X-Generation® Yellow toner for use in HP CM 1312, 1415 MFP, Canon LBP 5050, MF 8050)(MPT-251)	13543
X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451, (10 kg) bag (MPT-251)	13544
Supply roller for use in HP CM 1312 MFP	14077

HP CM 2320 MFP

X-Generation® Black toner for use in HP CM 2320 MFP (MPT-2025)	13271
X-Generation® Cyan toner for use in HP CM 2320 MFP (MPT-2025)	13272
X-Generation® Magenta toner for use in HP CM 2320 MFP (MPT-2025)	13273
X-Generation® Yellow toner for use in HP CM 2320 MFP (MPT-2025)	13274
Seal pull tab for use in HP CM 2320 MFP	13850

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Waste section for use in HP CM 2320 MFP	14739
X-Generation® Black toner for use in HP CM 2320 MFP (MPT-251)	20114
X-Generation® Cyan toner for use in HP CM 2320 MFP (MPT-251)	20115
X-Generation® Magenta toner for use in HP CM 2320 MFP (MPT-251)	20116
X-Generation® Yellow toner for use in HP CM 2320 MFP (MPT-251)	20117

HP CM 3530 MFP, M 551, 575

X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575	13650
X-Generation® Cyan toner for use in HP CM 3530 MFP, M 551, 575	13651
X-Generation® Magenta toner for use in HP CM 3530 MFP, M 551, 575	13652
X-Generation® Yellow toner for use in HP CM 3530 MFP, M 551, 575	13653
X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575	13654
Uni Drum™ with gears for use in HP CM 3530, 3525 MFP, Laserjet 500, M 551, M 651	13655
Smartchip™ Black for use in HP CM 3530 MFP	13715
SuMMiT® drum with gears for use in HP CM 3530, 3525 MFP	13934
Wiper blade for use in HP CM 3530, 4540 MFP, M 551, 575, 651	14503
X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)	18212

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Cyan toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)

18213

X-Generation® Magenta toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)

18214

X-Generation® Yellow toner for use in HP CM 3530 MFP, M 551, 575 (MPT-4525)

18215

X-Generation® Black toner for use in HP CM 3530 MFP, M 551, 575 (MPT 4525)

18230

HP CM 4540 MFP

X-Generation® Black toner for use in HP CM 4540 MFP (MPT-4525)

14996

X-Generation® Cyan toner for use in HP CM 4540 MFP (11,000 pages)

14997

X-Generation® Magenta toner for use in HP CM 4540 MFP

14998

X-Generation® Yellow toner for use in HP CM 4540 MFP

14999

X-Generation® Black toner for use in HP CM 4540 MFP (MPT-4525)

15033

Uni Drum™ with gears for use in HP CM 4540 MFP, M 551, 575 (with longer hub)

17523

HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451

SuMMiT® drum with gears for use in HP M 251, 276, 375, 451, 475, 476 MFP, Canon MF 8050 (X-Generation®)

13220

X-Generation® Black toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (10 kg) bag (MPT-251)

13538

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Cyan toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (10 kg) bag (MPT-251) 13540

X-Generation® Magenta toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451, (10 kg) bag (MPT-251) 13542

X-Generation® Black toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17910

X-Generation® Cyan toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17911

X-Generation® Magenta toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17912

X-Generation® Yellow toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 17913

X-Generation® Black toner for use in HP Laserjet Pro 200 M 251, 276 MFP (MPT-251) 18030

X-Generation® Black toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18266

X-Generation® Cyan toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18267

X-Generation® Magenta toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18268

X-Generation® Yellow toner for use in HP M 251, 252, 276, CM 1312, 1415, 2320, Pro 300, 400, MFP M 277, 351, 375, 475, 451 (MPT-251) 18269

Waste section for use in HP Laserjet Pro 200, M 251, 276, CP 1525, 1215,1515,1518, CM 1312, 1415 MFP 18346

X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 252, MFP M 277 20693

X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 252, MFP M 277 20727

HP LASERJET PRO 300, 400, MFP M 351, 375, 475, 451

SuMMiT® drum with no gears for use in HP Pro 400, MFP M 425 13372

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMiT® drum with no drive gear for use in HP Pro 402, 401, 400, MFP M 527, 426, 425	14013
Wiper blade for use in HP Pro 400, MFP M 425	16147
X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451	17142
X-Generation® Cyan toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	17143
X-Generation® Magenta toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451	17144
X-Generation® Yellow toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451	17145
X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451	17148
SuMMiT® drum with gears for use in HP Laserjet 300, 400, CM 1312, 1415, 2320, M 375, 475, 451 MFP, Canon MF 8050	17414
X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	18207
X-Generation® Cyan toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	18208
X-Generation® Magenta toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	18209
X-Generation® Yellow toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	18210
X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 475, 451 (MPT-251)	18211

HP M 226, 225, 202, 201, 127, 125 MFP, M 26, 12, Canon MF 227, 212

SuMMiT® drum with gears for use in HP M 202, 201, MFP M 226, 225, 127, 125, 26, 12	12740
Wiper blade for use in HP M 226, 225, 202, 201, 127, 125 MFP, M 26, 12, Canon MF 227, 212	16139

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****HP LASERJET PRO M 447, 337, 277 MFP, M 252**

X-Generation® Black toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20158
X-Generation® Cyan toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20159
X-Generation® Magenta toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20160
X-Generation® Yellow toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20161
SuMMiT® drum for use in for use in HP Color LaserJet Pro M 477, 277 MFP, M 452, 252	20167
SuMMiT® drum with gears for use in for use in HP Color LaserJet Pro M 277 MFP, M 252	20223
SuMMiT® OPC drum gearless for use in for use in HP Color LaserJet Pro M 277 MFP, M 252	20230
X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252)	20232
X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252)	20233
X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252)	20234
X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (MPT-252)	20235
X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252)	20236
X-Generation® Cyan glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252)	20237
X-Generation® Magenta glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252 (10 kg) bag (MPT-252)	20238
X-Generation® Yellow glossy toner for use in HP Color LaserJet Pro M 477, 277 MFP, M 553, 552, 452, 252(10 kg) bag (MPT-252)	20239

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 552, 553 (MPT-252)	20303
X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 553, 552, 553 (MPT-252)	20304
X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)	20305
X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452, 552, 553 (MPT-252)	20306
X-Generation® Black toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20367
X-Generation® Cyan toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20368
X-Generation® Magenta toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20369
X-Generation® Yellow toner for use in HP Color LaserJet Pro M 277 MFP, M 252 (MPT-252)	20370
Wiper blade for use in HP Color LaserJet Pro M 477, 277 MFP, M452, 252	20422
X-Generation® Black toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)	20644
X-Generation® Cyan toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)	20645
X-Generation® Magenta toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)	20646
X-Generation® Yellow toner for use in HP Color LaserJet Pro M 477, 377 MFP, M 452 (MPT-252)	20647
X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 452, MFP M 477	20653
X' version high yield toner hopper with seal for use in HP Color Laserjet Pro M 452, MFP M 477	20728
Uni Drum® with gears for use in for use in HP Color LaserJet Pro M 477, 277 MFP, M 452, 252	21198

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****HP M 506, 501, MFP M 527, M 402, MFP M 426**

X-Generation® toner for use in HP M 506, 501, MFP M 527, M 402, MFP M 426

20293

X-Generation® toner for use in HP M 506, 501, 402, MFP M 527, 426 (10 kg) bag

20383

Wiper blade for use in HP Laserjet Enterprise M 506, 501, MFP 527, Pro 402, MFP 426

20463

X-Generation® Black toner for use in HP M 402, 426 MFP

20695

X-Generation® Black toner for use in HP M 506, 501, 402, MFP M 527, 426

20909

X-Generation® black toner for use in HP M 506, 501, 527 MFP

20915

HP LASERJET PRO M 26 MFP, M 12

X-Generation® black toner for use in HP Laserjet Pro M 26 MFP, M 12

21066

HP M 5035, 5025, 712, 435 MFP

SuMMiT® OPC drum with gear for use in HP M 5035, 5025, 712, 435 MFP

16411

HP LASERJET ENTERPRISE MFP M 630, 625

X-Generation® toner for use in HP laserjet Enterprise MFP M 630, 625 (MPT-4015/M600 X GEN)

19680

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA®****KYOCERA FS 1370, 1320, 1220, 1041, TK 174, 172, 170,**

Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170 15968

Empty toner cartridge for use in Kyocera FS 1370, 1320, TK 174, 173, 172, 170 15969

Smartchip™ for use in Kyocera FS 1320 TK 170 17074

Smartchip™ for use in Kyocera FS 1320, TK 172 17167

Smartchip™ for use in Kyocera FS 1320, TK 174 17168

Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170 17318

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1115 1,600 pages, EUR 18895

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1119 1,600 pages, AUS 18899

Smartchip® for use in Kyocera FS 1041, 1220 MFP, 1320 MFP, TK 1117 1,600 pages US 19000

Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370, (100,000 pages) 19430

KYOCERA FS 1000, TK 17 H

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified) 7158

Absolute Black® toner for use in Kyocera FS 1000 TK 17 H (AMES Certified toner) 8694

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Toner hopper fill plug for use in Kyocera FS 1000, 1020, KM 1500, TK 17, LA, TK 18 H

9972

Black Airbag for Kyocera FS 1000 Cartridges

14972

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified toner)

16494

KYOCERA FS 1020 MFP, 1118, TK 18 H

Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H (AMES Certified)

7158

Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H (AMES Certified toner)

8881

Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H (AMES Certified)

9787

Toner hopper fill plug for use in Kyocera FS 1000,1020, KM 1500, TK 17, LA, TK 18 H,

9972

Absolute Black® refill toner for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1)

16494

Absolute Black® toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110, 1112, 1114

19076

Smartchip™ toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110

19080

Smartchip™ toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1112

19081

Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020

19428

KYOCERA FS 1700, TK 20 H

Absolute Black® toner for use in Kyocera FS 1700, TK 20 H (AMES Certified toner)

6074

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Waste hopper bottle for use in Kyocera FS 1700, TK 20 H

7315

Absolute Black® toner for use in Kyocera FS 1700, TK 20 H (AMES Certified toner)

8341

Absolute Black® toner for use in Kyocera TK 112, 67, 55, 50, 20, 18, 17, FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, 1kg

16494

KYOCERA FS 3900, TK 322, 320

Absolute Black® toner for use in Kyocera FS 3900, TK 322, 320 (AMES Certified)

10979

Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900

11118

Smartchip™ for use in Kyocera FS 3900, TK 322

11546

Smartchip™ for use in Kyocera FS 3900, TK 320

12684

Smartchip™ for use in Kyocera FS 3900, TK 324

17170

Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820

19589

KYOCERA FS 4000 ,TK 332, 330

Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 (AMES Certified)

10978

Absolute Black® toner cartridge for Kyocera FS 4000 ,TK 332, 330,

11119

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

11547

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

12685

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 (AMES Certified toner)

14058

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

16784

Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330

17171

Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820

19589

KYOCERA FS 9100, 9500, TK 70 H

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H(AMES Certified)

7599

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H (AMES Certified)

8966

Waste toner bottle for use in Kyocera FS 9100, 9500, TK 70 H

9606

Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H (AMES Certified)

13726

Wiper blade for use in Kyocera FS 9530, 9500, 9130, 9120, 9100, KM 5035, 4035, 4030, 3530, 3035, 2530

19220

KYOCERA FS 1920, TK 57 H, 55 H

Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H (AMES Certified)

5308

Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H (AMES Certified)

6444

Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1)

16494

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA FS 3820, TK 67, 65**

Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)	5253
Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)	5254
Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65 (AMES Certified)	13663
Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17 (MPT-TK1)	16494

KYOCERA FS 1035, 1135, TK 1140 MFP, TK 1142, TK 1144, TK 1147 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip® for use in Kyocera FS 1035, 1135 MFP, TK 1140	17361
Smartchip® for use in Kyocera FS 1035, 1135MFP, TK 1142	17371
Smartchip® for use in Kyocera FS 1035, 1135MFP, TK 1144	17372
Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147 (7,200 pages)(AMES Certified)	17375
Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147 (AMES Certified)	17579
X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140)(AMES Certified)	17580
X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140 (AMES Certified)	17581
Smartchip® for use in Kyocera FS 1035, 1135 MFP, TK 1147	17831
Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370, (100,000 pages)	19430

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA FS 4020, TK 360, 362, 364**

Smartchip™ for use in Kyocera FS 4020, TK 360	14522
Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364 (AMES Certified)	14536
Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364 (AMES Certified)	14641
Smartchip™ for use in Kyocera FS 4020, TK 362	16090
Smartchip™ for use in Kyocera FS 4020, TK 364	17176

KYOCERA FS 720, 820, 1016, TK 112, 110

Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110)(AMES Certified toner)	9115
Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016(AMES Certified toner)	9975
Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016(AMES Certified)	9976
Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370	19430

KYOCERA FS 1030, 1130 MFP, TK 1130, 1132, 1134 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120 (AMES Certified toner)	10289
Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120 (AMES Certified)	10290
Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1130	17360

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1132 17369

Smartchip® toner for use in Kyocera FS 1030, 1130 MFP, TK 1134 17370

Absolute Black® toner for use in Kyocera FS 1030, 1130 MFP, TK 1130, 1132, 1134 17376

KYOCERA FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for Kyocera TK 142, 140, FS 1100 (AMES Certified toner) 12614

Absolute Black® toner for use in Kyocera FS 1300, 1350, TK 132, 130 (AMES Certified toner) 12616

Absolute Black® toner for Kyocera FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104 (AMES Certified toner) 12617

Smartchip™ for use in Kyocera FS 1300, TK 130 12686

Smartchip™ for use in Kyocera TK 140, FS 1100, Europe 12687

Smartchip™ for use in Kyocera FS 1300, TK 132 16067

Absolute Black® toner for Kyocera TK 1100, 1102, 1104, FS 1110, 1024, 1124, 2,100 pages (AMES Certified) 16828

Smartchip™ for use in Kyocera FS 1300, 1350, 1128, 1028, TK 134 17158

Smartchip™ for use in Kyocera TK 142, FS 1100 4,000 pages, US 17162

Smartchip™ for use in Kyocera TK 144, FS 1100 4,000 pages, AU 17163

Smartchip™ toner for Kyocera TK 1100, FS 1110, 1024, 1124, Europe 18716

Uni Drum™ with gears for use in Kyocera FS 1028, 1128, 1035, 1135, 720, 820, 920, 1016, 1100, 1300, 1320, 1350, 1370 19430

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA FS 9530, 9130, TK 712, 710**

Absolute Black® toner for use in Kyocera FS 9530, 9130, TK 712, 710 (AMES Certified)	10983
Absolute Black® toner for use in Kyocera TK 712, 710, FS 9530, 9130	11881
Absolute Black® toner for use in Kyocera FS 9530, 9130, TK 712, 710 (AMES Certified)	13382
Smartchip™ for use in Kyocera FS 9130, 9530, TK 712, FS 9530, 9130	14432
Smartchip™ for use in Kyocera FS 9130, 9530, TK 710,	17223
Smartchip™ for use in Kyocera FS 9130, 9530, TK 714	17224
Wiper blade for use in Kyocera FS 9530, 9500, 9130, 9120, 9100, KM 5035, 4035, 4030, 3530, 3035, 2530	19220

KYOCERA FS 2000, TK 314, 312, 310

Absolute Black® toner for use in Kyocera FS 2000, TK 312, 310 (AMES Certified)	10982
Smartchip™ for use in Kyocera FS 2000, TK 312	11545
Smartchip™ for use in Kyocera FS 2000, TK 310	12683
Smartchip™ for use in Kyocera FS 2000, TK 314	17169
Lower fuser roller for use in Kyocera Mita FS1128MFP, FS1028MFP, FS2000D, FS2020D, FS3900DN, FS4000DN, KM2810, KM2820, 2F925270	19589

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA FS 2020,TK 340, 342, 344**

Absolute Black® toner for use in Kyocera FS 2020, TK 340, 342, 344, FS 2020 (AMES Certified toner)	14585
Smartchip™ for use in Kyocera FS 2020, TK 340 (Europe)	15020
Absolute Black® toner for use in Kyocera FS 2020,TK 340, 342, 344 (AMES Certified)	15185
Smartchip™ for use in Kyocera FS 2020, TK 342 (US)	17172
Smartchip™ for use in Kyocera FS 2020, TK 344 (AU)	17173
Lower fuser roller for use in Kyocera Mita FS 1128MFP, FS 1028MFP, FS 2000D, FS 2020D, FS 3900DN, FS 4000DN, KM 2810, KM 2820	19589

KYOCERA FS 1900, TK 50

Absolute Black® toner for use in Kyocera FS 1900, TK 50 (AMES Certified)	8877
Absolute Black® toner for use in Kyocera FS 1900, TK 50 H (AMES Certified)	9597
Absolute Black® toner for use in Kyocera FS 1900, TK 50 H (AMES Certified)	12287
Absolute Black® toner for use in Kyocera TK 112, 67, 55, 50, 20, 18, 17, FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, 1kg	16494

KYOCERA FS 2100, 3100, 4100, 4200, 4300, TK 3104, 3102, 3100 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Kyocera , FS 2100, TK 3104, 3102, 3100 (AMES Certified)	18125
Smartchip™ toner for use in Kyocera FS 2100, TK 3100 (Europe)	18134

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ toner for use in Kyocera FS 2100, M 3040, 3540, TK 3102 (USA) 18135

Smartchip™ toner for use in Kyocera FS 2100, TK 3104 (AUS) 18755

X-Generation® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100 18844

X-Generation® toner for use in Kyocera FS 2100, M 3040, 3540, TK 3104, 3102, 3100 18847

Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134 19008

Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 19739

KYOCERA FS 4100, TK 3114, 3112, 3110, FS 4100 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Kyocera FS 4100, TK 3114, 3112, 3110 18122

Smartchip™ toner for use in Kyocera FS 4100, TK 3112 (USA) 18127

Smartchip™ toner for use in Kyocera FS 4100, TK 3110 (Europe) 18128

Smartchip™ toner for use in Kyocera FS 4100, TK 3114 (AUS) 18756

X-Generation® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100 18844

Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134 19008

X-Generation® toner for use in Kyocera FS 4100, TK 3114, 3112, 3110 19096

Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 19739

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA FS 4200, TK 3124, 3122, 3120 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® toner for use in Kyocera FS 4200, TK 3124, 3122, 3120 (AMES Certified)	18123
Smartchip™ toner for use in Kyocera FS 4200, M 3550, TK 3122 (USA)	18130
Smartchip™ toner for use in Kyocera FS 4300, 4200, M 3560, TK 3130 (Europe)	18133
X-Generation ® Black toner for use in Kyocera FS 4200, 4100, 2100, M 3040, 3540, TK 3124, 3122, 3120, 3114, 3112, 3110, 3104, 3102, 3100	18844
X-Generation® Black toner for use in Kyocera FS 4200, TK 3124, 3122, 3120	18845
Waste toner bottle for use in Kyocera FS 4300, 4200, 4100, 2100, M 3040, 3540, 3550, 3560, TK 3100, 3102, 3110, 3112, 3114, 3120, 3130, 3132, 3134	19008
Absolute Black® toner for use in Kyocera FS 4300, 4200, 4100, 2100, 1135, M 2535, 2035, TK 3132, 3122, 3112, 3102, 1147, 1142 (MPT-TK2)	19739

KYOCERA FS 3800, TK 60 H

Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner)	6171
Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner)	8342
Absolute Black® toner for use in Kyocera FS 3800, TK 60 H (AMES Certified toner)	16494

KYOCERA FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350

Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350, (AMES Certified toner)	14586
Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP,TK 350, 352 (AMES Certified)	14808

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Kyocera FS 3920, TK 350

17141

Smartchip™ for use in Kyocera FS 3920, TK 352, FS 3920

17174

Smartchip™ for use in Kyocera FS 3920, TK 354, FS 3920

17175

KYOCERA FS C 5400, 5350, 5250, 5150, 5200, 5100 TK 570, 572, 574

Smartchip™ for use in Kyocera FS C 5400, TK 574, Black

17200

Smartchip™ for use in Kyocera FS C 5400, TK 574, Cyan

17201

Smartchip™ for use in Kyocera FS C 5400, TK 574, Magenta

17202

Smartchip™ for use in Kyocera FS C 5400, TK 574, Yellow

17203

Smartchip™ for use in Kyocera FS C 5400, TK 570, Black

17439

Smartchip™ for use in Kyocera FS C 5400, TK 570, Cyan

17440

Smartchip™ for use in Kyocera FS C 5400, TK 570, Magenta

17441

Smartchip™ for use in Kyocera FS C 5400, TK 570, Yellow

17442

Smartchip™ for use in Kyocera FS C 5400, TK 572, Black

17620

Smartchip™ for use in Kyocera FS C 5400, TK 572, Cyan

17621

Smartchip™ for use in Kyocera FS C 5400, TK 572, Magenta

17622

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Kyocera FS C 5400, TK 572, Yellow	17623
Absolute Black® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 16,000 pages	17676
Absolute Cyan® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 12,000 pages	17677
Absolute Magenta® toner for use in Kyocera FS C 5400, TK 570, 572, 574	17678
Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574	17679
Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag	18077
Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag	18078
Absolute Magenta® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540 (10kg) bag	18079
Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574	18080
Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19734
Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19735
Absolute Magenta® toner for use in Kyocera FS C 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19736
Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19737

KYOCERA FS C 1020 MFP, TK 152, 150

Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Black toner	14751
Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Cyan toner	14752

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Magenta toner

14753

Smartchip® for use in Kyocera FS C 1020 MFP, TK 152, Yellow toner

14754

Smartchip® for use in Kyocera FS C 1020 MFP, Black toner TK 150K

14755

Smartchip® for use in Kyocera FS C 1020 MFP, Cyan toner TK 150C

14756

Smartchip® for use in Kyocera FS C 1020 MFP, Magenta toner TK 150M

14757

Smartchip® for use in Kyocera FS C 1020 MFP, Yellow toner TK 150Y

14758

Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

14760

Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

14761

Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

14762

Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

14763

Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

15742

Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

15743

Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

15744

Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150

15745

Smartchip™ for use in Kyocera FS C 1020, Black TK 154K

16021

Smartchip™ for use in Kyocera FS C 1020, Cyan TK154C

16022

Smartchip™ for use in Kyocera FS C 1020, Magenta TK154M

16023

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Kyocera FS C 1020, Yellow TK154Y	16024
Absolute Black® refill toner cartridge for use in Kyocera FS 3820, 3800, 1920, 1900, 1700, 1020, 1000, 820, KM 1500, TK 112, 67, 55, 50, 20, 18, 17, (MPT-TK1)	16494
Absolute Black® toner for use in Kyocera FS 1040, 1120 MFP, 1020 MFP, TK 1110, 1112, 1114	19076
Smartchip™ toner for use in Kyocera FS-1040, 1120 MFP, 1020 MFP TK 1110	19080
Smartchip™ toner for use in Kyocera FS-1040, 1120 MFP, 1020 MFP, TK 1112	19081
Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020	19428

KYOCERA FS C 5350, 5300, TK 560, 562, 564

Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Black	17016
Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Cyan	17017
Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Magenta	17018
Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Yellow	17019
Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Black	17212
Smartchip™ for use in Kyocera FS C 5350, 5300, TK 560, Cyan	17213
Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Magenta	17214
Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Yellow	17215
Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	17547

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	17548
Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	17549
Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	17550
Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag	18077
Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag	18078
Absolute Magenta® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag	18079
Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5250, 5150, 5200, 5100, TK 590, 580, 570, 550, 540, (10kg) bag	18080
Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	18081
Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	18082
Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	18083
Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564	18084
Absolute Black® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19734
Absolute Cyan® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19735
Absolute Magenta® toner for use in Kyocera FS C 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19736
Absolute Yellow® toner for use in Kyocera FSC 5400, 5350, 5300, 5250, 5150, 5100 TK 590, 580, 570, 550, 540, 1kg	19737

KYOCERA FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Black	17430
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Cyan	17431
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Magenta	17432
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Yellow	17433
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Black	17434
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Cyan	17435
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Magenta	17436
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Yellow	17437
Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17465
Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594	17466
Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17467
Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17468
Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594	17766
Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17767
Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17768
Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592	17769
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Black (7,000 pages)(AU)	18446

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Cyan (5,000 pages)(AU)	18447
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Magenta (5,000 pages)(AU)	18448
Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Yellow (5,000 pages)(AU)	18449
Uni Drum™ with gears for use in Kyocera FS C 5020, 5030, 5150, 5250, 5200, 5300 (100,000 pages)	19433
Waste toner bottle for use in Kyocera TK 594, 592, 590, 584, 582, 580, FS C 5250, 5150, 2026, 2126, 2526, 2626 MFP	19869
Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 180g (7,000 pages)	20059
Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594, 120g (5,000 pages)	20060
Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)	20061
Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)	20062

KYOCERA KM 1505, 1510, 1810

Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810 (AMES Certified toner)	11650
Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810 (AMES Certified toner)	13519

KYOCERA KM 2530, 3035, 3530, 4030, 4035, 5035

Waste hopper bottle for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035	10422
Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (AMES Certified toner)	10700

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (AMES Certified toner)

14713

Wiper blade for use in Kyocera KM 5035, 4035, 4030, 3530, 3035, 2530

19220

Lower fuser roller for use in Kyocera Mita KM 5035, 4035, 3035, FS 9520, 9120 (2FG93151)

19627

KYOCERA KM 3050, 4050, 5050, TK 717, 715

Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715

11373

Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715

11374

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 717

13690

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 715

17225

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 719

17226

Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 718

20464

KYOCERA KM 4230, 5230, Ai 4040, 5050

Absolute Black® toner for use in Kyocera KM 4230, 5230, Ai 4040, 5050

11652

KYOCERA KM Ai 2310, 3010

Absolute Black® for use in Kyocera KM 1510, 1530, 1810, Ai 2310, 4040

5519

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Kyocera KM Ai 2310, 3010

11653

KYOCERA KM 1500, 1815, TK 100

Absolute Black® toner for use in Kyocera KM 1500, 1815, TK 100 (AMES Certified toner)

8075

Wiper blade for use in Kyocera™ KM 1500

13158

Absolute Black® refill toner cartridge for use in Kyocera KM 1500, TK 112, 67, 55, 50, 20, 18, 17, (MPT-TK1)

16494

Uni Drum™ with gears for use in Kyocera KM 1500, 1815, 1820, FS 1020

19428

KYOCERA KM 1525, 1530, 1570, 2030, 2070

Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070 (AMES Certified toner)

10257

Waste hopper bottle for use in Kyocera KM 1525, 1530, 1570, 2030, 2070

10421

Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070 (AMES Certified toner)

11651

Uni Drum™ with gears for use in Kyocera KM 1525, 1530, 1570, 2030, 2070

12358

Wiper blade for use in Kyocera Mita KM 2070, 2030, 1530, 1525

19212

KYOCERA KM 1620, 1650, 2020, 2035, 2050, TK 410, 411,

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411 (AMES Certified)

10298

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411 (AMES Certified)

10299

Waste toner bottle for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411

10417

Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411(AMES Certified)

11033

Uni Drum™ with gears for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411

13002

Smartchip™ for use in Kyocera KM 1620,1635, 1650, 2020, 2035, 2050, TK 410, (EU)

17177

Smartchip™ for use in Kyocera KM 1620,1635, 1650, 2020, 2035, 2050, TK 412, (US)

17178

Smartchip™ for use in Kyocera KM 1620, 1635, 1650, 2020, 2035, 2050,TK 414, (AU, AP)

17179

Wiper blade for use in Kyocera Mita KM 2050, 2020, 1650, 1635, 1620

19221

KYOCERA KM 2540, TK 677

Smartchip™ for use in Kyocera KM 2540, TK 677

17221

Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060, TK 675, 679

18274

Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060 TK 675, 679

18287

KYOCERA Mita KM 8030, 6030

Wiper blade for use in Kyocera Mita KM 8030, 6030 (special order)(MOQ. 10)

19222

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA Mita TASKalfa 220, 180, KM 1620,**

Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620 (AMES Certified toner)	16565
Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK435	17180
Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK437	17181
Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK439	17182
Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620 (AMES Certified)	17319
Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4105 (EU)	21067
Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4107 (US)	21068
Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP, TK-4109 (AP)	21069
Absolute Black® toner for use in Kyocera TaskAlfa 2201, 2200, 1801, 1800 MFP, TK-4109, 4107, 4105	21070

KYOCERA Mita TaskAlfa 520i, 420i, TK 725,

Absolute Black® toner for use in Kyocera Mita TaskAlfa 420i, 520i ,TK 725	16612
Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 725	17227
Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 727	17228
Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 729	17229

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA TaskAlfa 300ci, 250ci, TK 865**

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Black 17242

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Cyan 17243

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Magenta 17244

Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Yellow 17245

KYOCERA TaskAlfa 5501, 5500, 4501, 4500, 3501, 3500

Smartchip® Black for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501 (TK6305)(EU) 20142

Smartchip® Black for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501 (TK6307)(US) 20143

Absolute Black® toner for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501, (TK 6305, 6307) 20475

Absolute Black® developer for use in Kyocera TASKalfa 3500, 3501, 4500, 4501, 5500, 5501, (302LH93030, 302LH93034) 21129

KYOCERA TaskAlfa 2201, 2200, 1801, 1800 MFP, TK-4105

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4105)(EU) 21067

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4107)(US) 21068

Smartchip® for use in Kyocera TASKalfa 2201, 2200, 1801, 1800 MFP (TK-4109)(AP) 21069

Absolute Black® toner for use in Kyocera TaskAlfa 2201, 2200, 1801, 1800 MFP, (TK-4109, 4107, 4105) 21070

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA TaskAlfa 2551, TK-8327K**

Smartchip™ Black for use in Kyocera TASKalfa 2551 (TK-8327K)(US)	20717
Smartchip™ Cyan for use in Kyocera TASKalfa 2551ci (TK-8327C)(US)	20718
Smartchip™ Magenta for use in Kyocera TASKalfa 2551ci (TK-8327M)(US)	20719
Smartchip™ Yellow for use in Kyocera TASKalfa 2551ci (TK-8327Y)(US)	20720
Smartchip™ Black for use in Kyocera TASKalfa 2551ci (TK-8325K)(EU)	20721
Smartchip™ Cyan for use in Kyocera TASKalfa 2551ci (TK-8325C)(EU)	20722
Smartchip™ Magenta for use in Kyocera TASKalfa 2551ci (TK-8325M)(EU)	20723
Smartchip™ Yellow for use in Kyocera TASKalfa 2551ci (TK-8325Y)(EU)	20724

KYOCERA TaskAlfa 3011i, 3010i, TK7105

Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7105)(EU)	20980
Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7107)(US)	20981
Smartchip® toner for use in Kyocera TASKalfa 3011i, 3010i (TK7109)(AP)	20982
Absolute Black® toner for use in Kyocera TaskAlfa 3011i, 3010i, (TK-7105, 7107, 7109)	21073

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA TaskAlfa 8001, 8000, 6501, 6500, TK-6705**

Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6705)(EU)	20740
Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6707)(US)	20741
Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501, 6500 (TK-6708)(CH)	20742
Smartchip™ for use in Kyocera TASKalfa 8001, 8000, 6501,6500 (TK-6709)(AP)	20743

KYOCERA TaskAlfa 7551, 7550, 6551, 6550, TK-8705K

Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705K)(EU)	20744
Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705C)(EU)	20745
Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705M)(EU)	20746
Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8705Y)(EU)	20747
Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707K)(US)	20748
Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707C)(US)	20749
Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707M)(US)	20750
Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8707Y)(US)	20751
Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708K)(CH)	20752
Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708C)(CH)	20753

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708M)(CH)

20754

Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8708Y)(CH)

20755

Smartchip™ Black for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709K)(AP)

20756

Smartchip™ Cyan for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709C)(AP)

20757

Smartchip™ Magenta for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709M)(AP)

20758

Smartchip™ Yellow for use in Kyocera TASKalfa 7551, 7550, 6551, 6550 (TK-8709Y)(AP)

20759

KYOCERA TaskAlfa 3511i, 3510i

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7205)(EU)

20987

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7207)(US)

20988

Smartchip® toner for use in Kyocera TASKalfa 3511i, 3510i (TK7209)(Asia P.)

20989

Absolute Black® toner for use in Kyocera TaskAlfa 3511i, 3510i

21072

KYOCERA TaskAlfa 820, 620

Absolute Black® toner for use in Kyocera TaskAlfa 820, 620

21084

KYOCERA TaskAlfa 406, TK-5215K

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5215K)(EU)	20776
Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5215C)(EU)	20777
Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5215M)(EU)	20778
Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5215Y)(EU)	20779
Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5217K)(US)	20780
Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5217C)(US)	20781
Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5217M)(US)	20782
Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5217Y)(US)	20783
Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5218K)(CH)	20784
Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5218C)(CH)	20785
Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5218M)(CH)	20786
Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5218Y)(CH)	20787
Smartchip™ Black for use in Kyocera TASKalfa 406 (TK-5219K)(AP)	20788
Smartchip™ Cyan for use in Kyocera TASKalfa 406 (TK-5219C)(AP)	20789
Smartchip™ Magenta for use in Kyocera TASKalfa 406 (TK-5219M)(AP)	20790
Smartchip™ Yellow for use in Kyocera TASKalfa 406 (TK-5219Y)(AP)	20791

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA TaskAlfa 356, TK-5205K**

Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5205K)(EU)	20792
Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5205C)(EU)	20793
Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5205M)(EU)	20794
Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5205Y)(EU)	20795
Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5207K)(US)	20796
Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5207C)(US)	20797
Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5207M)(US)	20798
Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5207Y)(US)	20799
Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5208K)(CH)	20800
Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5208C)(CH)	20801
Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5208M)(CH)	20802
Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5208Y)(CH)	20803
Smartchip™ Black for use in Kyocera TASKalfa 356 (TK-5209K)(AP)	20804
Smartchip™ Cyan for use in Kyocera TASKalfa 356 (TK-5209C)(AP)	20805
Smartchip™ Magenta for use in Kyocera TASKalfa 356 (TK-5209M)(AP)	20806
Smartchip™ Yellow for use in Kyocera TASKalfa 356 (TK-5209Y)(AP)	20807

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KYOCERA TaskAlfa 306, TK-5195K**

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5195K)(EU) 20760

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5195C)(EU) 20761

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5195M)(EU) 20762

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5195Y)(EU) 20763

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5197K)(US) 20764

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5197C)(US) 20765

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5197M)(US) 20766

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5197Y)(US) 20767

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5198K)(CH) 20768

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5198C)(CH) 20769

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5198M)(CH) 20770

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5198Y)(CH) 20771

Smartchip™ Black for use in Kyocera TASKalfa 306 (TK-5199K)(AP) 20772

Smartchip™ Cyan for use in Kyocera TASKalfa 306 (TK-5199C)(AP) 20773

Smartchip™ Magenta for use in Kyocera TASKalfa 306 (TK-5199M)(AP) 20774

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow for use in Kyocera TASKalfa 306 (TK-5199Y)(AP)

20775

KYOCERA TaskAlfa 266, 265, TK-5135K

Smartchip™ Black for use in Kyocera TaskAlfa 266, 265 (TK-5135K)(EU)

19927

Smartchip™ Cyan for use in Kyocera TaskAlfa 266, 265 (TK-5135C)(EU)

19928

Smartchip™ Magenta for use in Kyocera TaskAlfa 266, 265 (TK-5135M)(EU)

19929

Smartchip™ Yellow for use in Kyocera TaskAlfa 266, 265 (TK-5135Y)(EU)

19930

Smartchip™ Black for use in Kyocera TaskAlfa 266, 265 (TK-5137K)(US)

19931

Smartchip™ Cyan for use in Kyocera TaskAlfa 266, 265 (TK-5137C)(US)

19932

Smartchip™ Magenta for use in Kyocera TaskAlfa 266, 265 (TK-5137M)(US)

19933

Smartchip™ Yellow for use in Kyocera TaskAlfa 266, 265 (TK-5137Y)(US)

19934

Absolute Black® toner for use in Kyocera TaskAlfa 266, 265

19935

Absolute Cyan® toner for use in Kyocera TaskAlfa 266, 265

19936

Absolute Magenta® toner for use in Kyocera TaskAlfa 266, 265

19937

Absolute Yellow® toner for use in Kyocera TaskAlfa 266, 265

19938

KYOCERA Mita 3060, 3040, 2560, 2540

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Upper fuser roller for use in Kyocera Mita 3060, 3040, 2560, 2540 (2H094160)

19624

KYOCERA Mita DC 1460

Absolute Black® toner for use in Kyocera Mita DC 1460

8293

KYOCERA Mita 3060, 3040, 2560, 2540

Upper fuser roller for use in Kyocera Mita 3060, 3040, 2560, 2540 (2H094160)

19624

KONICA MINOLTA®**KONICA MINOLTA BIZHUB 200, 250, 350, 282, 350, 362, DI 3510, 3010, 2510, 2050**

Fuser roller Lower for use in Konica Minolta Bizhub 200, DI 3510, 3010, 2510, 2010 (4030-5702-02, 4030-5702-03)

12147

Absolute Black® toner for use in Minolta Bizhub 200, 250, 350

17976

Uni Drum® with gears for use in Konica Minolta Bizhub C 200, 203, 253, 353

18573

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786

KONICA MINOLTA BIZHUB 223, 283, 363, 423

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Minolta Bizhub 223, 283, 363, 423

17977

Uni Drum® with gears for use in Konica Minolta Bizhub 423, 363, 283, 223, Di 3510, 2510, 2010, 1810

19240

KONICA MINOLTA BIZHUB 501, 421, 420, 361, 360

Upper Fuser Roller for use in Konica Minolta Bizhub 501, 421, 420, 361, 360 (50GE53030)

19618

Absolute Black® toner for use in Konica Minolta Bizhub 501, 500, 421, 420, 361, 360

20385

KONICA MINOLTA BIZHUB 4700, 4000, 3300

Smartchip® for use in Konica Minolta Bizhub 3300 (A63V00W, TNP-39)

19914

Smartchip® for use in Konica Minolta Bizhub 4000 (A63W01W, TNP-38)(US)

19915

Smartchip™ drum for use in Konica Minolta Bizhub 4700, 4000, 3300 (A63X03W, IUP-17)

19917

X-Generation® Black toner for use in Konica Minolta Bizhub 4750, 4700, 4050, 4000

19951

KONICA MINOLTA BIZHUB 4750, 4050 MFP

Smartchip® for use in Konica Minolta Bizhub MFP 4750, 4050 (A6VK01W, TNP-46)(US)

19922

Smartchip™ drum for use in Konica Minolta Bizhub MFP 4750, 4050 (A6VM03W, IUP-21)(US)

19924

X-Generation® Black toner for use in Konica Minolta Bizhub 4750, 4700, 4050, 4000

19951

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KONICA MINOLTA BIZHUB 4020, 3320 MFP**

Smartchip® for use in Konica Minolta Bizhub MFP 3320 (A6WT00W, TNP-43)(US)

19920

Smartchip® for use in Konica Minolta Bizhub MFP 4020 (A6WN01W, TNP-42)(US)

19921

Smartchip™ drum for use in Konica Minolta Bizhub MFP 4020, 3320 (A6W903W, IUP-19)(US)

19923

KONICA MINOLTA BIZHUB 40P

Smartchip™ toner for use in Konica Minolta Bizhub 40P (A0FP013)

13625

Absolute Black® toner for use in Konica Minolta Bizhub 40P

13775

Absolute Black® toner for use in Konica Minolta Bizhub 40P

13826

Smartchip™ toner for use in Konica Minolta Bizhub 40P (A0FP023)(EU)

18813

KONICA MINOLTA Pro C 500, CF 5001, 8050

Uni Drum™ F drum with gears for use in Minolta Pro C 500, CF 5001, 8050

12158

KONICA MINOLTA BIZHUB Pro 950, 920

SuMMiT® OPC drum for use in Minolta Bizhub Pro 950, 920

20093

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Konica Minolta Bizhub Pro 920

20384

Absolute Black® toner for use in Konica Minolta Bizhub Pro 920

20393

KONICA MINOLTA C 252, 250

Uni Drum™ with gears for use in Minolta Bizhub C 250, 252

11221

Wiper blade for use in Konica Minolta Bizhub C 252, 250, 222, 200 (200-CB)

19219

KONICA MINOLTA C 450, 362, 351, 350

Wiper blade for use in Konica Minolta Bizhub C 450, 362, 351, 350 (200-CB)

19894

Absolute Black® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310K, 4053-401)

20002

Absolute Cyan® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310C, 4053-701)

20003

Absolute Magenta® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310M, 4053-601)

20004

Absolute Yellow® toner for use in Minolta Bizhub C 450, 351, 350, 230g (TN310Y, 4053-501)

20005

KONICA MINOLTA BIZHUB C 654, 650, 451, 550, 353, 253, 203, 200

Smartchip™ Black for use in Konica Minolta Bizhub C 253, 353

16304

Smartchip™ Cyan for use in Konica Minolta Bizhub C 253, 353

16305

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Konica Minolta Bizhub C 253, 353	16306
Smartchip™ Yellow for use in Konica Minolta Bizhub C 253, 353	16307
Smartchip™ Black drum unit for use in Konica Minolta Bizhub C 253, 353	16308
Smartchip™ Cyan drum unit for use in Konica Minolta Bizhub C 253, 353	16309
Smartchip™ Magenta drum unit for use in Konica Minolta Bizhub C 253, 353	16310
Smartchip™ Yellow drum unit for use in Konica Minolta Bizhub C 253, 353	16312
Smartchip® Black for use in Konica Minolta Bizhub C 203,253	18069
Smartchip® Cyan for use in Konica Minolta Bizhub C 203,253	18070
Smartchip® Magenta for use in Konica Minolta Bizhub C 203,253	18071
Smartchip® Yellow for use in Konica Minolta Bizhub C 203,253	18072
Smartchip® Black drum unit for use in Konica Minolta Bizhub C 203,253	18073
Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 203,253	18074
Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 203,253	18075
Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 203,253	18076
Absolute Black toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200	18537
Absolute Cyan toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200	18538
Absolute Magenta toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200	18539

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow toner® for use in Konica Minolta Bizhub C 650, 550, 451, 353, 253, 203, 200	18544
Uni Drum® with gears for use in Konica Minolta Bizhub C 200, 203, 253, 353	18573
SuMMiT® drum for CMY with gears for use in Konica Minolta Bizhub C 451, 452, 550, 552, 650, 652	18574
Wiper blade for use in Konica Minolta Bizhub C 252, 250, 222, 200 (200-CB)	19219
Wiper blade for use in Konica Minolta Bizhub C 654, 652, 650, 552, 550, 550, 452, 451	21256

KONICA MINOLTA BIZHUB C 20

Absolute Black® toner for use in Konica Minolta Bizhub C 20	14942
Absolute Cyan® toner for use in Konica Minolta Bizhub C 20	14943
Absolute Magenta® toner for use in Konica Minolta Bizhub C 20	14944
Absolute Yellow® toner for use in Konica Minolta Bizhub C 20	14945
Smartchip® for use in Konica Minolta Bizhub C 20 Black (A0DK133, TN318K)(USA)	14946
Smartchip® for use in Konica Minolta Bizhub C 20 Cyan (A0DK233, TN318C)(USA)	14947
Smartchip® for use in Konica Minolta Bizhub C 20 Magenta (A0DK333, TN318M)(USA)	14948
Smartchip® Black for use in Konica Minolta Bizhub C 20 (A0DK153, TN318K)(Europe)	15065
Smartchip® Cyan for use in Konica Minolta Bizhub C 20 (A0DK453, TN318C)(Europe)	15066
Smartchip® Magenta for use in Konica Minolta Bizhub C 20 (A0DK353, TN318M)(Europe)	15067

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Yellow for use in Konica Minolta Bizhub C 20 (A0DK253, TN318Y)(Europe)	15068
Smartchip® Black drum unit for use in Konica Minolta Bizhub C 20 (A03100J)	15069
Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 20 (A0310GJ)(Europe)	15070
Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 20 (A0310AJ)(Europe)	15071
Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 20 (A03105J)	15072
Smartchip® Black drum unit for use in Konica Minolta Bizhub C 20 (A03100G)	15073
Smartchip® Cyan drum unit for use in Konica Minolta Bizhub C 20 (A0310GG)	15074
Smartchip® Magenta drum unit for use in Konica Minolta Bizhub C 20 (A0310AG)	15075
Smartchip® Yellow drum unit for use in Konica Minolta Bizhub C 20 (A03105G)	15076
Smartchip® Yellow for use in Konica Minolta Bizhub C 20 (A0DK253, TN318Y)(Europe)	15078

KONICA MINOLTA BIZHUB C 35, 25

Smartchip™ Yellow for use in Minolta Bizhub C35 (AOX5252)(EUR)	18402
Smartchip™ Yellow drum unit for use in Minolta Bizhub C 25, 35 (AOWG08J)(EUR)	18410
Smartchip™ Yellow toner for use in Minolta bizhub C 25 (TNP27Y, A0X5233)(USA)	19707
Smartchip™ Yellow toner for use in Minolta bizhub C 25 (TNP27Y, A0X5253)(EU)	19719

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KONICA MINOLTA BIZHUB C 368, 308, 258 MFP**

Waste toner container for use in Konica Minolta Bizhub 554, 454, 364, 284, 224, C 554, 454, 368, 308, 364, 224

20371

Smartchip™ Black for use in Minolta Bizhub C 368, 308, 258 MFP (TN324K, A8DA130)(US)

21145

Smartchip™ Cyan for use in Minolta Bizhub C 368, 308, 258 MFP (TN324C, A8DA430)(US)

21146

Smartchip™ Magenta for use in Minolta Bizhub C 368, 308, 258 MFP (TN324M, A8DA330)(US)

21147

Smartchip™ Yellow for use in Minolta Bizhub C 368, 308, 258 MFP (TN324Y, A8DA330)(US)

21148

KONICA MINOLTA BIZHUB C 3850, 3350

Absolute Black® toner for use in Minolta Bizhub C 3850, 3350

19572

Absolute Cyan® toner for use in Minolta Bizhub C 3850, 3350

19573

Absolute Magenta® toner for use in Minolta Bizhub C 3850, 3350

19574

Absolute Yellow® toner for use in Minolta Bizhub C 3850, 3350

19575

Smartchip™ Black for use in Minolta Bizhub C 3850, 3350 (A5X0150)

19576

Smartchip™ Cyan for use in Minolta Bizhub C 3850, 3350 (A5X0430)

19577

Smartchip™ Magenta for use in Minolta Bizhub C 3850, 3350 (A5X0330)

19578

Smartchip™ Yellow for use in Minolta Bizhub C 3850, 3350 (A5X0230)

19579

SuMMiT® OPC drum gearless for use in Minolta Bizhub C 3850, 3350

19580

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black drum for use in Minolta Bizhub C 3850, 3350 (IUP22K,A3GP01D)

20894

Smartchip™ Cyan drum for use in Minolta Bizhub C 3850, 3350 (IUP22C,A3GP0HD)

20895

Smartchip™ Magenta drum for use in Minolta Bizhub C 3850, 3350 (IUP22M,A3GP0CD)

20896

Smartchip™ Yellow drum for use in Minolta Bizhub C 3850, 3350 (IUP22M,A3GP0CD)

20897

KONICA MINOLTA Di 181, 350

Absolute Black® toner for use in Minolta Di 181, 350

5200

Uni Drum® with gears for use in Konica Minolta Bizhub 423, 363, 283, 223, Di 3510, 2510, 2010, 1810

19240

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786

KONICA MINOLTA Di 200, 250, 350

Absolute Black® toner for use in Minolta Di 200, 250, 350

8968

Fuser roller Lower for use in Konica Minolta Bizhub 200, DI 3510, 3010, 2510, 2010 (4030-5702-02, 4030-5702-03)

12147

Wiper blade for use in Minolta Di 200, 250

12670

Uni Drum™ with gears for use in Minolta Di 200, 250, 251, 350, 351

12671

Upper fuser roller for use in Konica Minolta Bizhub 362, 350, 282, 250, 222, 200, DI 3510, 3010, 2510, 2010 (4030-5701-03)

19786

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KONICA MINOLTA Di 550, 470, 450, EP 3050, 4050, 4000, 6001, 8010, 8015**

Feed tire assembly kit for use in Konica Minolta DI 550, 470, 450, PF 208, 115 (4002-3201-01)	12127
Uni Drum™ F with gears for use in Minolta Di 450, 470, 550	12541
Wiper blade for use in Minolta Di 450, 470, 550	12572
Wiper blade for use in Minolta EP 4050, 4000, 3050, 2050, DI 550, 470, 450	12666
Absolute Black™ toner for use in Minolta Di 550, 470, 450, (10kg) bag	15102
Absolute Black™ toner for use in Minolta Di 550, 470, 450,	17814
Cleaning web supply roller for for use in Konica Minolta DI 450, 470, 520, 550, 620, EP 6001, 8010, 8015 (4002-5732-01)	19620
Upper Fuser Roller for use in Konica Minolta DI 450, 550 (4002-5701-01)	19621
Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052)	19857

KONICA MINOLTA Di 551, 650, 5510, 7210

Wiper blade for use in Minolta Di 551, 650, 5510, 7210	12543
Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052)	19857
Upper Fuser Roller for use in Konica Minolta 7272, 7255, 7165, 7155, Bizhub 751, 750, 601, 600, DI 7210, 5510, 650, 551 (56AE53052)	19857

KONICA MINOLTA Di 750, 850

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Minolta Di 750

10225

Wiper blade for use in Konica Minolta 7085, 7075, Di 850, 750

19218

KONICA MINOLTA EP 1030, 1031, 1050

Uni Drum™ F with gears for use in Minolta EP 1030, 1031, 1053

9002

Wiper blade for use in Minolta EP 1030, 1031, 1053

12545

KONICA MINOLTA EP 1050, 1052, 1054, 1080, 1082, 1083, 2010

Uni Drum™ F with gears for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010

12546

Wiper blade for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010

12547

KONICA MINOLTA EP 2120

Uni Drum™ S with gears for use in Minolta EP 2120

5689

KONICA MINOLTA EP 8015, 6001, 6000, 5050

Absolute Black® toner for use in Minolta EP 8015, 6001, 6000, 5050

12302

Cleaning web supply roller for for use in Konica Minolta DI 450, 470, 520, 550, 620, EP 6001, 8010, 8015 (4002-5732-01)

19620

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****KONICA MINOLTA CF 2002, 3102**

Uni Drum™ gearless for use in Minolta CF 2002, 3102,

11963

LEXMARK®**LEXMARK X 954, 952, 950 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip® Black toner for use in Lexmark C/X 950, 952, 954 (C/X950X2KG)

17513

Smartchip® Black toner for use in Lexmark X 950, 952, 954

17517

Smartchip® Cyan toner for use in Lexmark X 950, 952, 954

17518

Smartchip® Magenta toner for use in Lexmark X 950, 952, 954

17519

Smartchip® Yellow toner for use in Lexmark X 950, 952, 954

17520

X-Generation® Black toner for use in Lexmark C 950, 952, X 950, 952, 954

17634

X-Generation® Cyan toner for use in Lexmark C 950, 952, X 950, 952, 954

17635

X-Generation® Magenta toner for use in Lexmark C 950, 952, X 950, 952, 954

17636

X-Generation® Yellow toner for use in Lexmark C 950, 952, X 950, 952, 954

17637

X-Generation® drum with gears and insert for use in Lexmark C 950, 952, X 954, 952, 950

18298

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® CMYK drum unit for use in Lexmark C 950, 952, X 954, 952, 950

18304

Wiper blade for use in Lexmark C 952, 950, X 954, 952, 950

18557

LEXMARK X 792, 748, 746, 738, 736, 734, 730

X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15792

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15793

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15794

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

15795

Smartchip™ Black for use in Lexmark C 730, 734, 736, X 734, 736, 738

15800

Smartchip™ Cyan for use in Lexmark C 730, 734, 736, X 734, 736, 738

15801

Smartchip™ Magenta for use in Lexmark C 730, 734, 736, X 734, 736, 738

15802

Smartchip™ Yellow for use in Lexmark C 730, 734, 736, X 734, 736, 738,

15803

X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16739

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16740

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16741

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738

16742

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, X 734, 736, 738, 746, 748

19730

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19731

X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19732

X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

19733

X-Generation® Black toner for use in Lexmark C 792, X 792 (MPT LXC792)

19943

X-Generation® Cyan toner for use in Lexmark C 792, X 792 (MPT LXC792)

19944

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

20101

X-Generation® Black toner for use in Lexmark C 730, 734, 736, 746, 748, 792, X 734, 736, 738, 746, 748, 792

20112

LEXMARK X 658, 656, 654, 652, 651

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (25,000 pages)(USA & WW)(MPS Jumbo yield)

18639

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (USA & WW)(MPS Jumbo yield)

18640

Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (Asia Pacific)(MPS Jumbo yield)

18928

Fuser maintenance kit for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X4724)

19843

Fuser assembly type 1 for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X4418)

19844

Transfer roller for use in Lexmark X 658, 656, 654, 652, 651, T 656, 654, 652, 650 (40X1886)

19845

PCR roller for use in Lexmark X 658, 656, 654, 652, 651, 646, 644, 642, T 654, 652, 650, 644, 642, 640 (40X5852)

19846

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****LEXMARK X 864, 862, 860, 854, 852, 850**

Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

16787

Smartchip® toner for use in Lexmark X 860, 862, 864 (X860H21G)

17884

Smartchip® drum unit for use in Lexmark X 860, 862, 864 (W860H22G)

17885

Developer for drum unit for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

18990

SuMMiT® OPC drum with gears for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

18991

Wiper blade for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

19150

Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864

20860

LEXMARK M/XM 3150, 1145

Smartchip® for use in Lexmark M/XM 3150 (24B6186)

20052

X-Generation® Black toner for use in Lexmark M 3150, 1145, XM 3150, 1145

20058

LEXMARK MX 812, 811, 810, 710, 611, 610, 510, 410, 310, 310

Smartchip™ for use in Lexmark MX 310, 410, 511, 611 (US)

18653

Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611(US)

18654

Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (US)

18655

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (EUR)	18660
Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (EUR)	18661
Absolute Black® toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611(AB MPT-MS810)	18679
Absolute Black® toner for use in Lexmark MS 510, 610, MX 510, 511, 610, 611	18680
X-Generation® Black toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611(XG MPT-MS810)	18688
X-Generation® Black toner for use in Lexmark MS 510, 610, MX 510, 511, 610, 611	18690
X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812 (MPT-MS810-XGEN)	18693
Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (Asia Pacific)	18698
Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (SE Asia)	18699
Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (Latin America)	18713
Smartchip™ for use in Lexmark MX 510, 511, 610, 611 (Latin America)	18714
X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812 (MPT-MS810-XGEN)	18715
Absolute Black® toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812,(MPT-MS810-LGA)(EU LGA Prequalified)	18883
Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 611 (MEA)	19609

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****OKIDATA CX 2033 MFP**

Absolute Black® toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP	14220
Absolute Cyan™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP	14221
Absolute Magenta™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP	14222
Absolute Yellow™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP	14223
Smartchip™ Black toner for use in Okidata CX 2033 MFP	14224
Smartchip™ Cyan toner for use in Okidata CX 2033 MFP	14225
Smartchip™ Magenta toner for use in Okidata CX 2033 MFP	14226
Smartchip™ Yellow toner for use in Okidata CX 2033 MFP	14227
Smartchip™ drum fuse for use in Okidata CX 2033, MC 560 MFP	14228
Uni Drum™ with gears for use in Okidata CX 2033 MFP	14232
Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033	14301
X-Generation® Black toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP	17266
X-Generation® Cyan toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP	17267
X-Generation® Magenta toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP	17268
X-Generation® Yellow toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP	17269

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****OKIDATA MC 160 MFP, C 130, 110**

Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110	14568
Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110	14569
Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110	14570
Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110	14571
Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110	14572
Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110	14573
Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110	14574
Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110	14575
Developer roller cover for use in Okidata MC 160 MFP	14581
Developer roller cover for use in Okidata C 130, 110, MC 160 MFP	18288

OKIDATA C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17719
Absolute Cyan® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562,	17720
Absolute Magenta® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17721
Absolute Yellow® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17722

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17727
Smartchip™ Cyan for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17728
Smartchip™ Magenta for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17729
Smartchip™ Yellow for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562	17730
Uni Drum ® drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP	17793
Uni Drum ® drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP	17793
Smartchip™ drum fuse for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP	18307
Color cartridges chip holder and retainer for use in Okidata C 310, 330, 510, 511, 530, 531, MC 562, 561, 361 MFP	18566
SuMMiT® Drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP	18733
Absolute Black® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag	20627
Absolute Cyan® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag	20628
Absolute Magenta® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag	20629
Absolute Yellow® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562, (10kg) bag	20630

OKIDATA B 8300

Absolute Black® toner for use in Okidata B 8300	9092
Absolute Black® developer carrier for use in Okidata B 8300	11937

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ gearless for use in Okidata B 8300

11938

OKIDATA B 930

Absolute Black® toner for use in Okidata B 930

13036

Developer carrier for drum unit for use in Okidata B 930,

13037

Smartchip™ Drum for use in Okidata B 930

13038

Uni Drum™ with gears for use in Okidata B 930

13040

Smartchip™ Black for use in Okidata C 930, 910

18283

Smartchip™ Cyan for use in Okidata C 930, 910

18284

Smartchip™ Magenta for use in Okidata C 930, 910

18285

Smartchip™ Yellow for use in Okidata C 930, 910

18286

Smartchip™ Black for use in Okidata B 930 (52117101)(US)

19979

OKIDATA B 6500

Cartridge pin for use in Okidata B 6200, 6300, 6500

6792

Clear Seal™ adhesive for use in Okidata B 6200, 6300, 6500, 710, 720, 730

7208

Absolute Black® toner for use in Okidata B 6500

11231

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Okidata B 6500	11234
Doctor blade for use in Okidata B 6500	11710
Drum shutter spring for use in Okidata B 6500, 6300, 6200	11989
Absolute Black® toner for use in Okidata B 6500	13308
Absolute Black® toner for use in Okidata B 6500	13309
Smartchip™ for use in Okidata B 6500	13310
Smartchip™ for use in Okidata B 6500	13311
SuMMiT™ drum with gears for use in Okidata B 6500	15230
X-Generation® Doctor blade for use in Okidata B 6500	17923
X-Generation® Wiper blade for use in Okidata B 6500	17924

OKIDATA C 5100

Absolute Black® toner for use in Okidata C 5100	8555
Absolute Yellow™ toner for use in Okidata C 5100,	8558
Absolute Yellow™ toner for use in Okidata C 5100	8804
Smartchip™ fuse for drum unit for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450	9362
Drum unit wiper blade for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450	9884

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Okidata C 5100	9934
Absolute Yellow™ toner for use in Okidata C 5100	9937
Absolute Black® Glossy toner for use in Okidata C 5100	10190
Absolute Cyan™ Glossy toner for use in Okidata C 5100	10191
Absolute Magenta™ Glossy toner for use in Okidata C 5100	10192
Absolute Yellow™ Glossy toner for use in Okidata C 5100	10193
Absolute Black™ Glossy toner for use in Okidata C 5100	10349
Absolute Cyan™ Glossy toner for use in Okidata C 5100	10350
Absolute Magenta™ Glossy toner for use in Okidata C 5100	10351
Absolute Yellow™ Glossy toner for use in Okidata C 5100	10352
Uni Drum™ with gears for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450	16543

OKIDATA C 511, 531, 330, 310, 321, 301, MC 332, 342, 351, 352, 361, 362, 561, 562 MFP

Absolute Black® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562	17719
Absolute Cyan® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562	17720
Absolute Magenta® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562	17721
Absolute Yellow® toner for use in Okidata C 301, 321, 310, 330, 511, 530, 531, MC 332, 342, 351, 352, 361, 362, 561, 562	17722

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17724
Absolute Magenta® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17725
Absolute Yellow® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17726
Smartchip® Black for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469803)(3,500 pages)	17727
Smartchip® Cyan for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469706)(2,000 pages)	17728
Smartchip® Magenta for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469705)(2,000 pages)	17729
Smartchip® Yellow for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU)(44469704)(2,000 pages)	17730
Smartchip® Cyan toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17732
Smartchip® Magenta toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17733
Smartchip® Yellow toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP	17734
Smartchip® Black toner for use in Okidata C 511, 531, MC 562 MFP	17736
Absolute Black® toner for use in Okidata C 511, 531, MC 562 MFP	17741
Uni Drum® for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP	17793
Smartchip™ drum fuse for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP	18307
Color cartridges chip holder and retainer for use in Okidata C 310, 330, 510, 511, 530, 531, MC 562, 561, 361 MFP	18566
SuMMiT® Drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562, 561, 361 MFP	18733
Smartchip® Cyan for use in Okidata C 841, 831, MC 873 (44844511)(US)	19988

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562	20627
Absolute Cyan® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562	20628
Absolute Magenta® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562	20629
Absolute Yellow® toner for use in Okidata C 301, 310, 321, 330, 511, 530, 531, MC 332, 351, 352, 361, 362, 561, 562	20630

OKIDATA C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

X-Generation® Black glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860	12721
X-Generation® Cyan glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860	12722
X-Generation® Magenta glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860	12723
X-Generation® Yellow glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860	12724
Absolute Cyan® toner for use in Okidata C 810, 830	14229
Absolute Magenta® toner for use in Okidata C 810, 830	14230
Absolute Yellow® toner for use in Okidata C 810, 830	14231
Smartchip™ Black toner for use in Okidata C 810, 830	15422
Smartchip™ Cyan toner for use in Okidata C 810, 830	15423
Smartchip™ Magenta toner for use in Okidata C 810, 830	15424
Smartchip™ Yellow toner for use in Okidata C 810, 830	15425

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMiT® drum with gears for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

16264

Absolute Black® toner for use in Okidata C 810, 830

17378

OKIDATA C 9000, 9100, 9200, 9300, 9400, 9500

Uni Drum™ with gears for use in Okidata C 9000

7522

Absolute Black® toner for use in Okidata C 9000

8389

Smartchip™ fuse for OPC drum unit for use in Okidata C 9000

9648

Drum unit wiper blade for use in Okidata C 9000

9885

Absolute Black® Glossy toner for use in Okidata C 9000

10195

Absolute Cyan™ Glossy toner for use in Okidata C 9000

10196

Absolute Magenta™ Glossy toner for use in Okidata C 9000

10197

Absolute Yellow™ Glossy toner for use in Okidata C 9000

10198

Absolute Black® Glossy toner for use in Okidata C 9000

11900

Absolute Cyan™ Glossy toner for use in Okidata C 9000

11901

Absolute Magenta™ Glossy toner for use in Okidata C 9000

11902

Absolute Yellow™ Glossy toner for use in Okidata C 9000

11903

Drum unit cover for use in Okidata C9000, 9100, 9200, 9300, 9400, 9500

14564

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****OKIDATA C 3000, 3100, 3200, 5100, 5200, 5250, 5300, 5400, 5450, 710, 711**

Absolute Cyan® toner for use in Okidata C 3000, 3100, 3200 9322

Absolute Magenta® toner for use in Okidata C 3000, 3100, 3200 9323

Absolute Yellow® toner for use in Okidata C 3000, 3100, 3200 9324

Smartchip™ fuse for drum unit for use in Okidata C 3000, 3100, 3200, 5100, 5200, 5250 5300, 5400, 5450 9362

Absolute Black® Glossy toner for use in Okidata C 3000, 3100, 3200 10208

Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200 10209

Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200 10210

Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200 10211

Smartchip™ drum unit fuse for use in Okidata C 3000, 3100, 3200 11313

Drum unit wiper blade for use in Okidata C 3000, 3100, 3200 11314

Uni Drum™ with gears for use in Okidata C 3000, 3100, 3200, 5100, 5200, 5250, 5300, 5400, 5450, 710, 711 16543

Uni Drum™ with gears for use in Okidata C 3000, 3100, 3200 16545

Absolute Black® Glossy toner for use in Okidata C 3000, 3100, 3200 16994

Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200 16995

Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200 16996

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200

16997

OKIDATA C 3600, 3530, 3400, 3450, 3300, MC 360

Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10829

Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10830

Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10831

Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

10832

Smartchip™ fuse drum unit for use in Okidata C 3600, 3400, 3300, MC 360

10838

Smartchip™ Black toner for use in Okidata C 3450, 3600

13608

Smartchip™ Magenta toner for use in Okidata C 3450, 3600

13610

Smartchip™ Yellow toner for use in Okidata C 3450, 3600

13611

Smartchip™ Black toner for use in Okidata C 3450, 3600

13612

Smartchip™ Cyan toner for use in Okidata C 3450, 3600

13613

Smartchip™ Magenta toner for use in Okidata C 3450, 3600

13614

Smartchip™ Yellow toner for use in Okidata C 3450, 3600

13615

Drum unit toner sealing cover for use in Okidata C 3600, 3400, 3300, MC 360

14306

Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360

14496

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	14497
Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	14498
Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	14499
Smartchip™ Black for use in Okidata C 3300, 3600, 3400, 3450, 3530	16267
Smartchip™ Cyan for use in Okidata C 3300, 3600, 3400, 3450, 3530	16268
Smartchip™ Magenta for use in Okidata C 3300, 3600, 3400, 3450, 3530	16269
Smartchip™ Yellow for use in Okidata C 3300, 3600, 3400, 3450, 3530	16270
X-Generation® Black toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360	17715
X-Generation® Cyan toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360	17716
X-Generation® Magenta toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360	17717
X-Generation® Yellow toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360	17718
X-Generation® Black toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	18868
X-Generation® Cyan toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	18869
X-Generation® Magenta toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	18870
X-Generation® Yellow toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360	18874

OKIDATA C 5700, 5750, 5600, 5650, 5550, 5700, 5800, 5900, 6000, 6050, 6100

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5700, 5650, 5600, 5550, 5500

10695

Absolute Black® Glossy toner for use in Okidata C 5700, 5600

11161

Absolute Cyan™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11162

Absolute Magenta™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11163

Absolute Yellow™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650

11164

Smartchip™ Black for use in Okidata C 5700, 5600

11165

Smartchip cover for use in Okidata C 6000, 5900, 5500, 711, 710, 610

19889

OKIDATA C 5900, 5800, 5500, CX 2032 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10612

Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10613

Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10614

Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10615

Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10616

Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10617

Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10618

Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032

10619

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500	10620
Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610	10695
Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500,	11747
Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500	11748
Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500	11749
Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500	11750
Smartchip™ Black Toner for use in Okidata C 5900, 5800, 5550	11957
Smartchip™ Cyan Toner for use in Okidata C 5900, 5800, 5550	11958
Smartchip™ Magenta Toner for use in Okidata C 5900, 5800, 5550	11959
Smartchip™ Yellow Toner for use in Okidata C 5900, 5800, 5550	11960
Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033	14301

OKIDATA C 6100, 5550 MFP, B 6100

Absolute Black® toner for use in Okidata B 6100	8364
Absolute MICR™ toner for use in Okidata B 6100	8365
Doctor blade for use in Okidata B 6100	8367
Wiper blade for use in Okidata B 6100	8862

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

PCR roller for use in Okidata B 6100

8890

Seal adhesive for use in Okidata B 6100

8891

Uni Drum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500

10620

Absolute Black® Glossy toner for use in Okidata C 6100, 5550 MFP

10629

Absolute Cyan™ glossy toner for use in Okidata C 6100, 5550 MFP

10630

Absolute Magenta™ glossy toner for use in Okidata C 6100, 5550 MFP

10631

Absolute Yellow™ glossy toner for use in Okidata C 6100, 5550 MFP

10632

Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610

10695

Smartchip™ Black for use in Okidata C 6100, 5550 MFP

11402

Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP

11405

Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033

14301

Smartchip™ Black for use in Okidata C 6100, 5550 MFP

18251

Smartchip™ Cyan for use in Okidata C 6100, 5550 MFP

18252

Smartchip™ Magenta for use in Okidata C 6100, 5550 MFP

18253

Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP

18254

OKIDATA C 7000, 7300, 7400, 7500

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500	8386
Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500	8387
Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500	8388
Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500	8597
Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500	8598
Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500	8599
Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500	8771
Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500	8772
Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500	8773
Uni Drum™ with gear for use in Okidata C 7000, 7300, 7500	8913
Smartchip™ fuse for OPC drum unit for use in Okidata C 7000, 7300, 7500	9992
Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11039
Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11040
Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11041
Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11042
Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11043
Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500	11044

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500

11045

Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500

11046

Drum unit toner sealing cover for use in Okidata C 7000, 7300, 7500

14296

OKIDATA C 710, B 710, 720, 730, 6200, 6300, 6500, MC 560 MFP

Clear Seal™ adhesive for use in Okidata B 6200, 6300, 6500, 710, 720, 730

7208

Absolute Black® Glossy toner for use in Okidata C 710, 711

13042

Absolute Cyan™ Glossy toner for use in Okidata C 710

13043

Absolute Magenta™ Glossy toner for use in Okidata C 710

13044

Absolute Yellow™ Glossy toner for use in Okidata C 710

13045

Smartchip™ drum fuse for use in Okidata C 711, 710, 610, CX 2033, MC 560 MFP

14228

Smartchip™ Black for use in Okidata C 710, 711

15092

Smartchip™ Cyan for use in Okidata C 710, 711

15093

Smartchip™ Magenta for use in Okidata C 710, 711

15094

Smartchip™ Yellow for use in Okidata C 710, 711

15095

Smartchip™ Black for use in Okidata C 710, 711 (44318604)(43866104)(USA)

15096

Smartchip™ Cyan for use in Okidata C 710, 711 (44318603)(43866103)(USA)

15097

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Okidata C 710, 711 (44318602)(43866102)(USA)

15098

Smartchip™ Yellow for use in Okidata C 710, 711 (44318601)(43866101)(USA)

15099

Absolute Black® toner for use in Okidata B 710, 720, 730

18439

Smartchip cover for use in Okidata C 6000, 5900, 5500, 711, 710, 610

19889

OKIDATA C 8600, 8800

Absolute Black® Glossy toner for use in Okidata C 8600, 8800

11928

Absolute Cyan™ glossy toner for use in Okidata C 8600, 8800

11929

Absolute Magenta™ glossy toner for use in Okidata C 8600, 8800

11930

Absolute Yellow™ glossy toner for use in Okidata C 8600, 8800

11931

Smartchip™ Black toner for use in Okidata C 8600, 8800

11932

Smartchip™ Cyan toner for use in Okidata C 8600, 8800

11933

Smartchip™ Magenta toner for use in Okidata C 8600, 8800

11934

Smartchip™ Yellow toner for use in Okidata C 8600, 8800

11935

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12721

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12722

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12723

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12724

Smartchip™ OPC drum unit fuse for use in Okidata C 8600, 8800

13028

X-Generation® Black glossy toner for use in Okidata C 8600, 8800

13105

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800

13106

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800

13107

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800

13108

Uni Drum™ with gears for use in Okidata C 8600, 8800

13329

Drum unit sealing cover for use in Okidata C 8600, 8800

15241

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16099

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16100

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16101

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

16102

SuMMiT™ drum with gears for use in Okidata C 8600, 8800

16264

OKIDATA C 9600, 9800, 9850, 9600, 8800, 8600

Absolute Black® Glossy toner for use in Okidata C 9600, 9800

10621

Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800

10622

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800

10623

Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800

10624

Smartchip™ Black for use in Okidata C 9600, 9800

10625

Smartchip™ Cyan for use in Okidata C 9600, 9800

10626

Smartchip™ Magenta for use in Okidata C 9600, 9800

10627

Smartchip™ Yellow for use in Okidata C 9600, 9800

10628

Smartchip™ OPC drum unit fuse for use in Okidata C 9600, 9800

10849

Uni Drum™ drum with gears for use in Okidata C 9600, 9800

10850

Absolute Black® Glossy toner for use in Okidata C 9600, 9800

11315

Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800

11316

Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800

11317

Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800

11318

X-Generation® Black glossy toner for use in Okidata C 9600, 9650, 9800, 9850

12290

X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12721

X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12722

X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12723

X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850

12724

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Cyan glossy toner for use in Okidata C 9600, 9650, 9800, 9850	13617
X-Generation® Magenta glossy toner for use in Okidata C 9600, 9650, 9800, 9850	13618
X-Generation® Yellow glossy toner for use in Okidata C 9600, 9650, 9800, 9850	13619
Drum unit toner sealing cover for use in Okidata C 9600, 9800	14307
Absolute Black™ glossy toner for use in Okidata C 9600, 9800	14576
Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800	14578
Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800	14579
Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800	14582
X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850	16099
X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850	16100
X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850	16101
X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850	16102
SuMMiT® drum with gears for use in Okidata C 9600, 9800	19559

OKIDATA CX 2366 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Okidata CX 2366	14336
Absolute Cyan™ toner for use in Okidata CX 2366	14337

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ toner for use in Okidata CX 2366

14338

Absolute Yellow™ toner for use in Okidata CX 2366

14339

Smartchip™ Black toner for use in Okidata CX 2366

14340

Smartchip™ Cyan toner for use in Okidata CX 2366

14341

Smartchip™ Magenta toner for use in Okidata CX 2366

14342

Smartchip™ Yellow toner for use in Okidata CX 2366

14343

OKIDATA ES 3640 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Magenta for use in Okidata ES 3640 Pro

15094

Smartchip™ Black for use in Okidata ES 3640

16177

Smartchip™ Cyan for use in Okidata ES 3640

16178

Smartchip™ Magenta for use in Okidata ES 3640

16179

Smartchip™ Yellow for use in Okidata ES 3640

16180

Smartchip™ Black for use in Okidata ES 3640 Pro

17482

Smartchip™ Cyan for use in Okidata ES 3640 Pro

17483

Smartchip™ Magenta for use in Okidata ES 3640 Pro

17484

Smartchip™ Yellow for use in Okidata ES 3640 Pro

17485

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****OKIDATA B 431, 411, MB 491, 471, 461 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Drum unit cover for use in Okidata B 431, 411, MB 491, 471, 461	11936
Smartchip™ for use in Okidata B 431, 411, MB 491, 471, 461	15100
Smartchip™ for use in Okidata B 431, MB 461, 471, 491	17297
Absolute Black® toner for use in Okidata B 431, 411, MB 491, 471, 461	17573
Absolute Black® toner for use in Okidata B 431, MB 491	17574
Smartchip® toner for use in Okidata B 431, MB 491 (44917601)(US, Latin America)	17608
Smartchip® toner for use in Okidata B 431, MB 491 (44917602)(EU)	17609
Smartchip™ drum fuse for use in Okidata B 431, 430, 420, 411, 410, 401, MB 491, 471, 470, 461, 460, 451, 441 MFP	18385
Uni Drum® with gears for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441 MFP	18508
Smartchip™ for use in Okidata B 431, 411, MB 491, 471, 461 (44574701)(US)	18515
Absolute Black® toner for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441	18516
Wiper blade for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441 MFP	18565
Absolute Black® toner for use in Okidata B 431, 411, 401, MB 491, 471, 461, 451, 441	18608
Absolute Black® toner for use in Okidata B 431, 411, MB 491, 471, 461	18609
Smartchip™ drum fuse with contacts for use in Okidata B 431, 430, 411, 401, MB 491, 471, 461, 451, 441 MFP	20643

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****OKIDATA MB 260, 280, 290 MFP**

Smartcard™ reset smartchip for use in Okidata MB 260, 280, 290 MFP	14288
Smartcard™ toner reset smartchip for use in Okidata MB 260, 280, 290 MFP	14600
Absolute black® toner for use in Okidata MB 260, 280, 290 MFP	14601
Uni Drum™ with gears for use in Okidata MB 290, 280, 260	14930

OKIDATA MC 160 MFP, C 130, 110

Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110	14568
Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110	14569
Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110	14570
Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110	14571
Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110	14572
Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110	14573
Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110	14574
Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110	14575

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer roller cover for use in Okidata MC 160 MFP

14581

Developer roller cover for use in Okidata C 130, 110, MC 160 MFP

18288

OKIDATA MC 860, 830, 810, 9800, 9850, 9600, 9650, 8800, 8600,

X-Generation® Black glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12721

X-Generation® Cyan glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12722

X-Generation® Magenta glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12723

X-Generation® Yellow glossy toner for use in Okidata C 810, 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860

12724

Smartchip™ OPC drum unit fuse for use in Okidata C 8800, 8600, 830, 821, 810, 801, MC 861, 860, 851

13028

Absolute Black® toner for use in Okidata MC 860

14310

Absolute Cyan™ toner TBAg for use in Okidata MC 860

14311

Absolute Magenta™ toner TBAg for use in Okidata MC 860

14312

Absolute Yellow™ toner TBAg for use in Okidata MC 860

14313

Smartchip™ Black toner for use in Okidata MC 860

14314

Smartchip™ Cyan toner for use in Okidata MC 860

14315

Smartchip™ Magenta toner for use in Okidata MC 860

14316

Smartchip™ Yellow toner for use in Okidata MC 860

14317

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Drum unit sealing cover for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

15241

Smartchip™ Black toner for use in Okidata MC 860

15550

Smartchip™ Cyan toner for use in Okidata MC 860

15551

Smartchip™ Magenta toner for use in Okidata MC 860

15552

Smartchip™ Yellow toner for use in Okidata MC 860

15553

Smartchip™ Black drum unit toner for use Okidata MC 860

15554

Smartchip™ Cyan drum unit toner for use Okidata MC 860

15555

Smartchip™ Magenta drum unit toner for use Okidata MC 860

15556

Smartchip™ Magenta drum unit toner for use Okidata MC 860

15557

X-Generation® Black glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16099

X-Generation® Cyan glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16100

X-Generation® Magenta glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16101

X-Generation® Yellow glossy toner for use in Okidata C 830, 8600, 8800, 9600, 9650, 9800, 9850, MC 860, 1kg

16102

SuMMiT® drum with gears for use in Okidata C 8600, 8800, 830, 821, 810, 801, MC 861, 860, 851

16264

OKIDATA 5900, 5780, 5750, 5700, 5680, 4515

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Okidata 5900, 5780, 5750, 5700, 5680, 4515

5636

PANASONIC®**PANASONIC DP 2000, 2500, 3000**

Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000

13912

Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000

16715

PANASONIC WORKIO DP 310, 2330, 3010, 3030

Uni Drum™ drum with gears for use in Panasonic Workio DP 2310, 2330, 3010, 3030

10297

RICOH®**RICOH AFICIO 200, 250, FX 200**

Wiper blade for use in Ricoh Aficio 200, 250

5148

Drum with gears for use in Ricoh Aficio 200, 250 F

7272

Drum with gears for use in Ricoh Aficio 200, 250 S,

8548

Absolute Black® toner for use in Ricoh Aficio 200, 250

8735

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer for use in Ricoh Aficio 200, 250	8793
Developer for use in Ricoh Aficio 200, 250	8794
Absolute Black® toner for use in Ricoh Aficio 200, 250	9470
Absolute Black® toner for use in Ricoh Aficio FX 200, Type 2285	11321
Smartchip™ for use in Ricoh Aficio FX 200, Type 2285	11322
Ricoh Aficio FX 200, Type 2285 Uni Drum™ OEM style with gears	11323
PCR roller for use in Ricoh Aficio FX 200, Type 2285	11328
Supply roller for use in Ricoh Aficio FX 200, Type 2285	11329

RICOH AFICIO 350, 450

Uni Drum™ S with gears for use in Ricoh Aficio 340, 350, 450	7271
Uni Drum™ F with gears for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045	7412
Absolute Black® toner for use in Ricoh Aficio 350, 450	8734
Absolute Black® toner for use in Ricoh Aficio 350, 450	9469
Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035)	12123
Wiper blade for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045	12575
X-Generation® Wiper blade for Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045	16522

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Transfer belt cleaning blade for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 2035, 2045, 3035, 3045, MP 3500, SP 8100 (A232-3930)	19245
Paper feed roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1045 P, 1045, 1035, 350, 355, 450, SP 500, 480, 360, COLOR 3506, 3006 (AF031035)	19468
Paper separation roller for use in Ricoh Aficio 1035, 1045, 340, 350, 450, AP4500, 4510, Color 3006, PS360, 380, 420, 430, 500 (AF03-2035)	19656
PCR for use in Ricoh Aficio 1045, 1035, 455, 450, 355, 350, 340, AP 4510, 4500 (AD027006)	19858

RICOH AFICIO 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085	7270
Uni Drum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105	8547
Wiper blade for use in Ricoh Aficio 550, 650, 850	12553
Upper Fuser Roller for use in Ricoh Aficio 550, 551, 650, 700, MP 9001, 9002 (AE011044)	19497
Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)	19650
ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295)	19838

RICOH AFICIO 1015, 1018, 2015, 2020

Wiper blade for use in Ricoh Aficio 1015, 1018	12550
Uni Drum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027	12712
Upper fuser picker finger for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (AE044062)	19452

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Fuser thermistor for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (AW100073)	19463
Paper feed roller for use in Ricoh Aficio 2020, 2015, 1018, 1015, MP 2500, 2000, 1600 (B0392740)	19464
Primary Charge roller for use in Ricoh Aficio 1015, 1018, 2015, 2016, 2018, 2020, 3025, 3030, MP 1600, 2000, 2510, 2550, 2852, 3010, 3350, 3352 (AD027018)	19467
Upper fuser roller for use in Ricoh Aficio 1015, 1018 (AE011065)	19586
Lower fuser pressure roller for use in Ricoh Aficio 1015, 1018 (AE02-0100)	19647

RICOH AFICIO 1022, 1027, 2022

OPC drum cleaning blade for use in Ricoh Aficio 220, 270,1022, 1027, 1032, 2022, 2027, 3025, 3030, MP 2352, 2510, 2550 (AD041114)	12552
Uni Drum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027	12712
Drum with gears for use in Ricoh Aficio 1022, 1027, 2022	12713
Lower pressure roller for use in Ricoh Aficio 1022, 1027, 2022, 2027, 3030, 3025, MP 2510, 2550, 2852, 3010, 3350, 3352 (AE020138)	19291
Upper fuser roller for use in Ricoh Aficio 1022, 1027, 2022, 2027, 3030, 3025, MP 2510, 2550, 2852, 3010, 3350, 3352	19293
Upper fuser picker finger for use in Ricoh Aficio 2027, 2022, 1027, 1022, 3030, 3025, MP 3352, 3350, 3010, 2550 (AE044025)	19453
Drum unit for use in Ricoh Aficio 1022, 1027, 2022, 2027, 2032, 3025, 3030, MP 2510, 2550, 2851, 3010, 3350, 3351	19462
Lower cleaning roller for use in Ricoh Aficio 1022, 2022, 3025, 3030, AP 2700, 3200, MP 2510, 2851, 3010, 3350 (AE042029)	19583
Paper feed roller for use in Ricoh Aficio 1022, 1027, 2022, 220, 270, 3025, AP2700, 3200, MP2500, 2550, 3010, 3350, PB3030, PS400, 450 (A2672751)	19655
Developer gear 5 piece kit for use in Ricoh Aficio 2032, 2027, 2022, 1032, 1022, 1027 (411018)	21012

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

PCR roller for use in Ricoh Aficio 2027, 2022, 1027, 1022

21063

RICOH AFICIO 1060, 1075, 2051, 2060

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

7270

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

8547

Uni Drum™ with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

12299

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060

12299

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500 (USA)

12553

Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105

15107

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060

17925

Transfer belt cleaning blade for use in Ricoh Aficio 2075SP, 2075, 2060SP, 2060, 2051, 1075, 1060, MP 9100, 9002, 8002, 7500, 6500, 6000, 5500

19286

Lower sleeved roller for use in Ricoh Aficio 1075, 1060, SP 9100 (AE020112)

19496

Upper fuser roller for use in Ricoh Aficio 1060, 1075 (AE011069)

19587

Fuser cleaning web roller for use in Ricoh Aficio 1060, 1075, SP 9100 DN (AE045046)

19619

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500 (S. AMERICA)

20626

RICOH AFICIO 2035, 2045, 3035, 3045

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMIT® OPC drum with gears for use in Ricoh Aficio 340, 350, 450, 1035, 1045, 2035, 2045, 3035, 3045, 4500, 4510, MP 4500, 3500	7271
Uni Drum™ F with gears for use in Ricoh Aficio 340, 350, 450, 1035, 1045, 2035, 2045, 3035, 3045	7412
Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035)	12123
Wiper blade for use in Ricoh Aficio 2035, 2045, 3035, 3045	12575
X-Generation® Wiper blade for Ricoh Aficio 2035, 2045, 3035, 3045	16522
Transfer belt cleaning blade for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 2035, 2045, 3035, 3045, MP 3500, SP 8100 (A232-3930)	19245
Lower fuser pressure roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, SP 8100, MP 4500, 3500 (AE020123, AE020125)	19448
Transfer belt for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 1045, 2035, 2045, 3035, 3045, MP 3500, 4000, 5000, 5001, 5002, SP 8100 (A232-3880)	19504
Upper Fuser roller for use in Ricoh Aficio 1035, 2035, 2045, 3035, 3045, AP 4510, MP 3500, MP 4500, SP8100 (AE011071)	19508
Lower cleaning roller for use in Ricoh Aficio 2035, 2045, 3035, 3045 (AE042084)	19584
Paper separation roller for use in Ricoh Aficio 1035, 1045, 340, 350, 450, AP4500, 4510, Color 3006, PS360, 380, 420, 430, 500 (AF03-2035)	19656
Primary Charge Roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, MP 5000, 4500, 4000, 3500 (AD02-7012)	19852
Cleaning roller for use in Ricoh Aficio 3045, 3035, 2045, 2035, MP 5000, 4500, 4000, 3500 (B082-2329)	19853

RICOH AFICIO 3800, 3850

Black toner for use in Ricoh Aficio 3800, 3850	8134
Drum with gears for use in Ricoh Aficio 3800	9694

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH AFICIO SP 100e, 100SF, 100SU, 200, 201, 202, 203, 204**

SuMMiT® drum with gears for use in Ricoh Aficio SP 204, 203, 202, 201, 200, 100e, 100SF, 100SU

18524

Smartchip™ for use in Ricoh Aficio SP 100e, 100SF, 100SU (407165, 407166, 407167)(US, LATAM, Asia)

18550

Smartchip™ for use in Ricoh Aficio SP 100e, 100SF, 100SU (407166)(EUR)

18576

Wiper blade for use in Ricoh Aficio SP 204, 203, 202, 201, 200, 100e, 100SF, 100SU

19247

RICOH AFICIO SP 300

Smartchip® for use in Ricoh Aficio SP 3300

14818

Uni Drum® OPC with gears for use in Ricoh SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735

Absolute Black® toner for use in Ricoh Aficio SP 300

17834

Uni Drum® with gears for use in Ricoh Aficio SP 300 dn

17835

Smartchip® for use in Ricoh Aficio SP 300

17837

RICOH AFICIO SP 3400, 3410

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF

17301

Uni Drum® OPC with gears for use in Ricoh Aficio SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Ricoh Aficio SP 3400, 3410, 3410SF	17742
Absolute Black® toner for use in Ricoh Aficio SP 3500, 3510, 3510SF, 3400, 3410, 3410SF	17770
Wiper blade for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF	19149
Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF	19151
SuMMiT® drum with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF	19152
Developer roller for use in Ricoh SP 3500, 3400	19561

RICOH AFICIO SP 5200, 5210

Smartchip™ for use in Ricoh Aficio SP 5200, 5210	18256
Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210	18257
Wiper blade for use in Ricoh Aficio SP 5200, 5210 SF, 5210 SR	18799
SuMMiT® Drum with gears for use in Ricoh Aficio SP 5200, 5210	19024
Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210	19084
Upper Fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4101)	19384
Lower sleeved fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4059)	19385
Doctor blade for use in Ricoh Aficio SP 5210, 5200	20432
Developer roller for use in Ricoh SP 5200, 5210, MFP 5200S, 5210SF	20729

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH AFICIO SP C 430, 431**

Paper separation roller "tire only" for use in Ricoh Aficio AP 4510, 4500, 1035,1045, 1045, 455, 450, 355, 350, 340, Color 3006, 3506, PS 360, 380, 390, 420, 430, 500 (AF032035)	12123
Smartchip for use in Ricoh Aficio SPC 430, 431 Black	17756
Smartchip for use in Ricoh Aficio SPC 430, 431 Cyan	17757
Smartchip for use in Ricoh Aficio SPC 430, 431 Magenta	17758
Smartchip for use in Ricoh Aficio SPC 430, 431 Yellow	17759
Absolute Black® toner for use in Ricoh Aficio SPC 430, 431	17826
Absolute Cyan® toner for use in Ricoh Aficio SPC 430, 431	17827
Absolute Magenta® toner for use in Ricoh Aficio SPC 430, 431	17828
Absolute Yellow® toner for use in Ricoh Aficio SPC 430, 431	17829
Absolute Black® toner for use in Ricoh Aficio SPC 430, 431	19203
Absolute Cyan® toner for use in Ricoh Aficio SPC 430, 431	19204
Absolute Magenta® toner for use in Ricoh Aficio SPC 430, 431	19205
Absolute Yellow® toner for use in Ricoh Aficio SPC 430, 431	19206
X-Generation® Black toner for use in Ricoh Aficio SPC 430, 431	19762
X-Generation® Cyan toner for use in Ricoh Aficio SPC 430, 431	19763

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Magenta toner for use in Ricoh Aficio SPC 430, 431

19764

X-Generation® Yellow toner for use in Ricoh Aficio SPC 430, 431

19765

RICOH AFICIO SP 4100

Clear Seal™ adhesive for toner hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

12259

Clear Seal™ adhesive for carrier hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

12260

Smartchip™ for use in Ricoh Aficio SP 4100N KP, 4110N KP, 4210N

13313

Wiper blade for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

15808

Uni Drum™ with gears for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

15809

Smartchip™ for use in Ricoh Aficio SP 4100 NL

15956

X-Generation® Black toner for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

17331

X-Generation® toner developer for use in Ricoh Aficio SP 4100, 4110, 4210, 4310

17342

X-Generation® Black toner for use in Ricoh Aficio SP 4100 NL

17624

X-Generation® Black toner for use in Ricoh SP 4100, 4110, 4210, 4310

18884

X-Generation® toner developer for use in Ricoh SP 4100, 4110, 4210, 4310

18885

RICOH AFICIO SP C 220, 221, 222

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ S with gears for use in Ricoh Aficio 220, 270 S	8542
Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222	12310
Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222	12311
Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222	12312
Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222	12313
Wiper blade for use in Ricoh Aficio 220, 270	12552
SuMMiT™ drum with gears for use in Ricoh Aficio 220, 270	12711
Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222	13064
Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222	13065
Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222	13066
Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222	13067
Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222	13126
Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222	13127
Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222	13128
Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222	13129
Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222	14938
Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222	14939

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222	14940
Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222	14941
Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222	16550
Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222	16551
Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222	16552
Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222	16553
Uni Drum™ with gear for use in Ricoh SPC 320, 312, 311, 310, 252, 242, 232, 231, 222, 221, 220	16789
Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222	16925
Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222	16926
Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222	16927

RICOH AFICIO 551, 700

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085	7270
Uni Drum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105	8547
Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105	12553
Copier toner for use in Ricoh Aficio 551, 700, Type 5105,	16713
Lower fuser pressure roller for use in Ricoh Aficio 1055, 1050, 700, 650, 551, 550 (AE022078)	19447

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Upper Fuser Roller for use in Ricoh Aficio 550, 551, 650, 700, MP 9001, 9002 (AE011044)	19497
Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)	19650
ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295)	19838

RICOH AFICIO MP C 3500, 4500

Absolute Black® toner for use in Ricoh Aficio MPC 3500, 4500	12558
Absolute Magenta™ toner for use in Ricoh Aficio MP C 3500, 4500	12560
Absolute Yellow™ toner for use in Ricoh Aficio MP C 3500, 4500	12561
Smartchip™ Black for use in Ricoh Ipcio SPC 810, 811	13722
Absolute Cyan™ toner for use in Ricoh Aficio MP C 3500, 4500	14630
Smartchip™ Black for use in Ricoh Aficio MP C 3500, 4500	14631
Smartchip™ Cyan for use in Ricoh Aficio MP C 3500, 4500	14632
Smartchip™ Magenta for use in Ricoh Aficio MP C 3500, 4500	14633
Smartchip™ Yellow for use in Ricoh Aficio MP C 3500, 4500	14634
Absolute Black® toner for use in Ricoh Aficio® MPC 2000, 2500, 3000, 3500, 4500	14635
Absolute Cyan® toner for use in Ricoh Aficio® MPC 2000, 2500, 3000, 3500, 4500	14637
Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500	14638

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500	14639
Wiper blade for use in Ricoh MPC 4500, 3500, 3000, 2500, 2000	19224
Uni Drum® with gears for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000	19426
Transfer belt wiper blade for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000 (B233-6023)	19720
Transfer belt cleaning blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3500, 3300, 3000, 2800, 2500, 2000	20439

RICOH AFICIO MP C 2000, 2500, 3000

Absolute Black® toner for use in Ricoh Aficio MP C 2000, 2500, 3000	13173
Absolute Cyan™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000	13174
Absolute Magenta™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000	13175
Absolute Yellow™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000	13176
Absolute Black® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500	14635
Absolute Cyan® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000	14636
Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500	14638
Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500	14639
Smartchip™ Black (20,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14952
Smartchip™ Cyan (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14953

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000

14954

Smartchip™ Yellow (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000

14955

Wiper blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3300, 2800, 2500, 2000

18300

Wiper blade for use in Ricoh MPC 4500, 3500, 3000, 2500, 2000

19224

Uni Drum® with gears for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000

19426

Transfer belt wiper blade for use in Ricoh Aficio MPC 4500, 3500, 3000, 2500, 2000 (B233-6023)

19720

Transfer belt cleaning blade for use in Ricoh Aficio MPC 5000, 4500, 4000, 3500, 3300, 3000, 2800, 2500, 2000

20439

RICOH AFICIO IPSIO CX 7100, 7500

Uni Drum with gears for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000

9270

RICOH AP 1400, 1600

Absolute Black® toner for use in Ricoh AP 1400, 1600

9344

Absolute Black® toner for use in Ricoh AP 1400, 1600

5128

RICOH AP 400, 410

Uni Drum™ with gears for use in Ricoh AP 400, 410

9768

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Clear Seal™ adhesive for toner hopper for use in Ricoh AP 400, 410

9772

Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 400, 410

9773

Wiper blade for use in Ricoh AP 400, 410

11775

Smartchip™ for use in Ricoh AP 400, 410

12175

X-Generation® Black toner for use in Ricoh AP 400, 410

17330

X-Generation® toner developer for use in Ricoh AP 400, 410

17341

RICOH AP 600, 610, 2600, 2610

Clear Seal™ adhesive for toner hopper for use in Ricoh AP 600, 610, 2600, 2610

9775

Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 600, 610, 2600, 2610

9776

Wiper blade for use in Ricoh AP 600, 610, 2600, 2610

9777

Uni Drum™ with gears for use in Ricoh AP 600, 610, 2600, 2610

9778

Smartchip™ for use in Ricoh AP 2610, 2600, 610, 600 toner

15219

X-Generation® Black toner for use in Ricoh AP 600, 610, 2600, 2610

17335

X-Generation® toner carrier for use in Ricoh AP 600, 610, 2600, 2610

17339

X Generation Wiper blade for use in Ricoh AP 600, 610, 2600, 2610

18575

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH IMAGIO P TYPE 2**

Uni Drum™ S drum with gears for use in Ricoh Imagio P Type 2

8707

RICOH IMAGIO CA, CF, DA SERIES TYPE 1

Absolute Black® toner for use in Ricoh Imagio CA, CF, DA Series, Type 1

8151

RICOH IMAGIO TYPE 18

Absolute Black® toner for use in Ricoh Imagio Type 18

8730

RICOH IMAGIO TYPE 4

Absolute Black® toner for use in Ricoh Imagio Type 4

8148

RICOH IMAGIO TYPE 7

Absolute Black® toner for use in Ricoh Imagio Type 7

8732

RICOH IMAGIO TYPE 900

Absolute Black® toner for use in Ricoh Imagio Type 900

6758

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Ricoh Imagio Type 900

6624

RICOH IPSIO CX 6000, 6100, 6600

Absolute Black® toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9734

Absolute Cyan™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9735

Absolute Magenta™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9736

Absolute Yellow™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600

9738

RICOH IPSIO SP C 710, 711

Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711

11727

Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11728

Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11729

Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711

11730

Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711

12729

Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12730

Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12731

Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711

12732

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black toner for use in Ricoh Ipsio SP C 710, 711	13264
Smartchip™ Cyan toner for use in Ricoh Ipsio SP C 710, 711	13267
Smartchip™ Magenta toner for use in Ricoh Ipsio SP C 710, 711,	13268
Smartchip™ Yellow toner for use in Ricoh Ipsio SP C 710, 711	13270
Drum unit sealing cover for use in Ricoh Ipsio SP C 710	15246

RICOH IPSIO SP C 810, 811 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811	12562
Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811	12563
Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811	12564
Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811	12565
Absolute Black® toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811	12566
Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811	12567
Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811	12568
Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811	12569
Smartchip™ Black for use in Ricoh Ipsio SPC 810, 811	13722
Smartchip™ Cyan for use in Ricoh Ipsio SPC 810, 811	13723

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Ricoh Ipsio SPC 810, 811

13724

Smartchip™ Yellow for use in Ricoh Ipsio SPC 810, 811

13725

Uni Drum® with gears for use in Ricoh Ipsio SPC 810, Aficio SPC 811

17522

RICOH IPSIO SP C 820, 821, 811 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black for use in Ricoh Aficio SPC 811

13727

Smartchip™ Cyan for use in Ricoh Aficio SPC 811

13728

Smartchip™ Magenta for use in Ricoh Aficio SPC 811

13729

Smartchip™ Yellow for use in Ricoh Aficio SPC 811

13730

Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17943

Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17944

Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17945

Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17946

Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17947

Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17948

Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17949

Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821

17950

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	17951
Absolute Cyan™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	17952
Absolute Magenta™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	17953
Absolute Yellow™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	17954
Absolute Black® Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	19195
Absolute Cyan™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821,	19196
Absolute Magenta™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	19197
Absolute Yellow™ Glossy toner for use in Ricoh Ipsiio SPC 820, 821, Aficio SPC 820, 821	19198

RICOH AFICIO 1515, MP 301 SP 301 SPF, 201, 171, 161

Uni Drum® gearless for use in Ricoh Aficio 1515, MP 201, 171, 161	19237
Upper Fuser roller for use in Ricoh Aficio 1515, MP 171F, 201 SPF (AE01-1061/AE01-1086)	19382
Upper Fuser roller for use in Ricoh Aficio MP 301 SP, 301 SPF (AE01-1131)	19383
Lower sleeved fuser roller for use in Ricoh Aficio 1515, 161 F, 171 F (AE02-0107)	19386
Wiper blade for use in Ricoh Aficio 1515, MP 201, 171, 161	19417
Lower Fuser roller for use in Ricoh Aficio MP 301 SP, 301 SPF (AE02-0207)	19601
Paper feed roller for use in Ricoh Aficio 1515, 1013, 120, MP 301, 201, 171, 161, SP 220 (AF03-1061)	19682

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer for use in Ricoh Aficio 1515, MP 301, 201, 171, 161, 275 bag (Type 1515, 411844)

20648

Upper fuser roller bushing set (2) for use in Ricoh Aficio 1515, 1013, 120, MP 201, 171, 161 (AE03-1034)

21004

Fuser thermistor for use in Ricoh Aficio 1515, MP 301, 201, 171, 161 (AW100088)

21008

RICOH AFICIO MP C 6000, 6501, 7500, 7501

Absolute Black toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501 (841084, 841288)

20375

RICOH AFICIO MP 8000, 7500, 6500, 6000, 5500

Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 8000, 7500, 7000, 6500, 6000, 5500

17925

RICOH AFICIO 1224 C, 1232 C

Absolute Black® toner for use in Ricoh Aficio 1224 C, 1232 C

9755

Absolute Cyan™ toner for use in Ricoh Aficio 1224 C, 1232 C

9756

Absolute Magenta™ toner for use in Ricoh Aficio 1224 C, 1232 C

9757

Absolute Yellow™ toner for use in Ricoh Aficio 1224 C, 1232 C

9758

Absolute Black® toner for use in Ricoh Aficio 1224 C, 1232 C

13193

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan™ toner for use in Ricoh Aficio 1224 C, 1232 C

13194

Absolute Magenta™ toner for use in Ricoh Aficio 1224 C, 1232 C

13195

Absolute Yellow™ toner for use in Ricoh Aficio 1224 C, 1232 C

13196

RICOH AFICIO 2105

Uni Drum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

7270

Uni Drum™ with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1075, 1085, 1105, 2051, 2060, 2075, 2090, 2105

8547

Wiper blade for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1055, 1060, 1085, 1105, 2060, 2075, 2090, 2105

12553

Absolute Black® toner for use in Ricoh Aficio 2105

16340

Paper separation roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085, 1050, 1055, MP 8000, 7500, 6500, 6000, 5500, 1350, 1100, 5560C, 3260C (AF032080, AF030240)

19465

Transfer Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A2293899)

19650

ADF Paper Feed Belt for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, 700, 650, 551, 550, 500, 400 (A806-1295)

19838

ADF Separation (Reverse) Roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, MP 9000, 8000, 7000, 6000, 5000 (A859-2241)

19847

RICOH AFICIO 3228, 3235, 3245 C

Absolute Black® toner for use in Ricoh Aficio 3228, 3235 3245 C

10019

Absolute Cyan™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10020

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10021

Absolute Yellow™ toner for use in Ricoh Aficio 3228, 3235 3245 C

10022

Uni Drum® with gears for use in Ricoh Aficio 3228, 3235, 3245 C (B1809511)

19446

RICOH AFICIO MP C 2800, 2880, 3001, 3300, 4501, 5000, 5050, 5501

Absolute Black® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5050, 5501

19766

Absolute Cyan® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19767

Absolute Magenta® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19768

Absolute Yellow® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4501, 5000, 5501

19769

Absolute Black® toner for use in Ricoh Aficio MPC 2800, 2880, 3300, 4000, 5000, 5050

20054

Absolute Cyan® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20055

Absolute Magenta® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20056

Absolute Yellow® toner for use in Ricoh Aficio MPC 2800, 2880, 3001, 3300, 4000, 4051, 5000, 5501

20057

RICOH AFICIO SP 311, 311 SFN

SuMMiT® drum with gears for use in Ricoh Aficio SP 311, 310, 300

17835

Wiper blade for use in Ricoh SP 311, 310, 300

19234

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® for use in Ricoh Aficio SP 311, 310 (407246)(EU)

19256

Absolute Black® toner for use in Ricoh Aficio SP 311, 311 SFN, 310

19281

Absolute Black® toner for use in Ricoh SP 311, 311 SFN, 300

19282

RICOH 4510, 4520, 3610, 3600

Smartchip® for use in Ricoh SP 4510 (407316)(US)

19808

Smartchip® for use in Ricoh SP 4510, 3610, 3600 (407319)(US)

19809

Smartchip® for use in Ricoh SP 4510 (407318)(EU)

19810

Smartchip® drum unit for use in Ricoh SP 4510, 3610, 3600 (407324)(WW)

19812

Absolute Black® toner for use in Ricoh Aficio SP 4510, 4500

20325

Absolute Black® toner for use in Ricoh Aficio SP 4520, 4510, 3610, 3600

20326

Absolute Black® toner for use in Ricoh Aficio SP 4510, 3610, 3600

20328

RICOH AFICIO SP 5200, 5210

Smartchip™ for use in Ricoh Aficio SP 5200, 5210 (406685, 406683, 406689)(WW)

18256

Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210,

18257

Wiper blade for use in Ricoh Aficio SP 5200, 5210 SF, 5210 SR

18799

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMiT® Drum with gears for use in Ricoh Aficio SP 5200, 5210	19024
Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210	19084
Upper Fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4101)	19384
Lower sleeved fuser roller for use in Ricoh Aficio SP 5200, 5210 (M052-4059)	19385
Doctor blade for use in Ricoh Aficio SP 5210, 5200	20432
Developer roller for use in Ricoh SP 5200, 5210, MFP 5200S, 5210SF	20729

RICOH AFICIO MP C 3002, 3502

Uni Drum® with gears for use in Ricoh Aficio MPC 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001 (D144-2253)	19480
Absolute Black® toner for use in Ricoh Aficio MPC 3502, 3002	21102
Absolute Cyan® toner for use in Ricoh Aficio MPC 3502, 3002,	21103
Absolute Magenta® toner for use in Ricoh Aficio MPC 3502, 3002	21104
Absolute Yellow® toner for use in Ricoh Aficio MPC 3502, 3002	21105
Absolute Black® toner for use in Ricoh Aficio MPC 3502, 3002	21106
Absolute Cyan® toner for use in Ricoh Aficio MPC 3502, 3002	21107
Absolute Magenta® toner for use in Ricoh Aficio MPC 3502, 3002	21108
Absolute Yellow® toner for use in Ricoh Aficio MPC 3502, 3002	21109

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH AFICIO MP C 2030, 2050, 2350, 2550**

Smartchip™ Black for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841280)(EU) 18435

Smartchip™ Cyan for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841281)(EU) 18436

Smartchip™ Magenta for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841282)(EU) 18437

Smartchip™ Yellow for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841283)(EU) 18438

Uni Drum® with gears for use in Ricoh Aficio MPC Color 2551, 2550, 2530, 2051, 2050, 2030 (D8092000, D8092001, D8092002, D8092003) 19476

Lower Fuser roller for use in Ricoh Aficio MP C 2550, 2530, 2050, 2030 (AE02-0175) 19603

Hot roller for use in Ricoh Aficio MP C 2550, 2530, 2050, 2030 (AE01-0074) 19604

Smartchip™ Black for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841280)(US) 20329

Smartchip™ Cyan for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841281)(US) 20330

Smartchip™ Magenta for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841282)(US) 20331

Smartchip™ Yellow for use in Ricoh Aficio MPC 2030, 2050, 2350, 2550 (841283)(US) 20332

RICOH AFICIO SP 5310, 5300, MP 601, 501 SPF

Smartchip® toner for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF (407823)(US) 20997

Absolute Black® toner for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF 20998

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Waste toner bottle for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF

20999

RICOH AFICIO SP 5310, 5300, MP 601, 501 SPF

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

17301

Uni Drum® with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

17735

Absolute Black® toner for use in Ricoh SP 3500, 3510, 3510SF

17743

Absolute Black® toner for use in Ricoh SP 3500, 3510, 3510SF, 3400, 3410, 3410SF

17770

Wiper blade for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19149

Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19151

SuMMiT® drum with gears for use in Ricoh SP 3400, 3410, 3410SF, 3500, 3510, 3510SF

19152

RICOH AFICIO MP C 4420, 4410, 4400

Absolute Black® toner for use in Ricoh Aficio SP 4420 SF, 4410 SF, 4400 SF

18839

Smartchip™ for use in Ricoh Aficio SP 4420, 4410, 4400 (406978)

18840

RICOH MP C 2503, 2003

Smartchip® Black toner for use in Ricoh MPC 2503, 2003 (841918)

20351

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Cyan toner for use in Ricoh MPC 2503, 2003 (841921)	20352
Smartchip® Magenta toner for use in Ricoh MPC 2503, 2003 (841920)	20353
Smartchip® Yellow toner for use in Ricoh MPC 2503, 2003 (841919)	20354
Uni Drum® with gears for use in Ricoh Aficio MPC 2503, 2003	20938

RICOH MP C 6003, 5503, 4503, 3503, 3003

Smartchip® Black toner for use in Ricoh MPC 6003, 5503, 4503 (841849)(US)	20359
Smartchip® Cyan toner for use in Ricoh MPC 6003, 5503, 4503 (841852)(US)	20360
Smartchip® Magenta toner for use in Ricoh MPC 6003, 5503, 4503 (841851)(US)	20361
Smartchip® Yellow toner for use in Ricoh MPC 6003, 5503, 4503 (841850)(US)	20362
Uni Drum® with gears for use in Ricoh Aficio MP C 6003, 5503, 4503, 3503, 3003	20533

RICOH AFICIO MP C 401 SR, 400, 300

Uni Drum® with gears for use in Ricoh Aficio MPC Color 401 SR, 400, 300 (M0262015)	19478
Paper feed roller for use in Ricoh Aficio 3045, 3035, MP 4500, 4001, 4000, 3500, 3353, 3352, 3053, 2852, 2553, 2352, MPC 401 (AF03-1090)	19681
Pickup roller for use in Ricoh Aficio 3045, 3035, MP 4500, 4001, 4000, 3500, 3353, 3352, 3053, 2852, 2553, 2352, MPC 401 (AF030090)	19690

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH MP 401 SF, SP 4520**

Smartchip® for use in Ricoh MP 401 SF, SP 4520 (841886)(US)

20539

Smartchip® for use in Ricoh MP 401 SF, SP 4520 (841887)(EU)

20540

Smartchip® drum unit for use in Ricoh MP 401 SF, SP 4520 (M906-0118)(US)

20658

SuMMiT® drum with gears for use in Ricoh MP 401, SP 4520, 4510, 3610, 3600

20659

Absolute Black® toner for use in Ricoh Aficio SP 4520, MP 401 SF

20699

RICOH AFICIO PRO 901, 900, 720

Uni Drum® with gears for use in Ricoh Aficio Pro Color 901, 900, 720 (D0169510)

19479

RICOH AFICIO MP 9000, 1350, 1100, Pro 1107, 907

Uni Drum® with gears for use in Ricoh Aficio MP 9000, 1100, 1350, Pro 1106

19239

ADF Separation (Reverse) Roller for use in Ricoh Aficio 2105, 2090, 2075, 2060, 2051, 1105, 1085 1055, 1050, MP 9000, 8000, 7000, 6000, 5000 (A859-2241)

19847

Wiper blade for use in Ricoh Aficio MP 9000, 1350, 1100 (B2343564)

20440

Upper Fuser Roller for use in Ricoh Aficio MP 9000, 1100, Pro 1107, 907 (AE011108)

21010

Developer for use in Ricoh Aficio MP 9000, 1350, 1100, Pro 1357, 1107, 907 (B2349640)

21011

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****RICOH AFICIO MP 5002, 5001, 5000, 4002, 4001, 4000**

Wiper blade for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000	18301
Uni Drum® with gears for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000	19238
Transfer belt for use in Ricoh Aficio 340, 350, 355, 450, 455, 1035, 1045, 2035, 2045, 3035, 3045, MP 3500, 4000, 5000, 5001, 5002, SP 8100 (A232-3880)	19504
Drum cleaning blade for use in Ricoh Aficio MP 4000, 4001, 4002, 5000, 5002 (D0092351)	19505
Upper Fuser roller for use in Ricoh Aficio MP 4000, 4001, 4002, 5000, 5001, 5002 (AE010099)	19507
Lower Fuser roller for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (AE020199)	19689
Upper fuser picker finger for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (AE04-4099)	19855
Fuser thermistor for use in Ricoh Aficio MP 5002, 5001, 5000, 4002, 4001, 4000 (D009-4177)	19856
Developer for use in Ricoh Aficio MP 5002, 5001, 5000, 4500, 4002, 4001, 4000, 3500 (B2969640)	21009

RICOH AFICIO MP C 7501, 7500, 6501, 6000, Pro C550 EX

Uni Drum® with gears for use in Ricoh Aficio MPC 7501, 7500, 6501, 6000, Pro C550 EX (D0149510)	19629
Absolute Black toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 900g (841084, 841288)	20375
Absolute Cyan toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841085, 841289)	20376
Absolute Magenta toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841086- 841290)	20377
Absolute Yellow toner for use in Ricoh Aficio MPC 6000, 6501, 7500, 7501, 500g (841087, 841291)	20378

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Wiper blade for use in Ricoh Aficio MPC 7501, 7500, 6501, 6000

20441

RICOH MP C 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001

Uni Drum® with gears for use in Ricoh Aficio MPC 5502, 5501, 4502, 4501, 3502, 3501, 3002, 3001 (D144-2253)

19480

RICOH CL 7000

Black toner for use in Ricoh CL 7000, 7100

10382

Drum with gears for use in Ricoh CL 7000

9695

RICOH CL 7200, 7300

Absolute Black® toner for use in Ricoh CL 7200, 7300

10023

Absolute Cyan™ toner for use in Ricoh CL 7200, 7300

10024

Absolute Magenta™ toner for use in Ricoh CL 7200, 7300

10025

Absolute Yellow™ toner for use in Ricoh CL 7200, 7300

10026

Absolute Black® toner for use in Ricoh CL 7200, 7300

11426

Absolute Cyan™ toner for use in Ricoh CL 7200, 7300

11427

Absolute Magenta™ toner for use in Ricoh CL 7200, 7300

11428

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow™ toner for use in Ricoh CL 7200, 7300

11429

SAMSUNG®**SAMSUNG CLX 4195, 6260, SLC 2680, 2670, 2620, CLP 415 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

SuMMiT® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260

17870

Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260

17871

Smartchip® Black for use in Samsung CLP 415, CLX 4195

17906

Smartchip® Cyan for use in Samsung CLP 415, CLX 4195

17907

Smartchip® Magenta for use in Samsung CLP 415, CLX 4195

17908

Smartchip® Yellow for use in Samsung CLP 415, CLX 4195

17909

Absolute Black® toner for use in Samsung CLX 4195

17959

Absolute Cyan™ toner for use in Samsung CLX 4195

17960

Absolute Magenta™ toner for use in Samsung CLX 4195

17961

Absolute Yellow™ toner for use in Samsung CLX 4195

17962

PCR roller for use in Samsung CLX 4195, 6260

17963

Smartchip® Black for use in Samsung CLP 415, CLX 4195

18051

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Cyan for use in Samsung CLP 415, CLX 4195	18052
Smartchip® Magenta for use in Samsung CLP 415, CLX 4195	18053
Smartchip® Yellow for use in Samsung CLP 415, CLX 4195	18054
Smartchip® Black for use in Samsung CLP 415, CLX 4195	18097
Smartchip® Cyan for use in Samsung CLP 415, CLX 4195	18098
Smartchip® Magenta for use in Samsung CLP 415, CLX 4195	18099
Smartchip® Yellow for use in Samsung CLP 415, CLX 4195	18100
Shipping lock and drum cover set for use in Samsung CLX 4195	18217
Doctor blade for use in Samsung CLP 415, 680, CLX 4195, 6260, SLC 2680, 2670, 2620 (CLT504/505/506)	18488
Absolute Black® toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW	18803
Absolute Cyan™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW	18804
Absolute Magenta™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860 FW	18805
Absolute Yellow™ toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620, 1860	18806
X-Generation® Black toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620,	19036
X-Generation® Cyan toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620	19037
X-Generation® Magenta toner for use in Samsung CLP 680, 415, CLX 6260, 4195	19038
X-Generation® Yellow toner for use in Samsung CLP 680, 415, CLX 6260, 4195	19039

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Black toner for use in Samsung CLP 415, CLX 4195	19045
X-Generation® Cyan toner for use in Samsung CLP 415, CLX 4195	19046
X-Generation® Magenta toner for use in Samsung CLP 415, CLX 4195	19047
X-Generation® Yellow toner for use in Samsung CLP 415, CLX 4195	19048
Clear adhesive seal for use in Samsung CLP 415, CLX 4195, SL-C 1860	19246
Wiper blade for use in Samsung CLP 680, 415, CLX 4195, 6260, SLC 2680, 2670, 2620	20428

SAMSUNG CLP 365, CLX 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Seal toner hopper fill plug for use in Samsung CLP 365, 300, CLX 3305, 3160 FN, SL-C 410, 430, 432, 433, 460, 462, 480, 482, 483 (32mm)	11625
Smartchip® Black for use in Samsung CLP 365, CLX 3305	17964
Smartchip® Cyan for use in Samsung CLP 365, CLX 3305	17965
Smartchip® Magenta for use in Samsung CLP 365, CLX 3305	17966
Smartchip® Yellow for use in Samsung CLP 365, CLX 3305	17967
Absolute Black® toner for use in Samsung CLP 365, CLX 3305	17968
Absolute Cyan™ toner for use in Samsung CLP 365, CLX 3305	17969
Absolute Magenta™ toner for use in Samsung CLP 365, CLX 3305	17970
Absolute Yellow™ toner for use in Samsung CLP 365, CLX 3305	17971

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Black for use in Samsung CLP 365, CLX 3305

18047

Smartchip® Cyan for use in Samsung CLP 365, CLX 3305

18048

Smartchip® Magenta for use in Samsung CLP 365, CLX 3305

18049

Smartchip® Yellow for use in Samsung CLP 365, CLX 3305

18050

Absolute Black® toner for use in Samsung CLP 365, CLX 3305

18061

Absolute Cyan® toner for use in Samsung CLP 365, CLX 3305

18062

Absolute Magenta® toner for use in Samsung CLP 365, CLX 3305

18063

Absolute Yellow® toner for use in Samsung CLP 365, CLX 3305

18064

Smartchip® Black for use in Samsung CLP 365, CLX 3305

18093

Smartchip® Cyan for use in Samsung CLP 365, CLX 3305

18094

Smartchip® Magenta for use in Samsung CLP 365, CLX 3305

18095

Smartchip® Yellow for use in Samsung CLP 365, CLX 3305

18096

Developer roller cover for use in Samsung CLP 365, CLX 3305

18218

Clear adhesive seal for use in Samsung CLP 365, CLX 3305

18344

Developer roller for use in Samsung CLP 360, 365, CLX 3305

18433

Smartchip™ drum fuse for use in Samsung CLP 365, 360, 325, 320, 315, 310, Xpress C410, CLX 3305, 3185, 3175, 3170

19088

Supply roller for use in Samsung CLP 365, CLX 3305

19721

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ drum fuse with holder for use in Samsung CLP 365, 360, 325, 320, 315, 310, Xpress C410, CLX 3305, 3185, 3175, 3170

19863

SAMSUNG CLX 3160 FN, CLP 300

Absolute Black® toner for use in Samsung CLX 3160 FN

10167

Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN

10168

Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN

10169

Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN

10170

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

10907

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

10908

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

10909

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

10910

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

11571

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

11572

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

11573

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

11574

Seal toner hopper fill plug for use in Samsung CLP 300, CLX 3160 FN

11625

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

11646

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

11647

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

11648

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

11649

Absolute Black® toner for use in Samsung CLX 3160 FN

11803

Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN

11804

Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN

11805

Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN

11806

PCR roller for use in Samsung CLP 300, CLX 3160 FN

12329

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

13492

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

13493

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

16149

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

16150

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

16151

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

16152

Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN

16153

Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN

16154

Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN

16155

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN

16156

SAMSUNG CLP 610, 660, CLX 6200, 6210, 6240

Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12473

Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12499

Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12500

Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12501

Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12502

Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12503

Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12504

Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12505

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12506

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12507

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12508

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12509

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12510

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

12511

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	12512
ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	12513
Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13099
Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13100
Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13101
Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13102
ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13813
ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13814
ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13815
ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13816
ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13817
ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13818
ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13819
ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	13820
PCR roller for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	14214
Uni Drum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250	14462
SuMMiT™ OPC drum with gears for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	15289

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16390

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16391

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16393

ASiC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16394

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16395

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16396

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16397

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16398

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16399

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16400

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16402

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16403

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16404

ASiC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16405

ASiC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16406

ASiC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240

16407

Supply roller for use in Samsung CLP 610, 660

16962

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG CLX 6220, 6250, CLP 612, 620, 670**

Uni Drum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250	14462
Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	15583
Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	15584
Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	15585
Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	15586
Smartchip™ Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	15587
ASiC Encrypto Smartchip® Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16424
ASiC Encrypto Smartchip® Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16425
ASiC Encrypto Smartchip® Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16426
ASiC Encrypto Smartchip® Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16427
ASiC Encrypto Smartchip® Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16428
ASiC Encrypto Smartchip® Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16429
ASiC Encrypto Smartchip® Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16430
ASiC Encrypto Smartchip® Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16431
Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16440

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16442
Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16443
Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	16444
Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	19740
Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	19741
Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	19742
Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250	19743

SAMSUNG CLP 680, 415, CLX 6260, SCL 2680, 2670, 2620 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

SuMMiT® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260	17870
Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260	17871
Smartchip® Black for use in Samsung CLP 680, CLX 6260	17914
Smartchip® Cyan for use in Samsung CLP 680, CLX 6260	17915
Smartchip® Magenta for use in Samsung CLP 680, CLX 6260	17916
Smartchip® Yellow for use in Samsung CLP 680, CLX 6260	17917
PCR roller for use in Samsung CLP 415, 680, CLX 4195, 6260	17963
Smartchip® Black for use in Samsung CLP 680, CLX 6260	18055

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Cyan for use in Samsung CLP 680, CLX 6260	18056
Smartchip® Magenta for use in Samsung CLP 680, CLX 6260	18057
Smartchip® Yellow for use in Samsung CLP 680, CLX 6260	18058
Smartchip® Black for use in Samsung CLP 680, CLX 6260	18101
Smartchip® Cyan for use in Samsung CLP 680, CLX 6260	18102
Smartchip® Magenta for use in Samsung CLP 680, CLX 6260	18103
Smartchip® Yellow for use in Samsung CLP 680, CLX 6260	18104
Drum cover for use in Samsung CLP 680, CLX 6260	18219
X-Generation® Black toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620	19036
X-Generation® Cyan toner for use in Samsung CLP 680, 415, CLX 6260, 4195, SLC 2680, 2670, 2620	19037
X-Generation® Magenta toner for use in Samsung CLP 680, 415, CLX 6260, 4195	19038
X-Generation® Yellow toner for use in Samsung CLP 680, 415, CLX 6260, 4195	19039
X-Generation® Black toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620	19041
X-Generation® Cyan toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620	19042
X-Generation® Magenta toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620	19043
X-Generation® Yellow toner for use in Samsung CLP 680, CLX 6260, SLC 2680, 2670, 2620	19044
Wiper blade for use in Samsung CLP 680, 415, CLX 4195, 6260, SLC 2680, 2670, 2620	20428

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG CLX 8380 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ Black for use in Samsung CLX 8380	15946
Smartchip™ Cyan for use in Samsung CLX 8380	15947
Smartchip™ Magenta for use in Samsung CLX 8380	15948
Smartchip™ Yellow for use in Samsung CLX 8380	15949
Absolute Black® toner for use in Samsung CLX 8380	17926
Absolute Cyan™ toner for use in Samsung CLX 8380	17927
Absolute Magenta™ toner for use in Samsung CLX 8380	17928
Absolute Yellow™ toner for use in Samsung CLX 8380	17929
Smartchip™ Black for use in Samsung CLX 8380	18153
Smartchip™ Cyan for use in Samsung CLX 8380	18154
Smartchip™ Magenta for use in Samsung CLX 8380	18155
Smartchip™ Yellow for use in Samsung CLX 8380	18156
Smartchip™ Black for use in Samsung CLX 8380	18157
Smartchip™ Cyan for use in Samsung CLX 8380	18158
Smartchip™ Magenta for use in Samsung CLX 8380	18159

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow for use in Samsung CLX 8380	18160
SuMMiT® drum gearless for use in Samsung CLX 8380	18997
Absolute Black® toner for use in Samsung CLX 8385, 8380	19121
Absolute Cyan™ toner for use in Samsung CLX 8385, 8380	19122
Absolute Magenta™ toner for use in Samsung CLX 8385, 8380,	19123
Absolute Yellow™ toner for use in Samsung CLX 8385, 8380	19124

SAMSUNG CLX 8385 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black for use in Samsung CLX 8385	17451
Smartchip™ Cyan for use in Samsung CLX 8385	17452
Smartchip™ Magenta for use in Samsung CLX 8385	17453
Smartchip™ Yellow for use in Samsung CLX 8385	17454
Smartchip™ Black for use in Samsung CLX 8385	17839
Smartchip™ Cyan for use in Samsung CLX 8385	17840
Smartchip™ Magenta for use in Samsung CLX 8385	17841
Smartchip™ Yellow for use in Samsung CLX 8385	17842
Absolute Black® toner for use in Samsung CLX 8385, 8380	17926

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan™ toner for use in Samsung CLX 8385, 8380	17927
Absolute Magenta™ toner for use in Samsung CLX 8385, 8380	17928
Absolute Yellow™ toner for use in Samsung CLX 8385, 8380	17929
Absolute Black® toner for use in Samsung CLX 8385, 8380	19121
Absolute Cyan™ toner for use in Samsung CLX 8385, 8380	19122
Absolute Magenta™ toner for use in Samsung CLX 8385, 8380,	19123
Absolute Yellow™ toner for use in Samsung CLX 8385, 8380	19124

SAMSUNG CLX 9250, 9258, 9350, 9358 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358	18162
Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358	18166
Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358	18170
Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358	18221
Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358	18222
Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358	18223
Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358	18224
Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358	18225

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358	18226
Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358	18227
Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358	18228
Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358	18229
Absolute Black® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250	21115
Absolute Cyan® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250	21116
Absolute Magenta® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250	21117
Absolute Yellow® toner for use in Samsung CLX 9358, 9350, 9258, 9252, 9250,	21118

SAMSUNG SCX 6345

Absolute Black® toner for use in Samsung SCX 6345	11415
Absolute Black® toner for use in Samsung SCX 6345	11416
Smartchip™ toner cartridge for use in Samsung SCX 6345	11417
Doctor blade for use in Samsung SCX 6345	11418
Wiper blade for use in Samsung SCX 6345	11420
Mag Roller Sleeve for use in Samsung SCX 6345	11473
PCR roller for use in Samsung SCX 6345	11475

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® developer carrier for drum unit for use in Samsung SCX 6345

11645

Smartchip™ drum unit for use in Samsung SCX 6345

13478

Clear adhesive seal for use in Samsung SCX 6345

14584

Uni Drum® with gears for use in Samsung SCX 6555, 6545, 6345

17527

SAMSUNG SCX 6555, 6545 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Wiper blade for use in Samsung SCX 6555, 6455, 6345

11420

TEXT grade toner for use in Samsung SCX 6555, 6545

14093

Smartchip™ toner with connector for use in Samsung SCX 6555, 6545

14094

TEXT grade toner for use in Samsung SCX 6555, 6545

17317

Absolute Black® toner for use in Samsung SCX 6555, 6545

17525

Uni Drum® OPC with gears for use in Samsung SCX 6555, 6545

17527

Absolute Black® toner for use in Samsung SCX 6555, 6545

17536

Smartchip™ drum unit for use in Samsung SCX 6555, 6545

17537

Absolute Black® developer for use in Samsung SCX 6555, 6545

17571

OEM style cable for use in Samsung SCX 6555

17648

PCR roller for use in Samsung SCX 6555, 6545

18615

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Black toner for use in Samsung SCX 6555, 6545	19750
X-Generation® Black toner for use in Samsung SCX 6555, 6545	19752
Upper fuser roller for use in Xerox WorkCentre 4250, 4260, Samsung SCX 6555, 6545 (022N02372, JC66-01871A)	20410
Fuser cleaning roller for use in Xerox WorkCentre 4250, 4260, Samsung SCX 6555, 6545 (006N01329, JC66-01870A)	20412
SuMMiT® drum with gears for use in Samsung SCX 6555, 6545	20667

SAMSUNG SCX 3405, SF 760

Drum cover for use in Samsung ML 2165, 2160, 1860, 1665, 1660, SL-M 2070, 2022, 2020, SCX 3405, 3205, 3200	15957
Smartchip® for use in Samsung ML 2160, 2165, SCX 3405, SF 760	17069
Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760	17071
Uni Drum® with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17473
SuMMiT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17474
Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17475
Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17476
Wiper blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17477
Doctor blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160 1165	17478
PCR roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17479

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165

17480

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760

18040

SuMMiT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165

18112

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, SF 760

18206

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/XAA)

18518

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/ELS)

18519

Smartchip® for use in Samsung ML 2165, 2160, SCX 3405, 3400, SF 760 (MLT-D101S/XIL)

18949

SAMSUNG SCX 4300, 4200, 4116, 4100

Absolute Black® toner for Samsung SCX 4300

13323

PCR roller for use in Samsung SCX 4300

13325

Doctor blade for use in Samsung SCX 4300

13326

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

Absolute Black® toner for use in Samsung SCX 4300

15343

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16412

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16413

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 4500**

Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500	11939
ASiC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500	11940
Fill plug for use in Samsung ML 1630, 1631, SCX 4500	12189
Uni Drum™ with gears for use in Samsung ML 1630, 1631, SCX 4500	12203
X-Generation® Doctor blade for use in Samsung ML 1630, 1631, SCX 4500	12351
Wiper blade for use in Samsung ML 1630, 1631, SCX 4500	12352
Developer roller for use in Samsung ML 1630, 1631, SCX 4500	12733
PCR roller for use in Samsung ML 1630, 1631, SCX 4500	12734
Supply roller for use in Samsung ML 1630, 1631, SCX 4500	12735
Developer Roller End Felt for use in Samsung ML 1630, 1631, SCX 4500	13009
Toner Adder Roller End Foam for use in Samsung ML 1630, 1631, SCX 4500	13010
Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500	13868
ASiC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500	16364
X-Generation® Wiper blade for use in Samsung ML 1630, 1631, SCX 4500	17081
SuMMiT® drum with gears for use in Samsung ML 1630, 1631, SCX 4500	18121

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 4600, 4623, SF 650**

Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650	14073
Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	14074
Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	14501
Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650	15119
X-Generation® Wiper blade for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623, SF 650	15124
Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650	15127
ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F	16414
Uni Drum™ with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623	16415
SuMMiT™ drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623	16416
ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2580, SCX 4600, 4610, 4623, 650F(MLT-D1052S)	16417
ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F	16418
ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2580, SCX 4600, 4610, 4623, 650F	16419
Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650	17270
SuMMiT™ drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623	18108
PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	18759
ASiC Encrypto Smartchip® for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F (MLT-D105L/SEE)	20145

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 4824, 4825, 4826, 4828**

Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828 12106

Absolute Black® toner for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 12107

Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828 12109

Developer roller sealing blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 13007

Recovery blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828 13008

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(US & AUS) 13858

Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650 14073

Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 14074

Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 14501

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209L)(US & AUS) 15970

Smartchip cover for use in Samsung® ML 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, (MLT-D209) 16453

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D2092L)(Europe) 16731

ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(EU) 16732

X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, (MLT-D209) 17078

PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650 18759

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 4833, 4835, 5639, 5737, 5739, ML 3310, 3312, 3710 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

X-Generation® toner for use in Samsung ML 4550, 4050, 3710, 3712, 3750, 3312, 3312, SCX 4833, 4835, 5639, 5737, 5739	16075
ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5637 (MLT-D205S)(USA)	16331
ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 5637 (MLT-D205L)(USA)	16332
Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739	16333
Uni Drum™ with gears for use in Samsung ML 2950, 2955, 3310, 3312, 3712, 3750, SL-M 2870, 2820, 2670, 2620, SCX 4833, 5737 (MLT-D205)	16334
X-Generation® Wiper blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5737	16335
Wiper blade for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5737	16335
Doctor blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3820, 4020, 4070, 4072, SCX 4833, 4835, 5737	16336
Developer roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3325, 3820, 3825, 4020, 4025, 4030,4035, 4070, 4075, 4080, SCX 4833, 4835, 5737	16337
PCR roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3820, 4020, 4030, 4070, 4080, SCX 4833, 4835, 5737	16338
Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, SCX 4833, 4835, 5737	16773
Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739	16794
Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5639, 5737, 5739	16912
ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5637 (MLT-D205S)(EU)	16949
ASiC Encrypto Smartchip® for use in Samsung ML 3310, 3710, SCX 4833, 5737 (MLT-D205L)(EU)	16950

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Encrypto Smartchip® for use in Samsung ML 3312, 3710, SCX 4833, 5639, 5739 (MLT-D205S)(EXP)	16991
ASiC Encrypto Smartchip® for use in Samsung ML 3312, 3710, 3712, SCX 4833, 5639, 5739 (MLT-D205L)(EXP)	16992
SuMMiT® OPC drum w gears for use in Samsung ML 2950, 2955, 3310, 3312, 3712, 3750, SL-M 2870, 2820, 2670, 2620, SCX 4833, 5737 (MLT-D205)	17094
Shipping lock for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5737 (MLT D205)	17749
Clear Seal for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SL-M 3320, 3325, 3820,3825, 3870, 4070, 4075, SCX 4833, 4835, 5737	17881
Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739	18555
SuMMiT® drum with gears for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 5737 (MLT-D205)	18694
Developer Roller Sealing Blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, 3753, SL-M 3320, 3325, 3820, 3825, 3870, 4070, 4075, SCX 4833, 4835, 5737	20430

SAMSUNG SCX 4016, 4216, SF 560, 755

Wiper blade for use in Samsung SCX 4016, 4216, SF 560, 755	4948
Developer roller for use in Samsung SCX 4016, 4216, SF 560, 755	5292
PCR roller for use in Samsung SCX 4016, 4216, SF 560, 755	5293
Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560	9168
Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560, 755	9610
Smartchip™ fuse for use in Samsung SCX 4016, 4216, SF 560, 755	10203
SuMMiT™ drum w/gears for use in Samsung SCX 4016, 4216, SF 560, 755	12035

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ with gears for use in Samsung SCX 4016, 4216, SF 560, 755

15207

SAMSUNG SCX 4100, 4116

Absolute Black® toner for use in Samsung SCX 4100, 4116

9639

Absolute Black® toner for use in Samsung SCX 4100, 4116

9640

Wiper blade for use in Samsung SCX 4200,4100, 4116

10549

Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116

10550

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

SAMSUNG SCX 4200

Absolute Black® toner for use in Samsung SCX 4200

10545

Absolute Black® toner for use in Samsung SCX 4200

10546

Smartchip™ for use in Samsung SCX 4200

10548

Wiper blade for use in Samsung SCX 4200,4100, 4116

10549

Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116

10550

Top cover for use in Samsung SCX 4200

11465

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Samsung SCX 4200

16120

SAMSUNG SCX 4300

Absolute Black® toner for Samsung SCX 4300

13323

PCR roller for use in Samsung SCX 4300

13325

Doctor blade for use in Samsung SCX 4300

13326

Uni Drum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100

15203

Absolute Black® toner for use in Samsung SCX 4300

15343

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16412

ASiC Encrypto Smartchip® for use in Samsung SCX 4300

16413

SAMSUNG SCX 4521, 4321

Absolute Black® toner for use in Samsung SCX 4521, 4321

10438

Absolute Black® toner for use in Samsung SCX 4521, 4321

10439

Wiper blade for use in Samsung SCX 4725, 4521, 4321

10441

Developer roller for use in Samsung SCX 4521, 4321

10443

PCR roller for use in Samsung SCX 4521, 4321

10444

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Supply roller for use in Samsung SCX 4521, 4321

10445

Smartchip™ fuse for use in Samsung SCX 4521, 4321

10446

Uni Drum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321

16113

Doctor blade for use in Samsung SCX 4521, 4321

16818

SAMSUNG SCX 4720, 4520

Universal cover top for use in Samsung ML 2250, 2251, 2252, SCX 4720, 4520, Dell 1600

6298

Absolute Black® toner for use in Samsung SCX 4720, 4520

9528

Absolute Black® toner for use in Samsung SCX 4720, 4520

9529

Absolute Black® toner for use in Samsung SCX 4720, 4520

9530

Developer roller for use in Samsung SCX 4720, 4520

9533

PCR roller for use in Samsung SCX 4720, 4520

9534

Wiper blade for use in Samsung SCX 4720, 4520

9535

Doctor blade for use in Samsung SCX 4720, 4520

9536

Smartchip™ for use in Samsung SCX 4720, 4520

9537

SuMMiT™ drum w/gears for use in Samsung SCX 4720, 4520

12036

Smartchip™ for use in Samsung SCX 4720, 4520

12256

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Uni Drum™ with gears for use in Samsung SCX 4720, 4520

15196

Smartchip™ for use in Samsung SCX 4720, 4520

16122

Smartchip™ for use in Samsung SCX 4720, 4520

16125

SAMSUNG SCX 4725

Wiper blade for use in Samsung SCX 4725, 4521, 4321

10441

Developer roller for use in Samsung SCX 5530, 5330, 4725

10993

Absolute Black® toner for use in Samsung SCX 4725

11665

Absolute Black® toner for use in Samsung SCX 4725

11666

ASiC Smartchip® for use in Samsung SCX 4725

11667

PCR roller for use in Samsung SCX 4725

11672

SuMMiT™ drum w/gears for use in Samsung SCX 4725

12037

Smartchip™ for use in Samsung SCX 4725

12051

Conversion kit for Samsung ML 1640, 2240, SCX 4725

14425

Uni Drum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321

16113

ASiC Smartchip® for use in Samsung SCX 4725

16277

Doctor blade for use in Samsung SCX 4725

16817

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 5112, 5312, 5315**

Smartchip™ drum unit fuse for use in Samsung SCX 5112, 5312, 5315	5083
Developer roller for use in Samsung SCX 5112, 5312, 5315	5180
Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315	5472
Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315	8977
Wiper blade for use in Samsung SCX 5112, 5312, 5315	8978
Doctor blade for use in Samsung SCX 5112, 5312, 5315	8979
SuMMiT™ drum w/gears for use in Samsung SCX 5112, 5312, 5315	12038

SAMSUNG SCX 5530, 5330

Absolute Black® toner for use in Samsung SCX 5530, 5330	10960
Absolute Black® toner for use in Samsung SCX 5530, 5330	10961
ASiC Smartchip® for use in Samsung SCX 5530, 5330	10963
Developer roller for use in Samsung SCX 5530, 5330, 4725	10993
PCR roller for use in Samsung SCX 5530, 5330	10994

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Smartchip® for use in Samsung SCX 5530, 5330

11946

Absolute Black® toner for use in Samsung SCX 5530, 5330

11947

SuMMiT™ drum w/gears for use in Samsung SCX 5530, 5330

12039

Uni Drum™ with gears for use in Samsung SCX 5530, 5330

15774

ASiC Smartchip® for use in Samsung SCX 5530, 5330

16372

ASiC Smartchip® for use in Samsung SCX 5530, 5330

16375

X-Generation® Doctor blade for use in Samsung SCX 5530, 5330

18086

X-Generation® Wiper blade for use in Samsung SCX 5530, 5330

18120

SAMSUNG SCX 5935, 5835, 5635 MFP

Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP

13878

Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP

13880

SuMMiT™ drum with gears for use in Samsung SCX 5935, 5835, 5635 MFP

13885

Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP

14904

Smartchip™ for use in Samsung SCX 5935 MFP

15741

Wiper blade for use in Samsung SCX 5935, 5835, 5635

15870

Doctor blade for use in Samsung SCX 5935, 5835, 5635

18626

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® black toner for use in Samsung SCX 5935, 5835, 5635 MFP

19391

X-Generation® Black toner for use in Samsung SCX 5935, 5835, 5635 MFP

19393

Developer roller for use in Samsung SCX 5935, 5835, 5635

19404

PCR Roller for use in Samsung SCX 5935, 5835, 5635

19406

Uni Drum™ drum with gears for use in Samsung SCX 5935, 5835, 5635 MFP

20295

SAMSUNG SCX 6320, 6220, 6120, 6520

Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520

9556

Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520

9557

PCR roller for use in Samsung SCX 6320, 6220, 6120, 6520

9560

Smartchip™ drum unit fuse for use in Samsung SCX 6322, 6320, 6220, 6120, 6520

9866

Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520

9867

Doctor blade for use in Samsung SCX 6320, 6220, 6120, 6520

11553

SuMMiT™ drum with gears for use in Samsung SCX 6320, 6220, 6120, 6520

14937

Developer roller for use in Samsung SCX 6320, 6220, 6120, 6520

15746

Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520

16127

X-Generation® Wiper blade for use in Samsung SCX 6320, 6220, 6120, 6520

17973

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 7128, 7135, 7145**

Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145	5285
Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145	5287
Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145	5288
Ecographics toner for use in Samsung SCX 7128, 7135, 7145	5289
Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145	5924
Ecographics toner for use in Samsung SCX 7128, 7135, 7145	16933

SAMSUNG SCX 3200, 3205, ML 1860, 165, 1660

X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200	15906
X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	15908
Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	15950
PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	15951
Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	15957
Name plate for use in Samsung ML 1665, 1660, SCX 3205, 3200	15975
SuMMiT™ OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	16014

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	16105
X-Generation® Doctor blade for use in Samsung ML 1865, 1665, 1660, SCX 3205, 3200	16158
ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1860, 1865, SCX 3200, 3205	16432
ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1865, SCX 3200	16433
ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660,, 1675, 1865, SCX 3200, 3205	17246
SuMMiT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	17418
X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	17674
ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1865, SCX 3200 (MLT-D104S/SEE)(EXP)	20144

SAMSUNG SCX 4828, 4826, 4825, 4824

Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828	12106
Absolute Black® toner for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828	12107
Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828	12109
Developer roller sealing blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828	13007
Recovery blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828	13008
PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	13488
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	13858

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650	14073
Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	14074
Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	14501
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	15970
Smartchip cover for use in Samsung® ML 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828	16453
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	16731
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	16732
X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828	17078
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	17320
ASiC Encrypto Smartchip® for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824	17321
PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650	18759

SAMSUNG SCX 4728, 4729 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

ASiC Encrypto Smartchip® for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(US)	16790
X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729	16913
X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729	16914
ASiC Encrypto Smartchip® for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729	16986

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

ASiC Encrypto Smartchip® for use in Samsung ML 2955, 2951, 2955, SCX 4728, 4729

16987

ASiC Encrypto Smartchip® for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(EXP)

17280

Developer roller for use in Samsung ML 2950, 2955, SCX 4729, 4728

18889

PCR roller for use in Samsung ML 2950, 2955, 2820, 2620, SCX 4729, 4728

18897

SAMSUNG SCX 3205, 3200

X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200

15906

X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15908

Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15950

PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15951

Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

15957

SuMMiT™ OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

16014

X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

16105

ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1860, 1865, SCX 3200, 3205 (MLT-D1042S)(EU)

16432

ASiC Encrypto Smartchip® for use in Samsung ML 1665, 1661, 1660, 1675, 1865, SCX 3200, 3205 (MLT-D104S)(EXP)

17246

SuMMiT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200

17418

X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205

17674

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SAMSUNG SCX 7128, 7135, 7145**

Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145	5285
Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145	5287
Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145	5288
Ecographics toner for use in Samsung SCX 7128, 7135, 7145	5289
Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145	5924
Ecographics toner for use in Samsung SCX 7128, 7135, 7145	16933

SHARP®**SHARP AL 1000, 2021, 2031, 2041, 2051 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 55 lb	5620
X-Generation® Wiper blade for use in Sharp AL 1000, 2021, 2031, 2041, 2051	6015
Absolute Black® toner for use in Sharp AL 1000, 2021, 2030, 2031, 2041, 2051	6031
Absolute Black® developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051	6032
Seal shipping cover protector for use in Sharp AL 1000, 2021, 2031, 2041, 2051	6532

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer for use in Sharp AL 1000	6975
Absolute Black® toner for use in Sharp AL 1000, 2021, 2031, 2041, 2051	8128
SuMMiT™ drum with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051	12708
Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051	16098
Uni Drum™ with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051	16785
Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051	17296
Absolute Black® toner for use in Sharp AL 1000, 2020, 2030, 2030, 2040	18631
Upper Fuser roller for use in Sharp AL1000, 1020, 1200, 1220, 1240, 1641, 1651, AR153, 115, 156, 157, 168, 208 (NROLI-11140-FCZZ)	19474

SHARP AR 650, 800

Developer for use in Sharp AR 650, AR 800	14219
---	-------

SHARP AR 162, 162s, 163, 164

OPC drum cleaning wiper blade for use in Sharp AR 160, 161, 162, 163, 164, 200, 201, 206, 207, 205, 5015, 5316, 5516, 5520, MX-M 200, 232, AL 1600, 1620, 1640 (SH200BDC)	5974
Absolute Black® developer for use in Sharp AR 162, 163, 164, 201, 202, 206, 207	8281
Smartchip™ w/housing for use in Sharp AR 162,162s, 163, 164, 201, 202, 207 T	11384
Smartchip™ w/ housing for use in Sharp AR 162, 162s, 163, 164	13832

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMiT® drum with gears for use in Sharp AR 160, 161, 162, 163, 164, 201, 206, 5015, 5316, M 207, 205, 165, 160 (AR-200DR, 201-DR)

17521

Absolute Black® toner for use in Sharp AR 162, 163, 164, 201, 202, 206, 207

20666

SHARP AR 450, 350, 280, AR M 280, 450, P 350, 450, DX B 450

Absolute Black® toner for use in Sharp AR 450, 350, 280

7090

Uni Drum™ OPC with gears for use in Sharp AR-M 280, 450, 350 NT

7436

Absolute Black® toner for use in Sharp AR 450, 350, 280

8817

Absolute Black® developer carrier for use in Sharp AR 450, 350, 280

10954

Smartchip™ for use in Sharp AR 350, 450 T (Europe)

13919

Smartchip™ for use in Sharp AR 350, 450 NT (US, Canada, Mexico)

13949

Absolute Black® toner for use in Sharp DX B 450 P

14356

Smartchip™ for use in Sharp DX B 450 P (DX-B45DTH)

14357

Uni Drum™ with gears for use in Sharp DX B 450 P

14358

SuMMiT® drum with gears for use in Sharp AR 337, 336, 335, 287, 285, 280, 250, M 450, 350, P 450, 350 (AR-451DR)

19290

Upper Fuser Roller for use in Sharp AR M 350, 450 (NROLT-1313-FCZZ)

19456

SHARP AR 455 MD

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Sharp AR 455 T (EU)	13920
Smartchip™ for use in Sharp AR 455 NT, (US, Canada, Mexico)	13950
Absolute Black® toner for use in Sharp AR 455 NT/T	14209
Absolute Black® developer carrier for use in Sharp AR 455 MD	14211
Uni Drum™ OPC for use in Sharp AR 455 DR	14212
Absolute Black® developer for use in Sharp AR 455 MD	14550

SHARP AR 500, 501, 505, 507

Absolute Black® toner for use in Sharp AR 500, 501, 505, 507	9093
--	------

SHARP AR M 550, 620, 700

Absolute Black® developer for use in Sharp AR 270, 310 ND	8820
Absolute Black® toner for use in Sharp AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317	9094
Absolute Black® toner for use in Sharp AR 270 NT	10194
Uni Drum™ with gears for use in Sharp AR 270 ND	10296
Absolute Black® toner for use in Sharp AR M 550, 620, 700	15873
Wiper Blade for use in Sharp AR M 700 620, 550, MX M 753, 700, 623, 620, 550 (AR-620BL, CCLEZ0173FC34)	19189

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Sharp AR 270, 310 NT, AR M 208, 236, 237, 257, 276, 277, 317

19473

Uni Drum® with gears for use in Sharp AR M 700, 620, 550, MX M 700, 620, 550

20937

SHARP AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317

Absolute Black® developer for use in Sharp AR 270, 310 ND

8820

Absolute Black® toner for use in Sharp AR 270 NT,

10194

Absolute Black® toner for use in Sharp AR 270, 310 NT, AR M 208, 236, 237, 257, 276, 277, 317

19473

SHARP AR AR-5618D, AR-5623D, MX-M182, MX-M182D, MX-M202D, MX-M232D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ for use in Sharp AR-5618D, AR-5623D, MX-M182, MX-M182D, MX-M202D, MX-M232D

18259

Absolute Black® toner for use in Sharp AR 5623, 5618, MX-M 182, 202, 232(MX235NT)

19032

Lower Fuser pressure roller for use in Sharp AR5516, 5520, ARM257, 317, MX-M160, M200D, M260, M264N, M310(NROLR0156QSAZ)

19648

Absolute Black® toner for use in Sharp AR 5623, 5618, MX-M 182, 202, 232

19877

SHARP AR020ST, AR5516, 5520

Smartchip™ for use in Sharp AR020ST, AR5516, 5520 (Asia Pacific)

18262

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SHARP DX B 350 P (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

X-Generation® Black toner for use in Sharp DX B 350 P	14348
Smartchip™ for use in Sharp DX B 350 P	14349
Uni Drum™ with gears for use in Sharp DX B 350 P	14350
PCR (recosted) roller for use in Sharp DX B 350 P	14352
Clear Seal™ adhesive for use in Sharp DX B 350 P	14353
Doctor blade for use in Sharp DX B 350 P	14354
Absolute Black® toner for use in Sharp DX B 350 P	17809

SHARP FO DC 550, FO 55 ND, 4400, 4450,

Absolute Black® toner for use in Sharp FO 55 ND, 4400, 4450, DC 550	10462
Smartchip™ for use in Sharp FO 55 ND, 4400, 4450, DC 550	10463
SuMMiT™ drum with gear for use in Sharp FO 55 ND, 4400, 4450, DC 550	16591
Absolute Black® developer for use in Sharp FO 55 ND, 4400, 4450, DC 550	17387
X-Generation® wiper blade for use in Sharp FO 55 ND, 4400, 4450, DC 550	17388

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SHARP FO 2081 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Uni Drum™ F with gears for use in Sharp FO 2081	16785
Smartchip™ for use in Sharp FO-2081	17449
Absolute Black® toner for use in Sharp FO-2081	17481
Absolute Black® developer for use in Sharp FO-2081 (FO56ND	17760
SuMMiT™ drum with gears for use in Sharp FO 2081	17838

SHARP MX 2300N, 2700N, 3500N, 3501N, 4501 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13757
Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13758
Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13759
Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13760
Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13761
Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13762
Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13763
Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501	13764

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****SHARP MX-M 200, 160, 181, 211, MX-M 200 D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

OPC drum cleaning wiper blade for use in Sharp AR 160, 161, 162, 163, 164, 200, 201, 206, 207, 205, 5015, 5316, 5516, 5520, MX-M 200, 232, AL 1600, 1620, 1640 (SH200BDC)	5974
Smartchip® toner for use in Sharp MX-M 200 D	17583
Absolute Black® toner for use in Sharp MX-M 200 D	17668
Absolute Black® developer for use in Sharp MX M 200, 160, 181, 211 (MX-206NT)	17700
Uni Drum® with gears for use in Sharp MX M 503, 453, 363, 283 (MX-500NR)	19482
Lower Fuser pressure roller for use in Sharp AR5516, 5520, ARM257, 317, MX-M160, M200D, M260, M264N, M310(NROLR0156QSAZ)	19648
Smartchip™ toner for use in Sharp MX M 200, 160 (MX-206GT)(EU)	20511
Smartchip® toner for use in Sharp MX-B 201, 200 D (MX-20NT)(US)	20990
Smartchip® toner for use in Sharp MX-B 201, 200 D (MX-20GT)(EU)	20991

SHARP SF 1014

Toner refill bottle for use in Sharp SF 1014	11820
--	-------

SHARP SF 7300, 7320, 7350, 7370

Refill bottles for use in Sharp SF 7300, 7320, 7350, 7370	11839
---	-------

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****TOSHIBA®****TOSHIBA E STUDIO 205 CP**

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 163, 165, 166, 167, 181, 182, 195, 200, 203, 205, 212, 223, 225, 230, 232, 233, 237, 242, 245, 250, 280, 282, 283 (OD-1600) 8543

Absolute Black® toner for use in Toshiba e Studio 163, 165, 203, 205 (T-1640) 11513

Absolute Black® developer for use in Toshiba e Studio 163, 165, 166, 181, 182, 195, 200, 202, 203, 205, 206, 207, 121, 223, 225, 230, 232, 233, 242, 245, 280, 282, 283, (D2320) 11514

Absolute Black® toner for use in Toshiba e Studio 205 CP 11691

Absolute Cyan™ toner for use in Toshiba e Studio 205 CP 11692

Absolute Magenta™ toner for use in Toshiba e Studio 205 CP 11693

Absolute Yellow™ toner for use in Toshiba e Studio 205 CP 11694

Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205 (T-1640) 11701

Toshiba e Studio CP 220, 205 (see Lexmark C 520, 522, 530, 532, 534) 14066

Uni Drum® with gears for use in Toshiba e-STUDIO 205, 206, 255, 256, 305, 306, 355, 356, 455, 456, 506 (OD4530) 19510

Upper Fuser Roller for use in Toshiba E-Studio 506, 456, 455, 356, 355, 306, 305, 255, 206, 205 (6LH58424000) 19622

TOSHIBA E STUDIO 12, 15, 120, 150

Absolute Black® toner for use in Toshiba e Studio 12, 15, 120, 150 11509

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Developer for use in Toshiba e-Studio 12, 15, 120, 150

11510

X-Generation® Wiper blade for use in Toshiba e Studio 12, 15, 120, 150

11512

TOSHIBA E STUDIO 16, 20, 25, 250

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 200, 230, 250, 280

8543

Absolute Black® toner for use in Toshiba e Studio 16, 20, 25, 250

8822

TOSHIBA E STUDIO 161, T 1620

Absolute Black® toner for use in Toshiba e Studio 161, T 1620

11567

Absolute Black® compatible developer for use in Toshiba e Studio 161, T 1620

11568

Wiper blade for use in Toshiba e Studio 161, T 1620

11570

SuMMiT™ drum with gears for use in Toshiba e Studio 161, T 1620

16382

TOSHIBA E STUDIO 163, 165, 203, 205, T 1640

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 163, 165, 166, 167, 181, 182, 195, 200, 203, 205, 212, 223, 225, 230, 232, 233, 237, 242, 245, 250, 280, 282, 283 (OD-1600)

8543

Absolute Black® toner for use in Toshiba e Studio 163, 165, 203, 205, T 1640

11513

Absolute Black® drum unit carrier developer for use in Toshiba e Studio 163, 165, 203, 205

11514

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205, T 1640

11701

TOSHIBA E STUDIO 168, 208, 258

Uni Drum™ with gears for use in Toshiba e Studio 168, 208, 258

12673

Wiper blade for use in Toshiba e-studio 168, 208, 258

12669

TOSHIBA E STUDIO 20 P, 25 P

Uni Drum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 200, 230, 250, 280

8543

Toshiba e Studio 20 P, 25 P matched system

10579

TOSHIBA E STUDIO 30 P, 40 P

Toshiba e Studio 30 P, 40 P matched system

10578

TOSHIBA E STUDIO 320 P

Toshiba e Studio 320 P matched system

10577

Toshiba e-Studio 270 P, 300 P (use 13435 Lexamrk E/X 240, 340 Super Universal™ chip)

11699

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****TOSHIBA E STUDIO CP 220, 205**

Toshiba e Studio CP 220, 205 matched system

14066

TOSHIBA E STUDIO 520, 550, 600, 650, 720, 810, 850

Uni Drum™ F with gears for use in Toshiba e Studio 520, 550, 600, 650, 720, 810, 850

5161

TOSHIBA E STUDIO 350, 450

Wiper blade for use in Toshiba e Studio 28, 35, 45, 350, 450

12583

Upper Fuser Roller for use in Toshiba E-Studio 350, 450

15085

Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458

15086

Absolute Black toner for use in Toshiba e-Studio 350, 352, 353, 450, 452, 453 (T3520)

18503

Paper Pickup Roller kit for use in Toshiba E-Studio 450, 350, 280, 230

19354

Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)

19356

Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000)

19359

SuMMiT® OPC drum with gears for use in Toshiba e Studio 28, 35, 45, 350, 353, 450, 452, 453 (OD-3500)

19511

TOSHIBA E STUDIO 28, 35, 45, T 3500

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Toshiba e Studio 28, 35, 45, T 3500	8823
Uni Drum™ F with gears for use in Toshiba e Studio 28, 35, 45, 350, 450	8991
Wiper blade for use in Toshiba e Studio 28, 35, 45, 350, 450	12583
Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458 (44202983000)	15086
Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)	19356
Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000)	19359
SuMMiT® OPC drum with gears for use in Toshiba e Studio 28, 35, 45, 350, 353, 450, 452, 453 (OD-3500)	19511

TOSHIBA E STUDIO 358,458, DP2800,3500,4500

Paper Feed Tire kit for use in Toshiba E-Studio 358,458, DP2800,3500,4500	15083
Upper Fuser Roller for use in Toshiba E-Studio 358,458, DP2800,3500,4500 (44299019000)	15084
Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458 (44202983000)	15086
Wiper blade for use in Toshiba E-Studio 458, 450, 358, 350 (6LA27554000/44299018000)	19356
Lower Picker Finger for use in Toshiba E-Studio 458, 450, 358, 350 (44203114000),	19359

TOSHIBA E STUDIO 2500C, 3500C, 3510C

Uni Drum® with gears for use in Toshiba e Studio 4520C, 3530C, 3520C, 3510C, 2830C, 2820C, 2330C, 2020C	19611
---	-------

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****TOSHIBA E STUDIO 500 P**

Smartchip™ for use in Toshiba e-Studio 500 P

11154

TOSHIBA E STUDIO 250 CP

Smartchip for toner cartridge for use in Toshiba e Studio 250 CP

6713

TOSHIBA E STUDIO 270 P, 300 P

Toshiba e-Studio 270 P, 300 P Superchip Universal™

11699

TOSHIBA E STUDIO 170 F

Absolute Black® toner for use in Toshiba e Studio 170 F

11817

Smartchip™ for use in Toshiba e Studio 170 F

12050

SuMMiT™ drum with gears for use in Toshiba e Studio 170 F

16594

TOSHIBA E STUDIO 190 P

Toshiba e Studio 190 P

5659

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****TOSHIBA BD 1340, 1350, 1370**

Wiper blade for use in Toshiba BD 1340, 1350, 1370

12581

TOSHIBA T 2060, 2860, 2870

Uni Drum™ F with gears for use in Toshiba T 2060, 2860, 2870

9004

Wiper blade for use in Toshiba T 2060, 2860, 2870

12582

Upper fuser roller for use in Toshiba 3560, 2860, 2060, DP 3580, 2570, 2460 (4409890600)

19785

XEROX®**XEROX PHASER 7500**

Smartchip™ Black for use in Xerox Phaser 7500

15958

Smartchip™ Cyan for use in Xerox Phaser 7500

15959

Smartchip™ Magenta for use in Xerox Phaser 7500

15960

Smartchip™ Yellow for use in Xerox Phaser 7500

15961

Smartchip™ CMYK drum unit for use in Xerox Phaser 7500

15962

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Black for use in Xerox Phaser 7500	16680
Smartchip™ Cyan for use in Xerox Phaser 7500	16681
Smartchip™ Magenta for use in Xerox Phaser 7500	16690
Smartchip™ Yellow for use in Xerox Phaser 7500	16691
X-Generation® Glossy Black toner for use in Xerox Phaser 7500	17493
X-Generation® Glossy Cyan toner for use in Xerox Phaser 7500	17494
X-Generation® Glossy Magenta toner for use in Xerox Phaser 7500	17495
X-Generation® Glossy Yellow toner for use in Xerox Phaser 7500	17496
X-Generation® drum with gears and insert for use in Xerox Phaser 7500	17569
SuMMiT® drum with gears and insert for use in Xerox Phaser 7500	17647
Wiper blade for use in Xerox Phaser 7500	19125

XEROX PHASER 6121 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black for use in Xerox Phaser 6121 MFP	16189
Smartchip™ Cyan for use in Xerox Phaser 6121 MFP	16190
Smartchip™ Magenta for use in Xerox Phaser 6121 MFP	16191
Smartchip™ Yellow for use in Xerox Phaser 6121 MFP	16192

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Xerox Phaser 6121 MFP

17877

Absolute Cyan™ toner for use in Xerox Phaser 6121 MFP

17878

Absolute Magenta™ toner for use in Xerox Phaser 6121 MFP

17879

Absolute Yellow™ toner for use in Xerox Phaser 6121 MFP

17880

Developer roller cover for use in Xerox Phaser 6121 MFP

18289

XEROX PHASER 6500, WORKCENTRE 6505, 6500

Smartchip™ Black for use in Xerox Phaser 6500, WC 6505

16546

Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505

16547

Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505

16548

Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505

16549

X-Generation® Black toner for use in Xerox Phaser 6500, WC 6505

16635

X-Generation® Cyan toner for use in Xerox Phaser 6500, WC 6505

16636

X-Generation® Magenta toner for use in Xerox Phaser 6500, WC 6505

16637

X-Generation® Yellow toner for use in Xerox Phaser 6500, WC 6505

16638

Smartchip™ Black for use in Xerox Phaser 6500, WC 6505

17349

Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505

17350

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505

17352

Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505

17353

X-Generation® Black toner for use in Xerox Phaser 6500, WC 6505

18775

X-Generation® Cyan toner for use in Xerox Phaser 6500, WC 6505

18776

X-Generation® Magenta toner for use in Xerox Phaser 6500, WC 6505

18777

X-Generation® Yellow toner for use in Xerox Phaser 6500, WC 6505

18778

XEROX PHASER 7400

Absolute Yellow™ toner for use in Xerox Phaser 7400

9439

Uni Drum™ with gears for use in Xerox Phaser 7400

9599

Smartchip™ Black for use in Xerox Phaser 7400

10840

Smartchip™ Cyan for use in Xerox Phaser 7400

10841

Smartchip™ Magenta for use in Xerox Phaser 7400

10842

Smartchip™ Yellow for use in Xerox Phaser 7400

10843

Smartchip™ drum unit fuse for use in Xerox Phaser 7400

10848

Absolute Yellow glossy toner™ for use in Xerox Phaser 7400

13517

Absolute Black® Glossy toner for use in Xerox Phaser 7400

14787

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Cyan glossy toner® for use in Xerox Phaser 7400	14788
Absolute Magenta glossy toner® for use in Xerox Phaser 7400	14789
Absolute Yellow glossy toner® for use in Xerox Phaser 7400	14790
X-Generation® Black glossy toner for use in Xerox Phaser 7400	20277
X-Generation® Cyan glossy toner for use in Xerox Phaser 7400	20278
X-Generation® Magenta glossy toner for use in Xerox Phaser 7400	20279
X-Generation® Yellow glossy toner for use in Xerox Phaser 7400	20280
X-Generation® Black glossy toner for use in Xerox Phaser 7400	20281
X-Generation® Cyan glossy toner for use in Xerox Phaser 7400	20282
X-Generation® Magenta glossy toner for use in Xerox Phaser 7400	20283
X-Generation® Yellow glossy toner for use in Xerox Phaser 7400	20284

XEROX PHASER 7760

Absolute Cyan™ toner for use in Xerox Phaser 7760	11188
Absolute Magenta™ toner for use in Xerox Phaser 7760	11189
Absolute Yellow™ toner for use in Xerox Phaser 7760	11190
Smartchip™ Black toner for use in Xerox Phaser 7760	11271

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Cyan toner for use in Xerox Phaser 7760	11272
Smartchip™ Magenta toner for use in Xerox Phaser 7760	11273
Smartchip™ Yellow toner for use in Xerox Phaser 7760	11274
Uni Drum™ drum gearless for use in Xerox Phaser 7760	11887
Smartchip™ Black, Cyan, Magenta, Yellow drum unit for use in Xerox Phaser 7760	11920
PCR roller for use in Xerox Phaser 7760	14124
Wiper blade for use in Xerox Phaser 7760	14309
Absolute Black® toner for use in Xerox Phaser 7760	14881
Absolute Cyan® toner for use in Xerox Phaser 7760	14882
Absolute Magenta® toner for use in Xerox Phaser 7760	14883
Absolute Yellow® toner for use in Xerox Phaser 7760	14884
Absolute Color® KCMY Carrier for use in Xerox Phaser 7760	14885
Absolute Black® toner for use in Xerox Phaser 7760	14886
ABsolute Cyan® toner for use in Xerox Phaser 7760	14887
Absolute Magenta® toner for use in Xerox Phaser 7760	14888
Absolute Yellow® toner for use in Xerox Phaser 7760	14889
X-Generation® drum gearless with insert for use in Xerox Phaser 7760	17559

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Black toner for use in Xerox Phaser 7760

17595

X-Generation® Cyan toner for use in Xerox Phaser 7760

17596

X-Generation® Magenta toner for use in Xerox Phaser 7760

17598

X-Generation® Yellow toner for use in Xerox Phaser 7760

17599

XEROX PHASER 6700

Absolute Black® toner for use in Xerox Phaser 6700

17272

Absolute Cyan® toner for use in Xerox Phaser 6700

17273

Absolute Magenta® toner for use in Xerox Phaser 6700

17274

Absolute Yellow® toner for use in Xerox Phaser 6700

17275

Smartchip® Black for use in Xerox Phaser 6700

17313

Smartchip® Cyan for use in Xerox Phaser 6700

17314

Smartchip® Magenta for use in Xerox Phaser 6700

17315

Smartchip® Yellow for use in Xerox Phaser 6700

17316

Smartchip™ Black drum unit for use in Xerox Phaser 6700

18175

Smartchip™ Cyan drum unit for use in Xerox Phaser 6700

18176

Smartchip™ Magenta drum unit for use in Xerox Phaser 6700

18177

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow drum unit for use in Xerox Phaser 6700

18178

Absolute Black® toner for use in Xerox Phaser 6700

18674

Absolute Cyan® toner for use in Xerox Phaser 6700

18675

Absolute Magenta® toner for use in Xerox Phaser 6700

18676

Absolute Yellow® toner for use in Xerox Phaser 6700

18677

X-Generation® Black toner for use in Xerox Phaser 6700

18879

X-Generation® Cyan toner for use in Xerox Phaser 6700

18880

X-Generation® Magenta toner for use in Xerox Phaser 6700

18881

X-Generation® Yellow toner for use in Xerox Phaser 6700

18882

SuMMiT® drum gearless for use in Xerox Phaser 6700

18961

X-Generation® Black toner for use in Xerox Phaser 6700

20404

X-Generation® Cyan toner for use in Xerox Phaser 6700

20405

X-Generation® Magenta toner for use in Xerox Phaser 6700

20406

X-Generation® Yellow toner for use in Xerox Phaser 6700

20407

XEROX PHASER 7700

Absolute Magenta™ toner for use in Xerox Phaser 7700

9402

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Yellow™ toner for use in Xerox Phaser 7700

9403

Absolute Black® toner for use in Xerox Phaser 7700

9444

Absolute Cyan™ toner for use in Xerox Phaser 7700

9445

Absolute Magenta™ toner for use in Xerox Phaser 7700

9446

Absolute Yellow™ toner for use in Xerox Phaser 7700

9447

Uni Drum™ gearless for use in Xerox Phaser 7700, C 2220

9988

Recovery blade for use in Xerox Phaser 7700, C 2220

10900

PCR roller for use in Xerox Phaser 7750, 7700, C 2220

10948

Absolute Black® toner for use in Xerox Phaser 7700

11195

Absolute Cyan™ toner for use in Xerox Phaser 7700

11196

Wiper blade for use in Xerox Phaser 7700

12185

XEROX PHASER 7750

Recovery blade for use in Xerox Phaser 7700, C 2220, 7750

10900

PCR roller for use in Xerox Phaser 7750, 7700, C 2220

10948

Absolute Black® toner for use in Xerox Phaser 7750

11183

Absolute Cyan™ toner for use in Xerox Phaser 7750

11184

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ toner for use in Xerox Phaser 7750

11185

Absolute Yellow™ toner for use in Xerox Phaser 7750

11186

Wiper blade for use in Xerox Phaser 7750, C 2220

11464

Uni Drum™ gearless for use in Xerox Phaser 7750

11922

XEROX PHASER 7800

Smartchip® Black for use in Xerox Phaser 7800

17681

Smartchip® Cyan for use in Xerox Phaser 7800

17682

Smartchip® Magenta for use in Xerox Phaser 7800

17683

Smartchip® Yellow for use in Xerox Phaser 7800

17684

Smartchip™ CMYK drum unit for use in Xerox Phaser 7800

17693

Uni Drum® with gears and insert for use in Xerox Phaser 7800

17698

SuMMiT® drum with gears and insert for use in Xerox Phaser 7800

17699

Smartchip® Black for use in Xerox Phaser 7800

18179

Smartchip® Cyan for use in Xerox Phaser 7800

18180

Smartchip® Magenta for use in Xerox Phaser 7800

18181

Smartchip® Yellow for use in Xerox Phaser 7800

18182

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Xerox Phaser 7800

19442

Absolute Cyan® toner for use in Xerox Phaser 7800

19443

Absolute Magenta® toner for use in Xerox Phaser 7800

19444

Absolute Yellow® toner for use in Xerox Phaser 7800

19445

Soft PCR roller for use in Xerox Phaser 7800

19558

Hard PCR roller for use in Xerox Phaser 7800

19593

Wiper blade for use in Xerox Phaser 7800

19613

XEROX PHASER 3320, WORKCENTRE 3315, 3325

Smartchip® for use in Xerox Phaser 3320

17657

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17658

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17659

Developer roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17660

Doctor blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17661

PCR roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17662

SuMMit® drum with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17663

Uni Drum® with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17664

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

X-Generation® Wiper blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17665

Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17669

Shipping lock for use in Xerox Phaser 3320, WorkCentre 3315, 3325

17750

Clear Seal for use in Xerox Phaser 3320, WC 3315, 3325

17897

SuMMiT® drum with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325

18896

Smartchip® for use in Xerox Phaser 3320 (106R02306)(Eastern Europe and S. America)

18965

Smartchip® for use in Xerox Phaser 3320, WorkCentre 3325, 3315

19284

XEROX PHASER 6000, 6010, WORKCENTRE 6015, DP CP 105, 205, CM 205, Dell 1250, 1355

Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015

16607

Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015

16608

Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015

16609

Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015

16610

Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355

16808

Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355

16809

Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015

17355

Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015

17356

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015	17357
Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015	17358
Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP105, 205, CM 205, Dell 1250, 1355	17802
Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP105, 205, CM 205, Dell 1250, 1355	17803
Absolute Black® toner for use in Xerox Phaser 6600, WC 6605	18323
Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605	18324
Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605	18325
Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605	18326
Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (WW)	18327
Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (WW)	18328
Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (WW)	18329
Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (WW)	18330
Absolute Black® toner for use in Xerox Phaser 6600, WC 6605	18779
Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605	18780
Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605	18781
Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605	18782
Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (106R02232)(EU)	19142

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (106R02229)(EU)	19143
Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (106R02230)(EU)	19144
Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (106R02231)(EU)	19145
PCR roller for use in Xerox Phaser 6600, WorkCentre 6605	19550
Smartchip® Black for use in Xerox Phaser 6600, WC 6605 (106R02236)(E.Europe, S.Africa, L.America)	19605
Smartchip® Cyan for use in Xerox Phaser 6600, WC 6605 (106R02233)(E.Europe, S.Africa, L.America)	19606
Smartchip® Magenta for use in Xerox Phaser 6600, WC 6605 (106R02234)(E.Europe, S.Africa, L.America)	19607
Smartchip® Yellow for use in Xerox Phaser 6600, WC 6605 (106R02235)(E.Europe, S.Africa, L.America)	19608

XEROX PHASER 3040, 3010, WORKCENTRE 3045 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	17489
Smartchip® toner for use in Xerox Phaser 3040, WorkCentre 3045	17490
Smartchip® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	17491
Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	17492
Smartchip® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	17696
Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	17771
Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045	18246

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX WORKCENTRE 5020, 5016 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Smartchip™ drum unit for use in Xerox Workcentre 5020, 5016	16963
Absolute Black® toner for use in Xerox Workcentre 5020, 5016	16965
SuMMiT™ drum with gears for use in Xerox Workcentre 5020, 5016	16966
Wiper blade for use in Xerox WorkCentre 5020, 5016	16967
Absolute Black® toner for use in Xerox Workcentre 5020, 5016	19023

XEROX WORKCENTRE 4118, FAXCENTRE 2218

X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218	5341
X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218	9509
Doctor blade for use in Xerox WorkCentre 4118, FaxCentre 2218	10873
Smartchip™ drum unit fuse for use in Xerox WorkCentre 4118, FaxCentre 2218	11589
SuMMiT™ Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218	15198
Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218	15748
Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218	16128
X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218	18045

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX WORKCENTRE 5222, 5225, 5230 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)**

Absolute Black® developer for use in Xerox XC 5210, 5220, 5222 (6R333)	5335
Absolute Black® toner for use in Xerox XC 5210, 5220, 5222 (6R333)	5337
Uni Drum™ OPC with gears for use in Xerox WorkCentre 5222, 5225, 5230	14107
Doctor blade for use in Xerox WorkCentre 5222, 5225, 5230	14108
Smartchip™ drum unit for use in Xerox WorkCentre 5222, 5225, 5230	14109
Absolute Black® toner for use in Xerox WorkCentre 5222, 5225,5230	15889
Absolute Black® toner for use in Xerox WorkCentre 5222, 5225, 5230	15890
Developer for drum unit for use in Xerox WorkCentre 5222, 5225,5230	15891
Seal for developer unit for use in Xerox WorkCentre 5222, 5225,5230	15893
Uni Drum™ with gears for use in Xerox WorkCentre 5222, 5225,5230	15894
Wiper blade for use in Xerox WorkCentre 5222, 5225,5230	15896
Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230	15897
Smartchip™ drum for use in Xerox WorkCentre 5222, 5225,5230	15898
Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230	16531
SuMMit® drum with gears for use in Xerox WorkCentre 5222, 5225, 5230	17013

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® toner for use in Xerox WorkCentre 5222, 5225, 5230 (106R01304)

18641

XEROX WORKCENTRE 4150

Absolute Black® toner for use in Xerox WorkCentre 4150

11554

Absolute Black® toner for use in Xerox WorkCentre 4150

11555

Smartchip™ toner cartridge for use in Xerox WorkCentre 4150

11556

Doctor blade for use in Xerox WorkCentre 4150

11557

Wiper blade for use in Xerox WorkCentre 4150

11559

Developer roller for use in Xerox WorkCentre 4150

11560

PCR roller for use in Xerox WorkCentre 4150

11561

Absolute Black® developer carrier for drum unit for use in Xerox WorkCentre 4150

11643

Smartchip™ drum unit for use in Xerox WorkCentre 4150

11644

Smartchip™ toner cartridge for use in Xerox WorkCentre 4150

14452

XEROX WORKCENTRE 4260, 4250 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ with connector for use in Xerox Workcentre 4250, 4260

15605

TEXT grade toner for use in Xerox Workcentre 4260, 4250

16073

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Xerox Workcentre 4260, 4250	17538
Absolute Black® toner developer for use in Xerox Workcentre 4260, 4250	17572
Smartchip™ drum unit for use in Xerox WorkCentre 4250, 4260	17642
Uni Drum® OPC with gears for use in Xerox WorkCentre 4250, 4260	17833

XEROX WORKCENTRE 7120, 7125 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Xerox Workcentre 7120, 7125	17539
Absolute Cyan® toner for use in Xerox Workcentre 7120, 7125	17540
Absolute Magenta® toner for use in Xerox Workcentre 7120, 7125	17541
Absolute Yellow® toner for use in Xerox Workcentre 7120, 7125	17542
Smartchip® Black toner for use in Xerox Workcentre 7120, 7125	17543
Smartchip® Cyan toner for use in Xerox Workcentre 7120, 7125	17544
Smartchip® Magenta toner for use in Xerox Workcentre 7120, 7125	17545
Smartchip® Yellow toner for use in Xerox Workcentre 7120, 7125	17546
Smartchip® Black toner for use in Xerox Workcentre 7120, 7125	18184
Smartchip® Cyan toner for use in Xerox Workcentre 7120, 7125	18185
Smartchip® Magenta toner for use in Xerox Workcentre 7120, 7125	18186

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip® Yellow toner for use in Xerox Workcentre 7120, 7125	18187
Smartchip® Black drum unit for use in Xerox Workcentre 7120, 7125	18188
Smartchip® Cyan drum unit for use in Xerox Workcentre 7120, 7125	18189
Smartchip® Magenta drum unit for use in Xerox Workcentre 7120, 7125	18190
Smartchip® Yellow drum unit for use in Xerox Workcentre 7120, 7125	18191
Uni Drum® with gears for use in Xerox WorkCentre 7125, 7120, 7220, 7225	19268
Wiper blade for use in Xerox WorkCentre 7125, 7120	19392

XEROX WORKCENTRE 7525, 7530, 7535, 7545, 7556 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17056
Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17057
Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17058
Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17059
Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17060
Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17061
Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17062
Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	17063

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ CMYK drum unit for use in Xerox WC 7525, 7530, 7535, 7540, 7545, 7556	17558
SuMMiT® drum with gears for use in Xerox Work Centre 7425, 7428, 7435, 7525, 7530, 7535, 7545, 7556, 7830, 7835, 7845, 7855	17646
X-Generation® Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	20844
X-Generation® Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	20845
X-Generation® Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	20846
X-Generation® Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556	20847

XEROX WORKCENTRE 7425, 7428, 7435 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)

Absolute Black® toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	10956
Absolute Yellow™ toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	10959
Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435	17048
Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435	17049
Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435	17050
Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435	17051
Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435	17052
Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435	17053
Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435	17054

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435	17055
X-Generation® Black toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17127
X-Generation® Cyan toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17128
X-Generation® Magenta toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17129
X-Generation® Yellow toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17130
X-Generation® Black toner for use in Xerox Work Centre 7425, 7428, 7435	17131
X-Generation® Cyan toner for use in Xerox Work Centre 7425, 7428, 7435	17132
X-Generation® Magenta toner for use in Xerox Work Centre 7425, 7428, 7435	17133
X-Generation® Yellow toner for use in Xerox Work Centre 7425, 7428, 7435	17134
X-Generation® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435	17601
Smartchip™ CMYK drum unit for use in Xerox WorkCentre 7435, 7428, 7425	17613
SuMMiT® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435	17646
SuMMiT® drum with gears for use in Xerox Work Centre 7425, 7428, 7435, 7525, 7530, 7535, 7545, 7556, 7830, 7835, 7845, 7855	17646
Wiper blade for use in Xerox WorkCentre C 7425, 7428, 7435	18302
Uni Drum™ gearless for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228	19952
Recovery blade for use in Xerox WorkCentre C 7425, 7428, 7435, 7830, 7835, 7845, 7855	20111

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX WORKCENTRE PRO C 7346, 7345, 7336, 7328, 3545, 2636, 2128**

Absolute Black® toner for use in Xerox WorkCentre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	10956
Absolute Yellow™ toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	10959
Smartchip™ drum for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228	19176
Uni Drum™ gearless for use in Xerox WorkCentre Pro C 7346, 7345, 7335, 7328, 7245, 7235, 7228	19952
X-Generation® Black toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17127
X-Generation® Cyan toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17128
X-Generation® Magenta toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17129
X-Generation® Yellow toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128	17130

XEROX WORKCENTRE PRO C 32, 40

Absolute Black® toner for use in Xerox WorkCentre Pro C 32, 40	9813
Absolute Cyan™ toner for use in Xerox WorkCentre Pro C 32, 40	9814
Absolute Magenta™ toner for use in Xerox WorkCentre Pro C 32	9815
Absolute Yellow™ toner for use in Xerox WorkCentre Pro C 32, 40	9816
Uni Drum™ gearless for use in Xerox WorkCentre Pro C 32, 40	11886

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX WORKCENTRE PRO C 320, 315**

GEAR set for drum for use in Xerox WC Pro 320, 315	5851
Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315	8329
Wiper blade for use in Xerox WorkCentre Pro 320, 315	8526
Mag roller sleeve for use in Xerox WorkCentre Pro 320, 315	8527
Doctor blade for use in Xerox WorkCentre Pro 320, 315	9257
Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315	9260
SuMMiT™ drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315	12361
X-Generation® Wiper blade for use in Xerox WorkCentre Pro 320, 315	17997

XEROX WORKCENTRE PRO C 420, 415

Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415	8901
Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415	8902
Wiper blade for use in Xerox WorkCentre Pro 420, 415	8911
Mag roller sleeve for use in Xerox WorkCentre Pro 420, 415	8914
Doctor blade for use in Xerox WorkCentre Pro 420, 415	9256
Smartchip™ for use in Xerox WorkCentre Pro 420, 415	9872

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

SuMMiT™ drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315

12361

XEROX DOCUPRINT C 3210, 2100

Toner fill hole plastic seal for use in Xerox DocuPrint C 3210, 2100

8300

Absolute Cyan™ toner for use in Xerox DocuPrint C 3210, 2100

11202

Absolute Magenta™ toner (6,000 pages) for use in Xerox DocuPrint C 3210, 2100

11203

Absolute Yellow™ toner for use in Xerox DocuPrint C 3210, 2100

11204

Uni Drum™ with gears for use in Xerox DocuPrint C 3210, 2100

11206

Wiper blade for use in Xerox DocuPrint C 3210, 2100

11207

Smartchip™ Black for use in Xerox DocuPrint C 3210, 2100

11208

Drum cover for use in Xerox DocuPrint C 3210, 2100

11242

Absolute Black® toner developer for use in Xerox DocuPrint C 3210, 2100

13559

Absolute Cyan™ toner developer for use in Xerox DocuPrint C 3210, 2100

13560

Absolute Magenta™ toner developer for use in Xerox DocuPrint C 3210, 2100

13564

Absolute Yellow™ toner developer for use in Xerox DocuPrint C 3210, 2100

13584

Absolute Black® toner for use in Xerox DocuPrint C 3210, 2100

14861

Absolute Cyan® toner for use in Xerox DocuPrint C 3210, 2100

14862

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta® toner for use in Xerox DocuPrint C 3210, 2100

14863

Absolute Yellow® toner for use in Xerox DocuPrint C 3210, 2100

14864

Black, Cyan, Magenta, Yellow carrier®

14865

XEROX DOCUPRINT C 3290 SF

Absolute Black® toner for use in Xerox Docuprint C 3290 SF

13955

Absolute Cyan™ toner for use in Xerox Docuprint C 3290 SF

13956

Absolute Magenta™ toner for use in Xerox Docuprint C 3290 SF

13957

Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF

13958

Absolute Black® toner developer for use in Xerox Docuprint C 3290 SF

13965

Absolute Cyan™ toner developer for use in Xerox Docuprint C 3290 SF

13966

Absolute Magenta™ toner developer for use in Xerox Docuprint C 3290 SF

13967

Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF

13968

Drum cover for use in Xerox Docuprint C 3290 SF

13969

Unidrum™ with gears for use in Xerox Docuprint C 3290 SF

16498

XEROX DOCUPRINT 220, 230, 240, 332, 340, 425, 440, DC 220, 230, 420

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

5271

OPC Drum with gears for use in Xerox DC 220, 230

5639

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00484

5773

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00313

5782

PCR roller for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

5909

Doctor blade for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

7011

Xerox DC 220, 230, 420, Smartchip™ w/housing

8170

Smartchip™ with housing for use in Xerox DC 220, 230, 420

8171

Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440

8508

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

8768

Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00318

8769

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

9103

Smartchip™ w/housing for use in Xerox DC 220, 230, 420

9104

XEROX DOCUPRINT 2050

Absolute Black® toner for use in Xerox DocuPrint 2050

11290

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX WORKCENTRE 4118, FAXCENTRE 2218**

X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218

5341

X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218

9509

SuMMiT™ Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218

15198

Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218

15748

Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218

16128

X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218

18045

X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218

18045

XEROX FAXCENTRE F 116, 1012

Absolute Black® toner for use in Xerox FaxCentre F 116, 1012

9811

Absolute Black® toner for use in Xerox FaxCentre F 116, 1012

16128

SuMMiT™ drum with gears for use in Xerox FaxCentre F 116, 1020

16600

XEROX DOCUCENTRE C 450, 400, 320

Absolute Black® toner for use in Xerox Document Centre C 250, 360, 450

10031

Absolute Cyan™ toner for use in Xerox Document Centre C 250, 360, 450

10032

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ toner for use in Xerox Document Centre C 250, 360, 450

10033

Absolute Yellow™ toner for use in Xerox Document Centre C 250, 360, 450

10034

Upper heat roller for use in Xerox Docucentre 450, 400, 320

16244

XEROX DOCUCENTRE 6550, 5540

Upper heat roller for use in Xerox Docucentre 6550, 5540

16242

Wiper blade for use in Xerox DC C 7780, 7600, 7550, 7500, 6680, 6550, 6500, 5580, 5540, 5500, 5400, 5065 Black drum unit

19232

Wiper blade for use in Xerox DC C 7780, 7600, 7550, 7500, 6680, 6550, 6500, 5580, 5540, 5500, 5400, 5065 CMY drum unit

19337

XEROX DOCUCOLOR C 3535, 2240, 1632

Absolute Black® toner for use in Xerox DocuColor C 3535, 2240, 1632

9709

Absolute Cyan™ toner for use in Xerox DocuColor C 3535, 2240, 1632

9710

Absolute Magenta™ toner for use Xerox DocuColor C 3535, 2240, 1632

9711

Absolute Yellow™ toner for use in Xerox DocuColor C 3535, 2240, 1632

9712

Uni Drum™ gearless for use in Xerox DocuColor C 3535, 2240, 1632

11884

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #****XEROX DOCUCOLOR 12, 1256, 50**

Absolute Black® toner for use in Xerox Docucolor 12, 1256, 50

8333

Universal toner carrier for use in Xerox Docucolor 12, 1256, 50

9088

Absolute Magenta™ toner for use in Xerox Docucolor 12, 1256, 50

9090

Absolute Yellow™ toner for use in Xerox Docucolor 12, 1256, 50

9091

Universal toner carrier K/C/M/Y carrier for use in Xerox Docucolor 12, 1256, 50

10652

XEROX DOCUCOLOR 2045, 2060, 5252, 6060

Universal toner carrier K/C/M/Y for use in Xerox Docucolor 2045, 2060, 5252, 6060

8299

Absolute Black® toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8337

Absolute Cyan™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8338

Absolute Magenta™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8339

Absolute Yellow™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060

8340

XEROX DOCUCOLOR 4 LP

Absolute Black® toner for use in Xerox Docucolor 4 LP

8043

Absolute Cyan™ toner for use in Xerox Docucolor 4 LP

8044

COPIER SUPPLIES & PARTS - ENGINE MODEL**UNINET PART #**

Absolute Magenta™ toner for use in Xerox Docucolor 4 LP

8046

Absolute Yellow™ toner for use in Xerox Docucolor 4 LP

8045

Universal toner carrier for use in Xerox Docucolor 4 LP

9057

XEROX 5318, 5320

Absolute Black® toner for use in Xerox 5318, 5320

782

Smartchip™ reset fuse for use in Xerox 5318, 5320, 5322

5892

XEROX 5614, 5114, 5113

Absolute Black® toner for use in Xerox 5614, 5114, 5113

7472

Smartchip™ for use in Xerox 5614, 5114, 5113

7725

Smartchip™ for use in Xerox 5614, 5114, 5113

7726

XEROX XC 5210, 5220, 5222

Absolute Black® developer for use in Xerox XC 5210, 5220, 5222

5335

Absolute Black® toner for use in Xerox XC 5210, 5220, 5222

5337

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS****BROTHER®**

Replacement toner cartridge for use in Brother TN 460, 6600

TN 460

5021

Replacement toner cartridge for use in Brother HL 1650

TN 560

11037

Replacement toner cartridge for use in Brother HL 5250, 5270, TN 580, 550, 3170, 3130, 3185, 3145

TN 650, 580

11050

Replacement toner cartridge for use in Brother HL 5140, 5150, 5170, TN 570, 540, 3030, 3060

TN 570

11059

Replacement toner cartridge for use in Brother HL 2040, 2050, 2070

TN 350, 2000, 2025

11239

Replacement toner cartridge for use in Brother HL 5340, 5350, 5370, 5380, MFC 8480

TN 650, 3280, 3290

15029

Replacement toner cartridge for use in Brother HL 2140, 2150, 2170,

TN 360, 2150, 2120

16810

Replacement toner cartridge for use in Brother HL 2240, 2242, 2250, 2270

TN 450, 420, 2220, 2250

16811

Replacement toner cartridge for use in Brother HL 1650, 1670, 1870, 5040, 5050, 5070

TN 7600, 7300

16812

Replacement toner cartridge for use in Brother HL 5470, 5450, 5440

TN 750

18483

Replacement toner cartridge for use in Brother HL 1110, 1111, 1112, 1118

TN 1040, 1050, 1060, 1070

19296

Replacement toner cartridge for use in Brother HL L 2380, 2360, 2340, 2320, 2305 2300, DCP-L 2540, 2520,
MFC L 2740, 2720, 2700

TN 660

20035

Replacement toner cartridge for use in Brother HL 1110, 1111, 1112, 1118

TN 1000, 1010, 1020, 1030,

20076

Replacement Black toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970,
9960, 9560, 9465, 9460

TN315, 318, 328, 348BK

20317

Replacement Cyan toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970,
9960, 9560, 9465, 9460

TN315, 325, 345C

20318

Replacement Magenta toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC
9970, 9960, 9560, 9465, 9460

TN315, 325, 345M

20319

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Yellow toner cartridge for use in Brother HL 4570, 4170, 4150, 4140, DCP 9055, 9270, MFC 9970, TN315, 325, 345Y 9960, 9560, 9465, 9460		20320	
Replacement Black toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, TN-210K 9010		20321	
Replacement Cyan toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, TN-210C 9010		20322	
Replacement Magenta toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, 9010	TN-210M	20323	
Replacement Yellow toner cartridge for use in Brother HL 3075, 3070, 3045, 3040, MFC 9325, 9320, 9125, 9120, 9010	TN-210Y	20324	
Replacement toner cartridge for use in Brother HL 6180, MFC 8950, DCP 8250	TN 780	20349	
Replacement Black toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850	TN-900, 369, 359, 349, 339, 329, 319BK	20554	
Replacement Cyan toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850	TN-900, 369, 359, 349, 339, 329, 319C	20555	
Replacement Magenta toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850	TN-900, 369, 359, 349, 339, 329, 319M	20556	
Replacement Yellow toner cartridge for use in Brother HL 9300, 9200, 8350, 8250, DCP 8450, 8400, MFC 9550, 8850	TN-900, 369, 359, 349, 339, 329, 319Y	20557	
Drum Unit			
Replacement drum unit cartridge for use in Brother HL 2040, 2050, 2070, DR 350, 2000, 2025,	DR 350	16751	
Replacement drum unit cartridge for use in Brother HL 2140, 2150, 2170, DR 360, 2100, 2125,	DR 360	16752	
Replacement drum unit cartridge for use in Brother HL 5240, 5250, 5270, DR 550, 520, 3100, 3115,	DR 620	16753	
Replacement drum unit cartridge for use in Brother HL 5340, 5350, 5370, DR 650, 620, 3200, 3215	DR 620	16754	
Replacement drum unit cartridge for Brother DR 450, 420, 2200, 2225, HL 2130, 2132, 2230, 2240, 2242, 2250, 2270	DR 450	16756	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement drum unit cartridge for use in Brother DR 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110	DR 720	18484	
Replacement drum unit cartridge for use in Brother DR 1000, 1020, 1035, 1050, 1060, 1070, HL 1110, 1111, 1112, 1118	DR 1000	19295	
Replacement drum unit cartridge for use in Brother DR-630, 2320, HL-L 2380, 2360, 2340, 2300, DCP-L 2540, MFC L 2740, 2720, 2700	DR 630	20702	
Replacement drum cartridge for use in Brother DR 720, HL 6180, 5470, 5450, 5440, MFC 8950, 8910, 8810, 8710, 8510, DCP 8155, 8150, 8110	DR 720	20549	
CANON®			
Replacement black toner cartridge for use in Canon NP 1010, 1020	F41-6601-000	101	
Replacement black toner cartridge for use in Canon NP 6080, 6150, 6080,6550, 6650, 7000, 7050, 8070, 8530, 8570	F41-9502-740	107	
Replacement black toner cartridge for use in Canon IR 1600, 2000, 2010	GPR8	213	
Replacement black toner cartridge for use in Canon NP 1215, 2020, 2120	NPG1	457	
Replacement toner cartridge for use in Canon NP 4050, 4080, 4145, C 400	NPG 4/1375A004AA	5274	
Replacement toner cartridge for use in Canon NP 3030, 3050, C 300	NPG 5	5275	
Replacement black toner cartridge for use in Canon IR 1210, 1230, 1270, 1300, 1310, 1330, 1370, 1510, 1530, 1570 1630, 1670	GPR 10	5613	
Replacement black toner cartridge for use in Canon NP 6030, 6025, 6330	NPG 7 /1377A002AA	5824	
Replacement toner cartridge for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130	NPG 11	6354	
Replacement toner cartridge for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130	NPG 11	6354	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement black toner cartridge for use in Canon NP 6050	NPG 10	6973	
Replacement black toner cartridge for use in Canon IR 2200, 2220, 2800, 3300, 3320	GPR-6 /6647A003A/AA	7068	
Replacement black toner cartridge for use in Canon GP 40	F42-3201-700	7179	
Replacement black toner cartridge for use in Canon NP 4335, 4835	F41-6001-100	7231	
Replacement black toner cartridge for use in Canon IR 550, 600	F42-1401-200D	7497	
Replacement black toner cartridge for use in Canon IR 200, 330, 400	F42-3201-700	7498	
Replacement black toner cartridge for use in Canon GP 30, 55	F41-8601-000	7502	
Replacement black toner cartridge for use in Canon NP 6045, 6545, 6551, 6560	NPG 14 / F41-1923-740	7548	
Replacement black toner cartridge for use in Canon IR 6000, 6020, 5000, 5020, 4600	NPG-16/ GPR 4/F42-1401-200D	7549	
Replacement black toner cartridge for use in Canon NP 6085, 6285	NPG 12/ F41-7901-000	7550	
Replacement black toner cartridge for use in Canon NP 6035	NPG-13	7551	
Replacement toner cartridge for use in Canon Laser Class 710, A10	7621A001AA	9216	
Replacement Black toner cartridge for use in Canon IR C 3100, 3170	GPR-13K	11106	
Replacement Cyan toner cartridge for use in Canon IR C 3100, 3170	GPR-13C	11107	
Replacement Magenta toner cartridge for use in Canon IR C 3100, 3170	GPR-13M	11108	
Replacement Yellow toner cartridge for use in Canon IR C 3100, 3170	GPR-13Y	11109	
Replacement black toner cartridge for use in Canon GP 200,200F, 210, 210E, 210G	F42-1401-700	12289	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550, GPR 23	0452B003AA	12749	
Replacement Cyan toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0453B003AA	12750	
Replacement Magenta toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0454B004AA	12751	
Replacement Yellow toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0455B004AA	12752	
Replacement black toner cartridge for use in Canon™ Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025	GPR22	12888	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement black toner cartridge for use in Canon™ Imagerunner 1018,1020, 1022, 1023, 1024,1025	GPR22	12888	
Replacement black toner cartridge for use in Canon GP 200	F42-1401-700	12889	
Replacement black toner cartridge for use in Canon™ IR 2016, 2018, 2020, 2022, 2025, 2030	0384B003AA	12890	
Replacement black toner cartridge for use in Canon Imagerunner 2520, 2525, 2530	GPR35/2785B003AA	15088	
Replacement Black toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2792B003AA/GPR33	17290	
Replacement Cyan toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2796B003AA/GPR33	17291	
Replacement Magenta toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2800B003AA/GPR33	17292	
Replacement Yellow toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2804B003AA/GPR33	17293	
Replacement black toner cartridge for use in Canon Imagerunner 6055, 6065, 6075	GPR 38	17329	
Replacement black toner cartridge for use in Canon Imagerunner 8085, 8105	GPR37	17590	
Replacement toner cartridge for use in Canon Imagerunner 1730, 1740, 1750	GPR-39/48	18705	
Replacement toner cartridge for use in Canon IR 8500, 9070	6748A003AA / GPR-7	19208	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement toner cartridge for use in Canon IR 2230, 2270, 2830, 2870, 3530, 3570, 4570	9634A003AA / GPR-16	19209	
Replacement toner cartridge for use in Canon Imagerunner 5570	0279B003AA/GPR-17	19210	
Replacement toner cartridge for use in Canon Imagerunner 7105, 7086, 7095	0387B003AA/GPR-19	19211	
Replacement toner cartridge for use in Canon Imagerunner 2545, 2535	GPR -34	19458	
Replacement Black toner cartridge for use in Canon IR C 3220, 3200, 2620	7629A001AA / GPR-11	19491	
Replacement Cyan toner cartridge for use in Canon IR C 3220, 3200, 2620	7628A001AA / GPR-11	19492	
Replacement Magenta toner cartridge for use in Canon IR C 3220, 3200, 2620	7627A001AA - GPR-11	19493	
Replacement Yellow toner cartridge for use in Canon IR C 3220, 3200, 2620	7626A001AA / GPR-11	19494	
Replacement Black toner cartridge for use in Canon IR C 5180, 5185	1069B001AA / GPR-20	19498	
Replacement Cyan toner cartridge for use in Canon IR C 5180, 5185	1068B001AA / GPR-20	19499	
Replacement Magenta toner cartridge for use in Canon IR C 5180, 5185	1067B001AA / GPR-20	19500	
Replacement Yellow toner cartridge for use in Canon IR C 5180, 5185	1066B001AA / GPR-20	19501	
Replacement Black toner cartridge for use in Canon IR 5050, 5055, 5065, 5075	1872B003AA / GPR-24	19502	
Replacement Black toner cartridge for use Canon Imagerunner C 4080, 4580	0262B001AA / GPR-21	19532	
Replacement Cyan toner cartridge for use Canon Imagerunner C 4080, 4580	0261B001AA / GPR-21	19533	
Replacement Magenta toner cartridge for use Canon Imagerunner C 4080, 4580	0260B001AA / GPR-21	19534	
Replacement Yellow cartridge for use Canon Imagerunner C 4080, 4580	0259B001AA / GPR-21	19535	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020	3782B003AA / GPR-36	20041	
Replacement Cyan cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020	3783B003AA / GPR-36	20042	
Replacement Magenta cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020	3784B003AA / GPR-36	20043	
Replacement Yellow cartridge for use in Canon Imagerunner Advance C 2230, 2225, 2220, 2030, 2025, 2020	3785B003AA / GPR-36	20044	
Replacement Black cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030	2790B003AA / GPR-31	20045	
Replacement Cyan cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030	2794B003AA / GPR-31	20046	
Replacement Magenta cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030	2798B003AA / GPR-31	20047	
Replacement Yellow cartridge for use in Canon Imagerunner Advance C 5240, 5235, 5035, 5030	2802B003AA / GPR-31	20048	
Replacement Black cartridge for use in Canon Imagerunner Advance 4251, 4245, 4225, 4057, 4051	4791B003AA / GPR-42	20049	
REPLACEMENT DRUM UNIT CARTRIDGE			
Replacement drum unit cartridge for use in Canon NP 1215	1316A001AA	9212	
FUJI XEROX ®			
Replacement toner cartridge, Black for use in Fuji Xerox Docuprint C 1190 FS	CT201260	14956	
Replacement toner cartridge, Cyan for use in Fuji Xerox Docuprint C 1190 FS	CT201261	14957	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement toner cartridge, Magenta for use in Fuji Xerox Docuprint C 1190 FS

CT201262

14958

Replacement toner cartridge, Yellow for use in Fuji Xerox Docuprint C 1190 FS

CT201263

14959

KYOCERA®

Replacement black toner cartridge for use in Kyocera KM 4230, 5230, Ai 4040, 5050

37015011

4969

Replacement black toner cartridge for use in Kyocera KM 4530, 5530, 6330, 7530

TK601

5075

Replacement black toner cartridge for use in Kyocera KM Ai 2310, 3010

37016011

5079

Replacement black toner cartridge for use in Kyocera KM 1505, 1510, 1810

37029011

5249

Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035

370AB011

5251

Replacement black toner cartridge for use in Kyocera KM 1500 LA

TK 17 LA

5931

Replacement black toner cartridge for use in Kyocera FS 1700

TK 20 H

5995

Replacement black toner cartridge for use in Kyocera FS 1920

TK 57 H, 55 H

6809

Replacement black toner cartridge for use in Kyocera FS 3820

TK 67, 65

6810

Replacement black toner cartridge for use in Kyocera KM 1500, 1815

TK100

7047

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement black toner cartridge for use in Kyocera FS 1700	TK 20 H	7612	
Replacement black toner cartridge for use in Kyocera FS 9100, 9500	TK 70 H	7764	
Replacement toner cartridge for use in Kyocera Mita DC 1560, 1860, 2360	37090011	7913	
Replacement toner cartridge for use in Kyocera Mita DC 2255	37037011	6075	
Replacement toner cartridge for use in Kyocera Mita DC 3555, 3585,4585	3,705,601,137,050,010	5273	
Replacement toner cartridge for use in Kyocera Mita DC 1605	37046011	6458	
Replacement black toner cartridge for use in Kyocera FS 1020, 1118	TK 18 H	8664	
Replacement black toner cartridge for use in Kyocera FS 1900	TK 50	9607	
Replacement black toner cartridge for use in Kyocera FS 3800	TK 60 H	9608	
Replacement black toner cartridge for use in Kyocera FS 720, 820, 1016	TK 112, 110	9630	
Replacement Black toner cartridge for use in Kyocera KM C 2230	0T5HNOUS	9795	
Replacement Cyan toner cartridge for use in Kyocera KM C 2230	0T5HNCUS	9796	
Replacement Magenta toner cartridge for use in Kyocera KM C 2230	0T5HNBUS	9797	
Replacement Yellow toner cartridge for use in Kyocera KM C 2230	(0T5HNAUS)	9798	
Replacement Black toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ011)	9799	
Replacement Cyan toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ511)	9800	
Replacement Magenta toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ411)	9801	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Yellow toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ311)	9802	
Replacement black toner cartridge for use in Kyocera FS 1000	TK 17 H	9817	
Replacement black toner cartridge for use in Kyocera KM 6230	TK 623 (37026011)	9980	
Replacement black toner cartridge for use in Kyocera KM Ai 6060, 5555	37013011	10009	
Replacement black toner cartridge for use in Kyocera KM 1620, 1650, 2020, 2050	TK 420, 421, 410, 411,	10300	
Replacement black toner cartridge for use in Kyocera FS 1030	TK 122, 120	10420	
Replacement black toner cartridge for use in Kyocera FS 2000	TK 312, 310	11117	
Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900	TK 322, 320	11118	
Absolute Black® toner cartridge for Kyocera TK 322, 320, FS 3900	TK 322, 320	11119	
Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035	(370AB011, TK 2530)	11319	
Replacement black toner cartridge for use in Kyocera FS 9530, 9130	TK 712	11372	
Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050	TK 717, 719	11375	
Replacement black toner cartridge for use in Kyocera KM 8530	TK 631	11639	
Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050	TK 715	13093	
Replacement black toner cartridge for use in Kyocera KM 2540, 2560, 3040, 3060	TK 675, 679	13533	
Replacement black toner cartridge for use in Kyocera FS 1100	TK 137, 140, 142	14103	
Replacement black toner cartridge for use in Kyocera FS 1300, 1350	TK 132, 130	14366	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement black toner cartridge for use in Kyocera FS 4020	TK 360, 362, 364	14802	
Replacement black toner cartridge for use in Kyocera FS 1320, 1370	TK 170,172,173,174	15967	
Replacement black toner cartridge for use in Kyocera Mita TASKalfa 180, 220, KM 1620	TK 437	16245	
Replacement black toner cartridge for use in Kyocera Mita TaskAlfa 420i, 520i	TK 725	16246	
Replacement black toner cartridge for use in Kyocera KM 1525, 1530, 1570, 2030, 2070	37028011	16748	
Replacement black toner cartridge for use in Kyocera Mita TASKalfa 255, 255 B, 305, FS 6025, 6030	TK 477	17029	
Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP	TK 1142	17535	
Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP	TK 1140	17582	
Replacement Black toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe	TK865K	18275	
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe	TK865C	18276	
Replacement Magenta toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe	TK865M	18277	
Replacement Yellow toner cartridge for use in Kyocera TASKalfa 300, 250 ci Europe	TK865Y	18278	
Replacement Black toner cartridge for use in Kyocera Taskalfa 350ci, 250ci USA	TK867	18279	
Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500	TK6305	18313	
Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500	TK6307	18314	
Absolute Black® Replacement toner cartridge for use in Kyocera FS 1030 MFP, 1130 MFP	TK-1130	18479	
Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP	TK 1142	18480	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP	TK 1147	18481	
Absolute Black® Replacement toner cartridge for use in Kyocera FS 1035, 1135 MFP	TK 1140	18482	
Replacement toner cartridge for use in Kyocera FS 1024, 1110, 1124	TK 1102	18706	
Replacement toner cartridge for use in Kyocera FS 6950	TK 442, 440,430	18707	
Absolute Black® Replacement toner cartridge for use in Kyocera TASKalfa 255, 255 B, 305, FS 6025, 6030	TK479	19294	
Replacement toner cartridge for use in Kyocera TK 710, FS 9530, 9130 EU	TK710	19429	
Replacement toner cartridge for use in Kyocera TASKalfa 255, 255 B, 305, FS 6025, 6030	TK 475	19554	
Replacement toner cartridge for use in Kyocera FS 1100 EU	TK 140	19625	
Replacement toner cartridge for use in Kyocera KM 2820, 2810	TK 137	19626	
Replacement toner cartridge for use in Kyocera FS 1120, ECOSYS P 2035	TK 162	19790	
Replacement toner cartridge for use in Kyocera FS 4000	TK 332	19791	
Replacement toner cartridge for use in Kyocera FS 3900	TK 322	19792	
Replacement toner cartridge for use in Kyocera FS 4200, M 3550	TK 3122	19793	
Replacement toner cartridge for use in Kyocera FS 2100, ECOSYS M 3540, 3040	TK 3102	19926	
Replacement Black toner cartridge for use in Kyocera Mita FSC 5350, 5300, Ecosys P 6030 US	TK 562	19972	
Replacement Cyan toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US	TK 562	19973	
Replacement Magenta toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US	TK 562	19974	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Yellow toner cartridge for use in Kyocera Mita FS C 5350, 5300, Ecosys P 6030 US	TK 562	19975	
Replacement toner cartridge for use in Kyocera ECOSYS FS 1120, 1040, 1020	TK 1112	19976	
Replacement toner cartridge for use in Kyocera ECOSYS FS 1125, 1060, 1025	TK 1122	19977	
Replacement Black toner cartridge for use in Kyocera Mita FS 3920, 3640, 3540, 3140, 3040 MFP US	TK 352	20023	
Replacement Black toner cartridge for use in Kyocera Mita FS 4300, M 3560	TK 3132	20024	
Replacement Black toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US	TK8307K	20959	
Replacement Cyan toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US	TK8307C	20960	
Replacement Magenta toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US	TK8307M	20961	
Replacement Yellow toner cartridge for use in Kyocera Taskalfa 3551, 3550, 3051, 3050 MFP US	TK8307Y	20962	
Replacement Black toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US	TK8507K	20963	
Replacement Cyan toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US	TK8507C	20964	
Replacement Magenta toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US	TK8507M	20965	
Replacement Yellow toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP US	TK8507Y	20966	
Replacement cartridge for use in Kyocera Taskalfa 2201, 2200, 1801, 1800 MFP	TK-4109, 4107, 4105	21071	
Replacement cartridge for use in Kyocera TaskAlfa 3011i, 3010i US	TK 7107	21074	
Replacement Black toner cartridge for use in Kyocera TaskAlfa 820, 620 MFP	TK 665	21083	
Replacement Black toner cartridge for use in Kyocera TASKalfa 552, 500, 400	TK-855K	21204	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 552, 500, 400	TK-857C	21205	
Replacement Yellow toner cartridge for use in Kyocera TASKalfa 552, 500, 400	TK-857Y	21207	
Replacement Magenta toner cartridge for use in Kyocera TASKalfa 552, 500, 400	TK-855M	21210	
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8317C	21213	
Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8317M	21214	
Replacement Black toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8315K	21216	
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8315C	21217	
Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8315M	21218	
Replacement Yellow toner cartridge for use in Kyocera TASKalfa 2550ci MFP	TK-8315Y	21219	
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2551ci MFP	TK-8327C	21221	
Replacement Magenta toner cartridge for use in Kyocera TASKalfa 2551ci MFP	TK-8325M	21222	
Replacement Black toner cartridge for use in Kyocera TASKalfa 2551ci MFP	TK-8325K	21224	
Replacement Cyan toner cartridge for use in Kyocera TASKalfa 2551c MFP	TK-8325C	21225	
Replacement Yellow toner cartridge for use in Kyocera TASKalfa 2551ci MFP	TK-8325Y	21227	
Replacement Black toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP	TK8505K	21231	
Replacement Cyan toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP	TK8505C	21232	
Replacement Magenta toner cartridge for use in Kyocera Taskalfa 5551, 5550, 4551, 4550 MFP	TK8505M	21233	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
TK8505Y	21234	
TK8305K	21235	
TK8305C	21236	
TK8305M	21237	
TK8305Y	21238	

KONICA MINOLTA®

8935-802	7684	
8931-602	7905	
8936-202	8158	
MT601A, 602A	8162	
TN211	8969	
502A,B	9977	
8937-905	9745	
8937-908	9746	
8937-907	9747	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Yellow toner cartridge for use in Konica Minolta CF 2002, 3102	8937-906	9748	
Replacement black toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-401	9749	
Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-701	9750	
Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-601	9751	
Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-501	9752	
Replacement black toner cartridge for use in Konica Minolta Di 551, 650, 5510, 7210	604A,B	9974	
Replacement black toner cartridge for use in Konica Minolta Di 450, 470, 550	502A,B	9977	
Replacement black toner cartridge for use in Konica Minolta Di 520, 620	603A,B	9978	
Replacement black toner cartridge for use in Konica Minolta Di 1810, 2010, 2510, 3010, 3510	205 A,B/305 A,B	9979	
Replacement black toner cartridge for use in Konica Minolta Di 750	8971-111	10226	
Replacement black toner cartridge for use in Konica Minolta Di 850	8937-807	10230	
Replacement black toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	TN 210	11098	
Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-508	11099	
Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-507	11100	
Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-506	11101	
Replacement Black toner cartridge for use in Konica Minolta Bizhub 350	8938-402	11613	
Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250	8938-415	11614	(EU)

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black toner cartridge for use in Konica Minolta Bizhub 350	8938-402	11615	
Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250, 360	8938-413	11616	(US)
Replacement black toner cartridge for use in Konica Minolta Bizhub 152,162,180,181 210	8937-884	11617	
Replacement black toner cartridge for use in Konica Minolta Bizhub 360, 420, 421, 500, 501	8938-402	11619	
Replacement black toner cartridge for use in Konica Minolta Bizhub 600, 750	TN710	11620	
Replacement black toner cartridge for use in Konica Minolta Bizhub 920	TN910	11621	
Replacement black toner cartridge for use in Konica Minolta EP 4000, 5000	8935-502, MT 501	11705	
Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM131, A0YM130, TN-510K, TN510K, 020V	11741	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM431, A0YM430, TN-510C, TN510C, 020Y	11742	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM331, A0YM330, TN-510M, TN510M, 020X	11743	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM231, A0YM230, TN-510Y, TN510Y, 020W	11744	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement toner cartridge for use in Konica Minolta 7030, 7025, 7020	950-236,01QJ	15409	
Replacement toner cartridge for use in Konica Minolta 7022, 7130, 7222, 7228	950-246, TN301K,O17Q	15410	
Replacement toner cartridge for use in Konica Minolta 7035	950-251, O1WK	15411	
Replacement toner cartridge for use in Konica Minolta 7135, 7235	950-367, TN303K, O2BP	15412	
Replacement toner cartridge for use in Konica Minolta 7145	960-420, TN401K, O2AS	15413	
Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430	15738	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

OEM #	UNINET PART #	SPECIAL CHARACTERISTICS	
Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM330	15739	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM230	15740	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7132	16293	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7432	16295	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7332	16296	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7232	16297	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Konica Minolta Bizhub 223, 283	TN 217	17014	
Replacement black toner cartridge for use in Konica Minolta Bizhub 363, 423	TN414	17015	
Replacement black toner cartridge for use in Konica Minolta Bizhub C 451	TN411K	17119	
Replacement black toner cartridge for use in Konica Minolta Bizhub C 550, 650	TN611K	17120	
Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611C	17121	
Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611M	17122	
Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611Y	17123	
Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42	TN415	17591	
Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42	TN415	17592	
Replacement Black toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690	AOV301F	17604	
Replacement Cyan toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690	AOV301HF	17605	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Magenta toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690	AOV301CF	17606	
Replacement Yellow toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690	AOV306F	17607	
Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal)	17850	
Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17851	
Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17852	
Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17853	
Replacement toner cartridge for use in Konica Minolta Bizhub 164, 184, 215	TN 116, 117	18292	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216K	18308	
Replacement Cyan toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216C	18309	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216M	18310	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216Y	18311	
Replacement Black toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131	18312	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement black toner cartridge for use in Konica Minolta Bizhub 223, 283, 363, 423	TN 217 /TN414	18315	
Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131	18340	
Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131	18341	
Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131	18342	
Replacement Black toner cartridge for use in Konica Minolta Bizhub 652, 552	(TN-618)(A0TM132)	19089	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Absolute Black® Replacement toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN411K/TN611K	19090	
Replacement Black toner cartridge for use in Minolta Bizhub C 224	TN321K	19091	
Replacement Cyan toner cartridge for use in Minolta Bizhub C 224	TN321C	19092	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 224	TN321M	19093	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 224	TN321Y	19094	
Replacement toner cartridge for use in Minolta Bizhub 360, 361, 420, 421, 500, 501 EU		19289	
Replacement Black toner cartridge for use in Minolta Bizhub C 554, 454	TN512K, A33K132	20015	
Replacement Cyan toner cartridge for use in Minolta Bizhub C 554, 454	TN512C, A33K432	20016	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 554, 454	TN512M, A33K332	20017	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 554, 454	TN512Y, A33K232	20018	
Replacement Black toner cartridge for use in Minolta Bizhub C 754, 654	TN 711, 712, A3VU330	20019	
Replacement Cyan toner cartridge for use in Minolta Bizhub C 754, 654	TN711C, A3VU430	20020	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 754, 654	TN711M, A3VU330	20021	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 754, 654	TN711Y, A3VU230	20022	
Replacement Black toner cartridge for use in Konica Minolta Bizhub 3320	TNP41, TNP43	20656	
Replacement Black toner cartridge for use in Konica Minolta Bizhub 4020	TNP40	20657	
Replacement Black toner cartridge for use in Minolta Bizhub C 3850, 3350	TNP-48K, A5X0130	20955	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Cyan toner cartridge for use in Minolta Bizhub C 3850, 3350	TNP-48C, A5X0430	20956	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 3850, 3350	TNP-48M, A5X0330	20957	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 3850, 3350	TNP-48Y, A5X0230	20958	
Replacement Black toner cartridge for use in Minolta Bizhub Press C 7000, 6000	TN 616K, A1U9130	21040	
Replacement Cyan toner cartridge for use in Minolta Bizhub Press C 7000, 6000	TN 616C, A1U9433	21041	
Replacement Magenta toner cartridge for use in Minolta Bizhub Press C 7000, 6000	TN 616M, A1U9333	21042	
Replacement Yellow toner cartridge for use in Minolta Bizhub Press C 7000, 6000	TN 616Y, A1U9233	21043	
Replacement Black toner cartridge for use in Minolta Bizhub C 287, 227 MFP	TN 221K, A8K3130	21200	
Replacement Cyan toner cartridge for use in Minolta Bizhub C 287, 227 MFP	TN 221C, A8K3430	21201	
Replacement Magenta toner cartridge for use in Minolta Bizhub C 287, 227 MFP	TN 221M, A8K3330	21202	
Replacement Yellow toner cartridge for use in Minolta Bizhub C 287, 227 MFP	TN 221Y, A8K3230	21203	

LANIER®

Replacement black toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885317	9563	
Replacement cyan toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885320	9564	
Replacement magenta oner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885319	9565	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement yellow toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C

885318

9566

Replacement black toner cartridge for use in Lanier 7355, 7365

1170227

16284

NASHUATEC®

Replacement black toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

885372BK

8138

Replacement cyan toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888037

8139

Replacement magenta toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888036

8140

Replacement yellow toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850

888035

8141

OKIDATA®

Replacement black toner cartridge for use in Okidata Okipage 4W

52106201

477

Replacement black toner cartridge for use in Okidata OL 400e

52107201

492

Replacement black toner cartridge, compatible for use in Okidata Okipage 8W, 6W

52111701

7033

Replacement toner cartridge for use in Okidata 14, 14ex, 14i

TYPE 8

8894

Replacement toner cartridge for use in Okidata C 5100

42127404 / 42127408

10217

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Absolute Cyan™ Replacement toner cartridge for use in Okidata C 5100	42127403 / 42127407	10218	
Absolute Magenta™ Replacement toner cartridge for use in Okidata C 5100	42127402 / 4212740	10219	
Absolute Yellow™ Replacement toner cartridge for use in Okidata C 5100	42127401 / 42127405	10220	
Replacement Black Glossy toner cartridge for use in Okidata C 9000	41963604 / 41963600	10221	
Replacement Cyan Glossy toner cartridge for use in Okidata C 9000	41963603 / 41963607	10222	
Replacement Magenta glossy toner cartridge for use in Okidata C 9000	41963602/ 41963606	10223	
Replacement Yellow glossy toner cartridge for use in Okidata C 9000	41963601/41963605	10224	
Replacement Black Glossy toner cartridge for use in Okidata C 5100	42127404 /42127408	10433	
Absolute Cyan™ Glossy Replacement toner cartridge for use in Okidata C 5100	42127403 /42127407	10434	
Absolute Magenta™ Glossy Replacement toner cartridge for use in Okidata C 5100	42127402 / 42127406	10435	
Absolute Yellow™ Glossy Replacement toner cartridge for use in Okidata C 5100	42127401 / 42127405	10436	
Replacement Black glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304208	10844	
Replacement Cyan glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304207	10845	
Replacement Magenta glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304206	10846	
Replacement yellow glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304205	10847	
Replacement black toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459304	12855	
Replacement cyan toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459331	12856	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement magenta toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459330	12857	
Replacement yellow toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459329	12858	
Replacement Absolute Black® toner cartridge for use in Okidata C 831	44844512	20387	
Replacement Absolute Cyan® toner cartridge for use in Okidata C 831	44844511	20388	
Replacement Absolute Magenta® toner cartridge for use in Okidata C 831	44844510	20389	
Replacement Absolute Yellow® toner cartridge for use in Okidata C 831	44844509	20390	
Replacement Absolute Black® toner cartridge for use in Okidata C 711, 710 US	44318604	21000	
Replacement Absolute Cyan® toner cartridge for use in Okidata C 711, 710 US	44318603	21001	
Replacement Absolute Magenta® toner cartridge for use in Okidata C 711, 710 US	44318602	21002	
Replacement Absolute Yellow® toner cartridge for use in Okidata C 711, 710 US	44318601	21003	

PANASONIC®

Replacement black toner cartridge for use in Panasonic KX P 4420	KX P 4420	527	
Replacement black toner cartridge for use in Panasonic DP 1520, 1820	DQ-TU10J-PU/PB	11680	
Replacement black toner cartridge for use in Panasonic DP 1510, 1810, 2010	DQ-TU10C	11681	
Replacement black toner cartridge for use in Panasonic DP 6530, 7240, 8130, 8540, 8570	T6510, T6510E	11685	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement black toner cartridge for use in Panasonic FP 7781, 7760

FQ-TE70

11838

Replacement black toner cartridge for use in Panasonic FP7728, 7735, 7742, 7750, 7830, 7835, 7845, 7850

FQTK20

13321

RICOH®

Replacement black toner cartridge for use in Ricoh FT 4118, 3813

885117

5245

Replacement black toner cartridge for use in Ricoh Aficio 1015, 1018, 1113

888086

5246

Replacement black toner cartridge for use in Ricoh Aficio 1022, 2022, 2032, 3030

888169

5247

Replacement black toner cartridge for use in Ricoh FT 4022, 4622

887718

5248

Replacement black toner cartridge for use in Ricoh 4080, 4150

5397-30

5278

Replacement black toner cartridge for use in Ricoh Aficio 1013, 1013F

885257

5894

Replacement black toner cartridge for use in Ricoh Type 310

889264

6456

Replacement black toner cartridge for use in Ricoh Aficio 200, 250

889613

7552

Replacement black toner cartridge for use in Ricoh Aficio 220, 270

885208

7553

Replacement black toner cartridge for use in Ricoh Aficio 350, 450

887725

7554

Replacement black toner cartridge for use in Ricoh Aficio 550, 650

887740

7555

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement black toner cartridge for use in Ricoh FT 4215, 4415, 4418, 4421	887523	7860	
Replacement Black toner cartridge for use in Ricoh Aficio 3800, 3850	885372BK	8138	
Replacement Cyan toner cartridge for use in Ricoh Aficio 3800	888037	8139	
Replacement Magenta toner cartridge for use in Ricoh Aficio 3800	888036	8140	
Replacement Yellow toner cartridge for use in Ricoh Aficio 3800	888035	8141	
Replacement toner cartridge for use in Ricoh Imagio MF 200	889613	8147	
Replacement black toner cartridge for use in Ricoh Imagio MF 250	TYPE 5	8149	
Replacement cyan toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636341	8273	
Replacement Black toner cartridge toner for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636338	8274	
Replacement Magenta toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636340	8275	
Replacement Yellow toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636339	8276	
Replacement toner cartridge for us ein Ricoh Imagio	TYPE 20	8704	
Replacement black toner cartridge for use in Ricoh Imagio P	TYPE 2	8706	
Replacement black toner cartridge for use in Ricoh Aficio 551, 700, Type 5105	887994	8827	
Replacement black toner cartridge for use in Ricoh Aficio 1035, 1045, 4510	885247, 888062	8828	
Replacement black toner cartridge for use in Ricoh Aficio 850, 1050	888008	8829	
Replacement black toner cartridge for use in Ricoh Aficio 1085, 1105, 2090, 2105	888156, 8885340	8830	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black toner cartridge toner for use in Ricoh CL 7000	885406	8837	
Replacement Cyan toner cartridge for use in Ricoh CL 7000	885409	8838	
Replacement Magenta toner cartridge for use in Ricoh CL 7000	885408	8839	
Replacement Yellow toner cartridge for use in Ricoh CL 7000	885407	8840	
Replacement Black toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885317	9563	
Replacement Cyan toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885320	9564	
Replacement Magenta toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885319	9565	
Replacement Yellow toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885318	9566	
Replacement Black toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888231	9567	
Replacement Cyan toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888234	9568	
Replacement Magenta toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888233	9569	
Replacement Yellow toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888232	9570	
Replacement black toner cartridge for use in Ricoh Aficio 400, 401, 500	11D,10D	11842	
Replacement black toner cartridge for use in Ricoh Aficio 2035, 2045	3110, 3210D	11843	
Replacement black toner cartridge for use in Ricoh Aficio 2015, 2018	888215	12233	
Replacement black toner cartridge for use in Ricoh Aficio 1515	888260	12234	
Replacement black toner cartridge for use in Ricoh Aficio 1060, 1075, 2051, 2060	885400	12235	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement cyan toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888607	12559	
Replacement black toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888604	12757	
Replacement magenta toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888606	12758	
Replacement yellow toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888605	12759	
Replacement Black toner for use in Ricoh Aficio MP C 2000, 2500, 3000	888636	12760	
Replacement cyan toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888639	12761	
Replacement magenta toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888638	12762	
Replacement yellow toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888637	12763	
Replacement Black toner for use in Ricoh Aficio MP 2500	MP2500,A,E	13381	
Replacement black toner cartridge for use in Ricoh Aficio MP 3500, 4000, 4001, 4500, 5000	884922, 8400040	15936	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Ricoh Aficio CL 7200, 7300	888442	16313	
Replacement Cyan toner cartridge for use in Ricoh Aficio CL 7200, 7300	888445	16314	
Replacement Magenta toner cartridge for use in Ricoh Aficio CL 7200, 7300	888444	16315	
Replacement Yellow toner cartridge for use in Ricoh Aficio CL 7200, 7300	888443	16316	
Replacement Black toner for use in Ricoh Aficio MP 8000 SP	885400	17028	
Replacement Black toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17389	
Replacement Cyan toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17391	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Magenta toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17392	
Replacement Yellow toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17393	
Replacement Black toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841500	17854	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841501	17855	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841502	17856	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841503	17857	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841452	17858	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for in Ricoh Aficio MPC 4501, 5501	841455	17859	
Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841454	17860	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841453	17861	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841084, 841288	20199	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841085, 841289	17863	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841086- 841290	17864	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841087, 841291	17865	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333	841276	18467	
Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333	841279	18468	
Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2880, 3300, 3333	841278	18469	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333	841277	18470	
Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MPC 2030, 2050 ,2550	841280	18471	
Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2030, 2550, 2551	841281	18472	
Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2030, 2050, 2550, 2551	841282	18473	
Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MPC 2030, 2050, 2550, 2551	841283	18474	
Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050	841284	18475	
Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050	841287	18476	
Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050	841286	18477	
Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MPC 4000, 5000, 5050	841285	18478	
Replacement toner cartridge for use in Ricoh Aficio MP 301 SP	841714	18560	
Replacement Black cartridge for use in Ricoh Aficio MPC 3002, 3502	841647	18561	
Replacement Cyan cartridge for use in Ricoh Aficio MP C 3002, 3502	841650	18562	
Replacement Magenta cartridge for use in Ricoh Aficio MP C 3002, 3502	841649	18563	
Replacement Yellow toner cartridge for use in Ricoh Aficio MP C 3002, 3502	841648	18564	
Replacement Black toner cartridge for use in Ricoh Aficio MPC 6000, 7500, 900g	841084, 841288	18912	
Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002	841751	19248	
Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002	841754	19249	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002	841753	19250	
Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002	841752	19251	
Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU		19259	
Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU		19260	
Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU		19261	
Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 5002, 4502, 4002 EU		19262	
Replacement Black toner cartridge for use in Ricoh SP 3400, 3410, 3400SF, 3410SF	406465	19312	
Replacement Black cartridge for use in Ricoh Aficio MPC 3002, 3502	841647	19512	
Replacement Cyan cartridge for use in Ricoh Aficio MP C 3002, 3502	841650	19513	
Replacement Magenta cartridge for use in Ricoh Aficio MP C 3002, 3502	841649	19514	
Replacement Yellow toner cartridge for use in Ricoh Aficio MP C 3002, 3502	841648	19515	
Replacement Black toner cartridge for use in Ricoh Aficio MPC 3501, 3001	841578	20025	
Replacement Black toner cartridge for use in Ricoh MP C 3503, 3003 US	841813	20027	
Replacement Cyan toner cartridge for use in Ricoh MP C 3503, 3003 US	841816	20028	
Replacement Magenta toner cartridge for use in Ricoh MP C 3503, 3003 US	841815	20029	
Replacement Yellow toner cartridge for use in Ricoh MP C 3503, 3003 US	841814	20030	
Replacement Black toner cartridge for use in Ricoh MP C 3503, 3003 EU	841817	20031	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Cyan toner cartridge for use in Ricoh MP C 3503, 3003 EU	841820	20032	
Replacement Magenta toner cartridge for use in Ricoh MP C 3503, 3003	841819	20033	
Replacement Yellow toner cartridge for use in Ricoh MP C 3503, 3003 EU	841818	20034	
Replacement Black toner cartridge for use in Ricoh MPC 2503, 2003, 360g US	841918	20131	
Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003, 275g US	841921	20132	
Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003, 275g US	841920	20133	
Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003, 275g US	841919	20134	
Replacement Black toner cartridge for use in Ricoh Aficio SP C 831, 830	821181	20135	
Replacement Cyan toner cartridge for use in Ricoh Aficio SP C 831, 830	821184	20136	
Replacement Magenta toner cartridge for use in Ricoh Aficio SP C 831, 830	821183	20137	
Replacement Yellow toner cartridge for use in Ricoh Aficio SP C 831, 830	821182	20138	
Replacement toner cartridge for use in Ricoh Aficio 1060, 1075, 2051, 2060, MP 5500, 6000, 6500, 7000, 7500, 885400 / Type 6110-D 8000		20155	
Replacement toner cartridge for use in Ricoh Aficio 1515, MP 161, 171	Type 1170D, 1270D	20156	
Replacement Black toner cartridge for use in Ricoh Aficio MP 3500, 4000, 4001, 4500, 5000, 5001, 5002	884922, 840040	20157	
Replacement Black toner cartridge for use in Ricoh Aficio MPC 6000, 7500	841084, 841288	20199	
Replacement Black toner cartridge for use in Ricoh SP 3500, 3510, 3500SF, 3510SF		20327	
Replacement Black cartridge for use in Ricoh Aficio SP 5210, 5200	SP5200HA	20543	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black cartridge for use in Ricoh Aficio SP 4310, 4210, 4110, 4100	Type 220	20565	
Replacement Black Jumbo cartridge for use in Ricoh SP 3500, 3510, 3500SF, 3510SF		20567	
Replacement toner cartridge for use in Ricoh MP 3554, 3054, 2554	841993	20725	
Replacement toner cartridge for use in Ricoh MP 6054, 5054, 4054	842126	20726	
Replacement toner cartridge for use in Ricoh Aficio MP 2501		20967	
Replacement Black toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US	841849	20968	
Replacement Cyan toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US	841852	20969	
Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US	841851	20970	
Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 US	841850	20971	
Replacement Black toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU	841853	20972	
Replacement Cyan toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU	841856	20973	
Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU	841855	20974	
Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 6004, 6003, 5503, 4504, 4503 EU	841854	20975	
Replacement Black toner cartridge for use in Ricoh MPC 2503, 2003 EU	841925	20983	
Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003 EU	841928	20984	
Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003 EU	841927	20985	
Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003 EU	841926	20986	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement Black toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20992

Replacement Cyan toner cartridge for use in Ricoh Aficio Ricoh Aficio MPC 7501, 6001 WW

20993

Replacement Magenta toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20994

Replacement Yellow toner cartridge for use in Ricoh Aficio MPC 7501, 6001 WW

20995

Replacement Cyan toner cartridge for use in Ricoh MPC 2503, 2003

841921

20132

Replacement Magenta toner cartridge for use in Ricoh MPC 2503, 2003

841920

20133

Replacement Yellow toner cartridge for use in Ricoh MPC 2503, 2003

841919

20134

Replacement Black cartridge for use in Ricoh Aficio SP 5310, 5300, MP 601, 501 SPF

407823

21039

Replacement cartridge for use in Ricoh Aficio SP 204, 203, 201, 200

407259 / 407254

21050

Replacement Black toner cartridge for use in Ricoh MPC 305

841621, 841618, 841622

21239

Replacement Cyan toner cartridge for use in Ricoh MPC 305

841591, 841595, 941607

21240

Replacement Magenta toner cartridge for use in Ricoh MPC 305

841592, 841596, 841608

21241

Replacement Yellow toner cartridge for use in Ricoh MPC 305

841593, 841597, 941609

21242

SAVIN®

Replacement Black toner cartridge for use in Savin® C 2408, 3210

9563

Replacement cyan toner cartridge for use in Savin® C 2408, 3210

9564

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS**

Replacement magenta toner cartridge for use in Savin® C 2408, 3210

9565

Replacement yellow toner cartridge for use in Savin® C 2408, 3210

9566

Replacement magenta toner cartridge for use in Savin® C 3224, 3828

9569

Replacement yellow toner cartridge for use in Savin® C 3224, 3828

9570

Replacement Black toner cartridge for use in Savin® 2235, 2238, 2245, 2535,2545

13802

SHARP®

Replacement black toner cartridge for use in Sharp AR 330, 400 NT

5326

Replacement black toner cartridge for use in Sharp SF 2022, 2027, 2035

222NT, 235NT

5977

Replacement black toner cartridge for use in Sharp SF 2216, 2220

(226NT)

7662

Replacement black toner cartridge for use in Sharp SF 2025,2030,2530,2040,2540

SF230,240NT

8984

Replacement black toner cartridge for use in Sharp AR 5120, 5015, 5220

AR016T,FT,ST

11601

(not for USA region)

Replacement black toner cartridge for use in Sharp AR 650, 800, 850

(AR650NT)

11641

Replacement black toner cartridge for use in Sharp™ SF 2050, 2052, 2060, 3062, 2260

AR360NT

12881

Replacement black toner cartridge™ for use in Sharp AR-M 162, 163, 164, 201

AR 201

13320

Replacement black toner cartridge for use in Sharp AR M 351, 355, 451, 455

AR455NT

14372

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

OEM #	UNINET PART #	SPECIAL CHARACTERISTICS	
Replacement Black toner cartridge for use in Sharp® MX 2300, 2700	MX27NTBA	14715	USA, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTCA	14716	USA, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTMA	14717	USA, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTYA	14718	USA, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Sharp® MX 2300, 2700	MX27GTBA	14719	Europe, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700	MX27GTCA	14720	Europe, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700	MX27GTMA	14721	Europe, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700	MX27GTMA	14722	Europe, THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Black toner cartridge for use in Sharp® MX 3501, 4501	MX45NTBA	14723	
Replacement Cyan toner cartridge for use in Sharp® MX 3501, 4501	MX45NTCA	14724	
Replacement Magenta toner cartridge for use in Sharp® MX 3501, 4501	MX45NTMA	14725	
Replacement Yellow toner cartridge for use in Sharp® MX 3501, 4501	MX45NTYA	14726	
Replacement black toner cartridge for use in Sharp AL 2021, 2031, 2041, 2051	AL-204TD	16521	
Replacement black toner cartridge for use in Sharp AR M 208, 236, 237, 256,257, 276, 277, 316, 317	AR270NT/310NT/T	17359	
Replacement black toner cartridge for use in Sharp MX-M 283,363,453, 503	MX500GT/NT	17447	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement black toner cartridge for use in Sharp MX M 260	MX312GT/N	17588	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement black toner cartridge for use in Sharp MX-M 200 D	MX-206NT	17849	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17866	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE THIS IS AN EASY TO REMANUFACTURE CARTRIDGE THIS IS AN EASY TO REMANUFACTURE CARTRIDGE THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement Cyan toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17867	
Replacement Magenta toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17868	
Replacement Yellow toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17869	
Replacement black toner cartridge for use in Sharp AR 5516, 5520	AR020T	18029	
Replacement Black toner cartridge for use in Sharp MX 2600, 2601N, 3100N	MX-31NTBA	18807	
Replacement Cyan toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001	MX31-C	18808	
Replacement Yellow toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001	MX31Y	18809	
Replacement Magenta toner cartridge for use in Sharp MX 2600, 2601N, 3100N, 4100, 4101, 5000, 5001	MX31-M	18810	
Replacement toner cartridge for Sharp AR 100, AL-1000	AL-100TD	19457	
Replacement Black toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402	MX-C40NTB	19527	
Replacement Cyan toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402	MX-C40NTC	19528	
Replacement Magenta toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402	MX-C40NTM	19529	
Replacement Yellow toner cartridge for use in Sharp® MX C 311, 312, 400, 401, 402	MX-C40NTY	19530	
Replacement Black toner cartridge for use in Sharp® MX 5500, 6200, 7000	MX70NTBA	19531	
Replacement Black toner cartridge for use in Sharp MX 5001, 5000, 4101, 4100	MX-50NTBA	20297	
Replacement toner cartridge for use in Sharp® MX-M 565, 564, 465, 464, 365, 364	MX560GT/NT	20418	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Black toner cartridge for use in Sharp® MX-C 301, 300, 250	MX-C30NTB	20703	
Replacement Cyan toner cartridge for use in Sharp® MX-C 301, 300, 250	MX-C30NTC	20705	
Replacement Magenta toner cartridge for use in Sharp® MX-C 301, 300, 250	MX-C30NTM	20706	
Replacement Yellow toner cartridge for use in Sharp® MX-C 301, 300, 250	MX-C30NTY	20707	
Replacement Black toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310	MX-23GTBA	21085	
Replacement Cyan toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU	MX-23GTCA	21086	
Replacement Magenta toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU	MX-23GTMA	21087	
Replacement Yellow toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310 EU	MX-23GTYA	21088	
Replacement Black toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310	MX-23NTBA	21089	
Replacement Cyan toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310	MX-23NTCA	21090	
Replacement Magenta toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310	MX-23NTMA	21091	
Replacement Yellow toner cartridge for use in Sharp MX 3116, 3111, 2616, 2310	MX-23NTYA	21092	
Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050	MX-60NTBA	21170	
Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050	MX-60NTCA	21171	
Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050	MX-60NTMA	21172	
Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4050, 3570, 3550, 3070, 3050	MX-60NTYA	21173	
Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60GTBA	21174	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60GTCA	21175	
Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050 (special order)	MX-60GTMA	21176	
Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60GYA	21177	
Replacement Black toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60FTBA	21178	
Replacement Cyan toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60FTCA	21179	
Replacement Magenta toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60FTMA	21180	
Replacement Yellow toner cartridge for use in Sharp MX 6070, 6050, 5070, 5050, 4070, 4060, 4050, 3570, 3560, 3550, 3070, 3060, 3050	MX-60FTYA	21181	
Replacement Black toner cartridge for use in Sharp MX M 356, 316, 266	MX-315NT	21258	
Replacement Black toner cartridge for use in Sharp MX M 356, 316, 266	MX-315GT	21259	
Replacement Black toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610	MX-36NTBA	21288	
Replacement Cyan toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610	MX-36NTCA	21289	
Replacement Magenta toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610	MX-36NTMA	21290	
Replacement Yellow toner cartridge for use in Sharp MX 3640, 3610, 3140, 3115, 3110, 2640, 2615, 2610	MX-36NTYA	21291	
Replacement Black toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP	MX-51NTBA	21292	
Replacement Cyan toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP	MX-51NTCA	21293	
Replacement Magenta toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP	MX-51NTMA	21294	
Replacement Yellow toner cartridge for use in Sharp MX 5141, 5140, 5111, 5110, 4141, 4140, 4111, 4110 MFP	MX-51NTYA	21295	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION**OEM #****UNINET PART #****SPECIAL CHARACTERISTICS****REPLACEMENT DRUM UNIT CARTRIDGE**

Replacement drum unit cartridge for use in Sharp AL 1000

AL100DR

19441

Replacement drum unit cartridge for use in Sharp FO-2081

FO55DR

17836

TOSHIBA®

Replacement copier black toner cartridge for use in Toshiba T 1550,1560

5960

Replacement black toner cartridge for use in Toshiba T 5560, 6560

5981

Replacement black toner cartridge for use in Toshiba T 1650, 1710, 2050, 2500

7967

Replacement black toner cartridge for use in Toshiba T 3550, 4550

7971

Replacement black toner cartridges for use in Toshiba T 120

8048

Replacement black toner cartridge for use in Toshiba E Studio 28, 35, 45, T 3500

8831

USA

Replacement black toner cartridge for use in Toshiba E Studio 16, 160, T 1600

8832

Replacement black toner cartridge for use in Toshiba E Studio 20, 25, T 2500

8989

Replacement black toner cartridge for use in Toshiba E Studio 55, 65, 80, T 6570

8990

USA

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement black toner cartridge for use in Toshiba e Studio 163, 165, 203, 205	T1640	11566	
Replacement black toner cartridge for use in Toshiba e Studio 350, 352, 450, 452	T-3520	11686	
Replacement black toner cartridge for use in Toshiba e Studio 620, 600, 720, 850,	T-6000, T6000E	11687	
Replacement black toner cartridge for use in Toshiba e Studio 200L, 202L, 230, 232, 280, 282	T-2320, 2340E	11688	
Replacement black toner cartridge for use in Toshiba e Studio 161,	T 1620	11689	
Replacement black toner cartridge for use in Toshiba e Studio 55, 65, 80	T6570E	11690	Europe
Replacement black toner cartridge for use in Toshiba e Studio 28, 35, 45,	T 3500	11841	Europe
Replacement black toner cartridge for use in Toshiba E Studio T 203L, 233, 283,	T2840	12595	
Replacement black toner cartridge for use in Toshiba e Studio 12, 15, 120, 150,	T1200	13430	
Replacement black toner cartridge for use in Toshiba e-Studio 202S, 203S,		13953	
Replacement black toner cartridge for use in Toshiba e-Studio 242,212, 182, 181,	T1810	15869	
Replacement black toner cartridge for use in Toshiba e Studio 205, 255, 305, 355, 455	T4530	15883	
Replacement black toner cartridge for use in Toshiba E studio 195, 225, 243, 245	T2450	17589	THIS IS AN EASY TO REMANUFACTURE CARTRIDGE
Replacement toner cartridge Black for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18504	
Replacement toner cartridge Cyan for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18505	
Replacement toner cartridge Magenta for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18506	
Replacement toner cartridge Yellow for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18507	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement toner cartridge for use in Toshiba e Studio 550 , 650, 810	T6510	19614	
Replacement toner cartridge for use in Toshiba e Studio 855, 853, 755, 723, 655, 603, 555, 523,	T7200, T8550	19263	
Replacement toner cartridge for use in Toshiba e-STUDIO 206L, 256, 306, 356, 506	T4590	19878	
Replacement Black toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25K	21296	
Replacement Cyan toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25C	21297	
Replacement Magenta toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25M	21298	
Replacement Yellow toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25Y	21299	
Replacement Black toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25EK	21300	
Replacement Cyan toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25EC	21301	
Replacement Magenta toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25EM	21302	
Replacement Yellow toner cartridge for use in Toshiba e-STUDIO 4540, 3540, 3040, 2540, 2040	TFC25EY	21303	

XEROX®

Replacement toner cartridge for use in Xerox 1012	6R257	741	
Replacement toner cartridge for use in Xerox 5614, 5114, 5113	6R751,6R752	7724	
Replacement cartridge for use in Xerox WorkCentre Pro 421	106R647	8825	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement toner cartridge for use in Xerox XD 100	6R914	8985	
Absolute Black® Replacement toner cartridge for use in Xerox Phaser 6110	106R01274	12764	
Absolute Magenta® Replacement toner cartridge for use in Xerox Phaser 6110	106R01272	12765	
Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6110	106R01273	12766	
Absolute Cyan® Replacement toner cartridge for use in Xerox Phaser 6110	106R01273	12768	
Replacement Black toner cartridge for use in Xerox Phaser 3160, 3155, 3140	108R00909	12854	
Replacement toner cartridge, Black for use in Fuji Xerox Docuprint C 1190 FS	CT201260	14956	
Replacement toner cartridge, Cyan for use in Fuji Xerox Docuprint C 1190 FS	CT201261	14957	
Replacement toner cartridge, Magenta for use in Fuji Xerox Docuprint C 1190 FS	CT201262	14958	
Replacement toner cartridge, Yellow for use in Fuji Xerox Docuprint C 1190 FS	CT201263	14959	
Replacement Black toner cartridge for use in Xerox Phaser 7400	10106R01080	15719	
Replacement Cyan toner cartridge for use in Xerox Phaser 7400	10106R01077	15720	
Replacement Magenta toner cartridge for use in Xerox Phaser 7400	10106R01078	15721	
Replacement Yellow toner cartridge for use in Xerox Phaser 7400	10106R01079	15722	
Replacement toner cartridge for use in Xerox DocuCentre 535, 545, 555	6R1046,006R010446	15933	
Replacement toner cartridge for use in Xerox WorkCentre 232, 238, 245, 255, 5665, 5675, 5687	006R01146	16253	
Replacement toner cartridge for use in Xerox WorkCentre M 20, C 20	106R01047	16496	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION	OEM #	UNINET PART #	SPECIAL CHARACTERISTICS
Replacement drum cartridge for use in Xerox WorkCentre M 20, C 20	113R00671	16497	
Replacement Black toner cartridge for use in Xerox Phaser 6128 MFP	106R01459	16720	
Replacement Cyan toner cartridge for use in Xerox Phaser 6128 MFP	106R01456	16721	
Replacement Magenta toner cartridge for use in Xerox Phaser 6128 MFP	106R01457	16722	
Replacement Yellow toner cartridge for use in Xerox Phaser 6128 MFP	106R01458	16723	
Replacement toner cartridge for use in Xerox Phaser 4510		17534	
Replacement Black toner cartridge for use in Xerox Phaser 6140		18041	
Replacement Cyan toner cartridge for use in Xerox Phaser 6140		18042	
Replacement Magenta toner cartridge for use in Xerox Phaser 6140		18043	
Replacement Yellow toner cartridge for use in Xerox Phaser 6140		18044	
Replacement toner cartridge for Xerox WorkCentre 3550	106R01531	19599	
Replacement toner cartridge for use in Xerox Phaser 3040, 3010, WorkCentre 3045	106R02182	19702	
Absolute Black® replacement toner cartridge for use in Xerox Phaser 6700		20208	
Absolute Cyan® replacement toner cartridge for use in Xerox Phaser 6700		20209	
Absolute Magenta® replacement toner cartridge for use in Xerox Phaser 6700		20210	
Absolute Yellow® replacement toner cartridge for use in Xerox Phaser 6700		20211	

COPIER REPLACEMENT TONER CARTRIDGES - PRODUCT DESCRIPTION

OEM #

UNINET PART #

SPECIAL CHARACTERISTICS

REPLACEMENT DRUM UNIT CARTRIDGE

Replacement drum unit cartridge for use in Xerox XD 100

13R551

8986